

Note to the user


The protective spring with nylon strap (item 7) and clamp (item 8) are added as replacement parts on the page 12, PARTS LIST / HANDPIECE.

Refer to the drawing below.

PARTS LIST / HANDPIECE

NOTE:

Spare or repair parts do not include mounting screws, if they are not listed on the description. Screws must be ordered separately.



Item No.	Part No.	Part Name	Description
1	B2544	Handle	With screws
2	A1143	Heating element	100V
	A1144	Heating element	110V
	A1145	Heating element	120V
	A1146	Heating element	220-240V
3	B1188	Silicone hose	
4	B1441	Pipe assembly	
5	B2556	Cord assembly	
6	B1354	Cord stopper	With screws
7	B2634	Protective spring	(120V only) With nylon strap
8	B2635	Clamp	(120V only)