

# ➤ Video Repair Parts



<b>■ Video Heads . . . . .</b>	<b>2</b>	<b>Cassette Housings . . . . .</b>	<b>80</b>
■ Akai / LG . . . . .	5	■ Akai . . . . .	80
■ Funai . . . . .	5	■ Daewoo / Tempest . . . . .	80
■ JVC . . . . .	5	■ Funai / Teac / Palsonic . . . . .	80
■ Hitachi . . . . .	5	■ LG / Goldstar . . . . .	80
■ Samsung . . . . .	5	■ JVC / Philips . . . . .	80
■ Video Head Cross Reference . . . . .	6	■ Mitsubishi . . . . .	81
■ AC Heads . . . . .	8	■ Panasonic . . . . .	81
<b>■ Motors . . . . .</b>	<b>9</b>	■ Samsung . . . . .	81
■ Akai . . . . .	9	■ Sanyo . . . . .	82
■ Daewoo . . . . .	10	■ Sharp . . . . .	82
■ Goldstar / LG . . . . .	10	■ Sony . . . . .	82
■ Funai / Teac / Palsonic . . . . .	10		
■ Hitachi . . . . .	10		
■ JVC . . . . .	11		
■ LG / Goldstar . . . . .	12		
■ Mitsubishi . . . . .	13		
■ NEC . . . . .	14		
■ National . . . . .	14		
■ Panasonic . . . . .	14		
■ Philips . . . . .	15		
■ Samsung . . . . .	15		
■ Sanyo . . . . .	16		
■ Sharp . . . . .	16		
■ Sony . . . . .	19		
■ Teac / Philips . . . . .	19		
<b>■ Video Belts . . . . .</b>	<b>20</b>	<b>Tension Bands . . . . .</b>	<b>83</b>
■ Cross Reference . . . . .	20	■ Akai . . . . .	83
■ Belt Kits . . . . .	22	■ Funai / Teac / Palsonic . . . . .	83
■ Video Belts & Idler Tyres . . . . .	23	■ LG / Goldstar . . . . .	83
■ Idler Tires . . . . .	24	■ Hitachi . . . . .	84
<b>■ Pinch Rollers . . . . .</b>	<b>25</b>	■ JVC . . . . .	84
■ Akai . . . . .	25	■ Mitsubishi . . . . .	84
■ Daewoo . . . . .	25	■ NEC . . . . .	85
■ Funai / Teac . . . . .	25	■ National . . . . .	85
■ Goldstar / LG / NEC . . . . .	25	■ Panasonic . . . . .	85
■ Hitachi . . . . .	25	■ Samsung . . . . .	85
■ JVC / Philips . . . . .	26	■ Sanyo . . . . .	86
■ Mitsubishi . . . . .	26	■ Sharp . . . . .	86
■ NEC . . . . .	26	■ Sony . . . . .	87
■ National . . . . .	26		
■ Panasonic . . . . .	27		
■ Philips / Teac . . . . .	27		
■ Samsung . . . . .	27		
■ Sanyo . . . . .	27		
■ Sharp . . . . .	27		
■ Sony . . . . .	27		
■ Video Pinch Roller Listing . . . . .	28		
<b>■ Overhaul Kits . . . . .</b>	<b>30</b>	<b>■ Mode Switches . . . . .</b>	<b>87</b>
■ JVC OEM . . . . .	30	■ Akai . . . . .	87
■ National Panasonic OEM . . . . .	31	■ Deitron / Tempest / Tracton . . . . .	88
■ JVC Replacement . . . . .	32	■ Funai / Teac . . . . .	88
■ National Panasonic Replacement . . . . .	32	■ Goldstar . . . . .	88
<b>■ Idlers &amp; Gears . . . . .</b>	<b>33</b>	■ Hitachi . . . . .	88
■ Akai . . . . .	33	■ JVC . . . . .	89
■ Daewoo / NEC / AWA / Tempest . . . . .	36	■ LG . . . . .	89
■ Funai / Teac / Palsonic . . . . .	38	■ Mitsubishi . . . . .	89
■ LG / Goldstar / NEC / Teac . . . . .	40	■ NEC . . . . .	90
■ Hitachi . . . . .	44	■ National . . . . .	90
■ JVC . . . . .	45	■ Panasonic . . . . .	91
■ Mitsubishi / AWA . . . . .	52	■ Orion . . . . .	91
■ NEC . . . . .	54	■ Samsung . . . . .	91
■ Orion . . . . .	55	■ Sanyo . . . . .	91
■ Panasonic . . . . .	55	■ Sharp . . . . .	92
■ Samsung . . . . .	63	■ Sony . . . . .	93
■ Sanyo / Fisher / Sony . . . . .	66		
■ Sharp . . . . .	68		
■ Sony . . . . .	75		
■ Toshiba . . . . .	79		
■ Teac / Philips . . . . .	79		
		<b>■ Mode Sensors . . . . .</b>	<b>94</b>
		■ Universal Lamps . . . . .	94
		■ JVC . . . . .	94
		■ Akai . . . . .	94
		■ Sharp . . . . .	94
		■ LG / Goldstar . . . . .	94
		■ National . . . . .	94
		■ NEC . . . . .	94
		■ JVC . . . . .	94
		■ Sharp . . . . .	94
		■ Rotational Sensor . . . . .	94
		■ Reel Sensor . . . . .	94
		■ Infrared . . . . .	94
		■ Components . . . . .	94
<b>■ Misc Parts . . . . .</b>	<b>95</b>		
■ Brake Pads . . . . .	95		
■ Misc Parts . . . . .	95		
■ Chroma . . . . .	95		
■ Switchmode Repair . . . . .	95		
<b>■ Servicing Tools and Accessories . . . . .</b>	<b>96</b>		



# Video Repair Parts


## □ Video Heads

### VIDEO HEADS

All VCR Heads are of OEM quality. Please be careful when replacing the heads, as physically damaged items are not covered under warranty. For a head not listed here, please enquire as there may be substitutes available. VH=Upper Drum Only VHD=Upper & Lower Drum with Motor.

PLEASE REFER TO CROSS-REFERENCE LISTING FOR SUGGESTED MODELS

Replaces	Equiv.	Code
AMSTRAD 255015	FUNAI, TEAC 8059-08-05	VH146
AKAI BV-V1004A280A	BV-V1022A170A	VH50
AKAI BV-V1030A220D		VH55
AKAI BV-V1047A220A		VH56
AKAI BV-V1015A120A		VH57
AKAI BV-V1075A420G	BV-V1123A420A	VH58
AKAI BV-V1075A420B	BV-V1102A420E, V1123A420B	VH59
AKAI BV-V1039A120A		VH270
AKAI BV-V1102A420G	BV-V1102A420C, V1102A420D	VH285
AKAI BV-V1102A420D		VH286
AKAI BV-V1182A420B		VH288
AKAI BV-V1182A420E		VH289
AKAI BV-V1123A420C	CIRCUIT BOARD TYPE	VH290
AKAI BV-V1182D420A	CIRCUIT BOARD TYPE	VH291
AKAI BV-V1234D430E	PIN TYPE	VH293
DAE-WOO, TEMPEST 97SA217900		VH190
DAE-WOO, TEMPEST 97SA428700		VH191
DAE-WOO, TEMPEST 97SA428700		VH193
FUNAI,TEAC 8000-01-13		VH140
FUNAI,TEAC 8059-01-19		VH142
FUNAI,TEAC 8059-01-20		VH143
FUNAI,TANDY 8059-01-95		VH144
FUNAI,TEAC 8059-08-05 [SP]		VH145
FUNAI,TEAC NFN513		VH147
FUNAI,TEAC 62DD806501601		VH440
FUNAI,TEAC 620806501610		VH442
GOLDSTAR 413-014/50/51/75/98		VH180
GOLDSTAR 413-159A		VH182
GOLDSTAR/NEC 413165D		VH185
HITACHI 5458161	5458165	VH94
HITACHI 5458413,5458415,5458282	5.45899E+14	VH96
HITACHI 5458104	5458282	VH98
HITACHI 5458434	5459002	VH99
HITACHI 5459001		VH100
HITACHI 5457474		VH240
HITACHI 5436103		VH245
HITACHI 5457471		VH248
HITACHI 5457472		VH249
JVC PU31332D	PU31332-GIO	VH10
JVC PU31332J		VH12
JVC PU31332L		VH14
JVC PQ20020B		VH15
JVC PQ20016B-2		VH16
JVC PQ20013C		VH17
JVC PU20850G		VH18
JVC PU31332F		VH20
JVC PDM2119		VH202
JVC PDM2001C-8		VH203
JVC PDM2004B		VH204
JVC PDM2007A		VH205
JVC PDM2112B		VH206
JVC PQ20014C/C4		VH207
JVC PDM3403C		VH210
JVC PRD2002D		VH214
JVC PDM2002C		VH215
JVC PDM2104B-9	PDM2104D	VH217
JVC PRD30050B		VH218
JVC PDM3353L		VH219
JVC PDM3353J14		VH420
JVC NKP0003LP	428869110625	VH425
MITSUBISHI 927B72302		VH119
MITSUBISHI 928B00804	928B00803	VH120
MITSUBISHI 928B22102		VH121
MITSUBISHI 928B334020		VH122
MITSUBISHI 927B499021		VH123






MORE SUBSTITUTES  
AVAILABLE SEE:  
<http://www.wes.com.au/>



## VIDEO HEADS Continued...

Replaces	Substitutes	Code
MITSUBISHI 928B79909		VH124
MITSUBISHI 928B17302	928B173050	VH125
MITSUBISHI 928B09004		VH126
MITSUBISHI 928B64109		VH127
MITSUBISHI 928B65409		VH128
MITSUBISHI 928B29602		VH130
MITSUBISHI 928B32207		VH132
MITSUBISHI 928B984021		VH133
MITSUBISHI 927B723014		VH134
MITSUBISHI 928B20702		VH135
MITSUBISHI 928B40409		VH136
MITSUBISHI 948B07002		VH137
MITSUBISHI 928B37107		VH138
MITSUBISHI 927B730021	928B65413 928B65407	VH139
NATIONAL VEH0103	VEH0131	VH30
NATIONAL VEH0322		VH31
NATIONAL VEH0366		VH32
NATIONAL VEH0339		VH33
NATIONAL VEH0416	VEH0386	VH34
NATIONAL VEH0417	VEH0385	VH36
NATIONAL VEH0288	VEH0279	VH37
NATIONAL VEH0265	VEH0231	VH38
NATIONAL VEH0343		VH39
NATIONAL VEH0121	VEH0115	VH40
NATIONAL VEH0171		VH41
NATIONAL VEH0177		VH42
NATIONAL VEH0201		VH43
NATIONAL VEH0209		VH44
NATIONAL VEH0252		VH45
NATIONAL VEH0218		VH46
NATIONAL VEH0267	VEH0256	VH47
NATIONAL VEH0287	VEH0270	VH48
NATIONAL VEH0286	VEH0295, VEH0296	VH49
NATIONAL VEH0352		VH201
NATIONAL VEH0225		VH298
NATIONAL VEH0269		VH299
NATIONAL VEH0300		VH300
NATIONAL VEH0323	VEH0324	VH303
NATIONAL VEH0400		VH304
NATIONAL VEH0415		VH305
NATIONAL VEH0433		VH310
NATIONAL VEH0467		VH315
NATIONAL VEH0454		VH317
NATIONAL VEH0531		VH319
NATIONAL VEH0532		VH320
NATIONAL VEH0548		VH330
NATIONAL VEH0598		VH335
NATIONAL VEH0599		VH336
NATIONAL VEH0601		VH337
NATIONAL VEH0653		VH340
NATIONAL VEH0679		VH343
NATIONAL VEH0712		VH346
NEC 824 23AH1		VH160
NEC 824 34AH1		VH161
NEC 826 11AH1		VH163
NEC 826 91AH1		VH164
NEC 82B 26AH1		VH165
NEC 827 63AH1		VH166
NEC NNC601		VH168
NEC 79V15036		VH172
NEC 79V15879		VH173
NEC 79V15041		VH174
ORION VH1, VH2		VH150
ORION VH3		VH155
TOSHIBA 70321968		VH89
TOSHIBA 70321320		VH91
TOSHIBA 70321488		VH92
TOSHIBA 70321994	70321827	VH93
TOSHIBA 70325174		VH389
TOSHIBA 70325185		VH390





MORE SUBSTITUTES  
AVAILABLE SEE:  
<http://www.wes.com.au/>



# Video Repair Parts

## VIDEO HEADS - Continued...

Replaces	Substitutes	Code
SAMSUNG 69000-390-013 (Grade "A")		VH77
SAMSUNG 69000-342-400		VH75
SAMSUNG 69000-390-012		VH76
SAMSUNG 69000-390-026		VH375
SAMSUNG 69020-124-042 (Head Only!)		VH376
SAMSUNG 69000-390-271		VH78
SANYO 613-022-0264	613-078-8672	VH79
SANYO 143-0-242V-22300/22400	143-0-242v-01700/002200	VH80
SANYO 143-0-771T-06500	143-0-771T-06800	VH81
SANYO 143-0-771T-13400	143-0-771T-09000	VH82
SANYO 143-0-762T-02000		VH85
SANYO 143-0-771T-06100	FISHER	VH87
SANYO 143-0-771T-25221		VH88
SANYO 613-096-8039		VH171
SANYO 613-164-0719		VH179
SANYO 613-166-2926		VH371
SANYO 143-0771T-09200		VH209
SHARP DDRMU0002HE09		VH21
SHARP DDRMU0004HE09	DDRMU0004HE12	VH22
SHARP DDRMU0001HE10		VH23
SHARP DDRMU0002HE04	DDRMU0002HE02 DDRMU0002HE05	VH24
SHARP DDRMU0004HE14	DDRMU0004HE17	VH26
SHARP DDRMU0004HE04		VH27
SHARP DDRMU0002HE17		VH28
SHARP DDRMW0005HE02		VH220
SHARP DDRMU0005HE10		VH224
SHARP NSH515		VH322
SHARP NSH516		VH222
SHARP NSH853		VH323
SHARP DDRMU0002HE36		VH225
SHARP DDRMU0002HE39		VH226
SHARP DDRMU0004HE22	DDRMU004HE23 TV/VCR	VH228
SHARP NSH551		VH229
SHARP NSH513		VH230
SHARP NSH852	NSH552	VH321
SONY DSR-35R		VH68
SONY DSR-43R		VH70
SONY 884-854-001		VH71
SONY DZR-27R 8848-54501		VH72
SONY 3-955-048-01		VH360
SONY 1-550-536-11		VH175
SONY 1-550-534-11		VH176
SONY 1-550-694-11		VH177
SONY 8-848-625-01		VH178




MORE MODELS  
AVAILABLE SEE:  
<http://www.wes.com.au/>


## DRUM ASSEMBLIES COMPLETE

Includes Upper-Drum (Video Head) with Lower-Drum & Motor

Description	Code
LG / AKAI DRUM ASSEMBLY 6723R-0101B	VHD0101
LG / AKAI DRUM ASSEMBLY 6723R-0103B	VHD0103
AKAI DRUM ASSEMBLY BV-V9009 A020A	DRM12
JVC DRUM ASSEMBLY HR-D170	DRM170
HITACHI DRUM ASSEMBLY VT128	DRM128
SAMSUNG DRUM 69017-123-710	DRM971
SAMSUNG DRUM 69017-124-042	DRM124
SAMSUNG DRUM 69017-124-059	DRM125
SAMSUNG DRUM 69017-124-061	DRM127



Motor Only  
See Page 9



Lower Drum  
Assemblies  
See  
Page 4-2

### Upper/Lower Drum Assemblies

Please note that some of the latest heads are only available in this complete form.

If the Upper Drum is available separately, it will be listed as "VH" and share the same suffix number from the substitution list as the "VHD" code number. (But not "DRM").

This is because of new manufacturing and head alignment techniques.



## Akai / LG

### AKAI / LG DRUM ASSEMBLIES

VHD Upper & Lower  
Drum assemblies  
With Motor.

6723R-0101B

Code  
VHD0101

6723R-0103B

Code  
VHD0103

Head only is available.  
See VH Listing.



## Funai

### FUNAI LOWER DRUM ASSEMBLY//\*\*/3


#### NON-SOLDER TYPE

Original Part No 6004-09-01, Chassis V-3S

Models MV307, 316, 445, 450,  
VCR417, 9000,  
VGX815, 820,

Suit VR1900, VX4000

Code FU901




## Servicing Tools and Accessories

### UNIVERSAL HEAD EXTRACTOR TOOL

Hand tool designed for extracting video heads without damage to the drum assembly.  
Adjustable for various heads.

Code  
HT800



### COTTON GLOVES

Eliminate the need to clean heads after fitting by using gloves. Recommended by leading manufacturers.  
Sold in pairs.


Code  
GLV2

## Hitachi

### HITACHI DRUM ASSEMBLY//\*\*/4

Complete UPPER &  
LOWER assembly.  
Suit VT128,etc.

Code  
DRM128




## JVC

### JVC COMPLETE DRUM ASSEMBLY//\*\*/5

Upper and lower  
drum assembly  
with motor, etc.  
Suit HR-D170, 171, etc.

Code  
DRM170




## Samsung

### SAMSUNG LOWER DRUM ASSEMBLIES//\*\*/6

#### 69000-370-034 (2HEAD)

Suit PB970, 971, TE90H Code DRM970



#### 69000-400-013 (4HEAD)

Suit VB350 Code LDR13

#### 69000-291-083 (2HEAD)

Suit VB306 Code LDR83

#### 69000-291-084 (4HEAD)

Suit VB336 Code LDR84

HEAD SOLD SEPARATELY

### JVC LOWER DRUM ASSEMBLY//\*\*/7


Lower drum & motor, etc.  
REQUIRES VIDEO HEAD

Suit Code  
HRD580 PDM2138H  
HRDX20 PDM2138Y

#### VIDEO HEAD

Optional Upper Drum


Suit Code  
HRDX20 VH216



### SAMSUNG DRUM ASSEMBLY//\*\*/8

#### 69017-123-710

Suit PB970, 971, 972 Code DRM971



#### 69020-124-042

Suit SV30B, AV30BV Code DRM124

#### 69020-124-059

Suit SV80, 81 Code DRM125

#### 69020-124-061

Suit SV140 Code DRM127

INCLUDES VIDEO HEAD



# Video Repair Parts

## Video Head Cross Reference

VIDEO HEADS		SUBSTITUTION LISTING			
AKAI					
Suit	Code	Suit	Code		
VP77	VH14	BLAUPUNKT	RTV100,200,202, RTV211,214 RTV222,224		
VP88	VH50		VH40 VH40 VH40		
VS1,2,3,5	VH50		VH49 VH45 VH46		
VS4	VH53		VH48 VH49 VH48		
VS6,8	VH57		VH49 VH48 VH48		
VS10	VH14		VH49 VH48 VH42		
VS11,12	VH75		VH48 VH48 VH47		
VS11EA	VH58		VH49 VH49 VH16		
VS12EA,VS15	VH270		VH49 VH49 VH16		
VS20,22,26	VH58		VH49 VH49 VH16		
VS35,53,55	VH59		VH299 VH43 VH38		
VS75	VH290		VH37 VH33 VH31		
VS105,112,115,116	VH55		VH34 VH34 VH48		
VS155,165	VH56		VH34 VH33 VH48		
VS200	VH75		VH33 VH33 VH40		
VS201,202,220,240	VH55		VH33 VH33 VH47		
VS301,303,304	VH55		VH34 VH34 VH47		
VS422,425	VH58		VH34 VH34 VH48		
VS465	VH285		VH34 VH33 VH48		
VS515	VH280		VH34 VH33 VH40		
VS765	VH59		VH34 VH33 VH40		
VS965,967	VH286		VH34 VH34 VH45		
VS7100,7300	VH14				
VS9300,9500	VH10				
VS9700,9800	VH10				
VSA650,1100,1110	VH290				
VSF10,11	VH58				
VSF12	VH285				
VSF30,33	VH59				
VSF200,220,221	VH58				
VSF300,301,305	VH285				
VSF302,315	VH285				
VSF400,410,430	VH59				
VSF440,441	VH59				
VSF500,510,550	VH290				
VSF560,580	VH290				
VSF590,600	VH290				
VSG30,33,34,35	VH285				
VSG40,43,44,45	VH59				
VSG51,54,55	VH59				
VSG60,64,65	VH290				
VSG205	VH58				
VSG240,242,245,246	VH291				
VSG262,265	VH293				
VSG280,281	VH293				
VSG405,411,415,	VH288				
VSG417,418,425	VH288				
VSG445,511	VH288				
VSG705,735,740	VH289				
VSG745,746,755,757	VH289				
VSG855,856,858	VH289				
VSP3EA	VH75				
VSP8,9	VH58				
<b>AMSTRAD</b>					
DD9904	VH146				
VCR3000	VH146				
VCR6000,6100	VH143				
VCR9512	VH146				
<b>AWA/THORN</b>					
AT1,ATV1	VH10				
ATV2,4,5	VH120				
ATV10,11	VH126				
ATV20,30	VH126				
AV10,11,TR101	VH126				
AV12,14, TR102	VH125				
AV21	VH137				
AV49	VH138				
AV51	VH135				
AV52	VH130				
AV58	VH128				
AV59	VH127				
AV61,62	VH180				
AV64,66	VH182				
AV411	VH136				
TR201	VH137				
<b>SEE ALSO MITSUBISHI</b>					
					
Suit	Code	Suit	Code		
BR1200 .	VH10	GOLDSTAR	GHV51 .		
BR7000,7030,7040	VH14		GHV1221,1232,1240		
BR7000ES.	VH14		VH180		
HR2200,2650	VH14		VH180		
HR3300,20,30,60	VH10		VH182		
HR3660,4000	VH14		VH182		
HR4100 .	VH10		VH182		
HR6200,7200	VH12		VH182		
HR7300 .	VH14		VH182		
HR7600,7610,7650	VH14		VH182		
HR7655EG	VH18		VH18		
<b>SUIT</b>		<b>SUIT</b>			
HR7700	VH20				
HRD110,111,120	VH14				
HRD121,225	VH14				
HRD140,141,142,143	VH16				
HRD150,157,157,158	VH16				
HRD160,170	VH216				
HRD171,210	VH216				
HRD180,230	VH204				
HRD250,257	VH15				
HRD300,400	VH211				
HRD320	VH216				
HRD337MS	VH215				
HRD455	VH207				
HRD522,540	VH216				
HRD530	VH203				
HRD565,566	VH209				
HRD580,600,640	VH211				
HRD725,726,755	VH17				
HRD750,830	VH206				
HRD92MS	VH203				
HRDX20,22	VH216				
HRFC100MS	VH215				
HRJ200	VH219				
HRJ220	VH210				
HRJ400	VH420				
HRS5000	VH202				
<b>SUIT</b>		<b>MARANTZ</b>			
MV693	VH201				
MV740A	VH220				
<b>CANON</b>		<b>MASUDA</b>			
VR10	VH41	M22	VH180		
VR30	VH45				
<b>CASIO</b>		<b>MITSUBISHI</b>			
VX2000	VH140	(or see AWA,GOLDSTAR)			
<b>COMPUTAR</b>		HS300,301,302	VH120		
CTR3024	VH138	HS303,304	VH126		
<b>DEITRON</b>		HS306	VH125		
DVR6158	VH191/VH193	HS307	VH135		
<b>DISTAR</b>		VT7,17,19,20E	VH99		
DS757	VH75	VT11,14,30,33,34	VH96		
<b>ESC</b>		VT35,38,39	VH100		
VCR8025	VH191/VH193	VT55,77	VH50		
<b>FERGUSON</b>		VT61,62,63	VH96		
3V00	VH10	VT100,110,111	VH248		
3V23,31,35	VH14	VT113,115,118	VH248		
V-1,V-2	VH140	VT120,125,128	VH248		
VCR4000,4500	VH140	VT130,138,145	VH249		
VCR4800,5200	VH140	VT168	VH240		
VIP1000,1400	VH140	VT258	VH249		
VIP2500,3000	VH142	VT330,340,503	VH96		
<b>FISHER See Sanyo</b>		VT418,528,	VH248		
<b>FUNAI</b>		VT428	VH249		
VPI100,1000,1400	VH140	VT498	VH240		
VIP2500A,3000A	VH142	VT518,528	VH248		
<b>G.E.</b>		VT538	VH249		
6900,7300	VH14	VT540,545	VH245		
8100,8900,9300	VH14	VT546,548	VH245		
<b>HMV</b>		VT680	VH94		
<b>ITT</b>		VT720,722,726,728	VH248		
TR3913A	VH12	VT3000	VH10		
VR3950	VH14	VT3428,3448	VH339		
VP100	VH14	VT4000,4200,5000	VH98		
<b>JVC</b>		VT5128,5148	VH339		
BR1200 .	VH10	VT5500,5600	VH98		
BR7000,7030,7040	VH14	VT6500,6800,7000	VH94		
BR7000ES.	VH14	VT8000,8040,8500	VH94		
HR2200,2650	VH14	VT8700,9000,9300	VH94		
HR3300,20,30,60	VH10	VT9500,9700,9900	VH94		
HR3660,4000	VH14	VTD660,665	VH245		
HR4100 .	VH10	VTL30	VH249		
HR6200,7200	VH12	VTM640,645,646	VH245		
HR7300 .	VH14	VTM720,722	VH248		
HR7600,7610,7650	VH14	VTM726,728	VH248		
HR7655EG	VH18	VTM748,730,731	VH245		
<b>NATIONAL/PANASONIC</b>		VTM735,736,740	VH245		
AG6200	VH298	VTM745,746	VH245		
AG5260	VH337	VTM818	VH248		
AG6124	VH343	VTP10,30	VH96		
NV100	VH41				
NV180	VH45				
NV200	VH41				
NV230,250,280	VH48				
NV260	VH49				
NV300,332,333,340	VH30				
NV370,380	VH46				
NV390	VH30				
NV430	VH48				
NV433	VH49				
NV450,460,470	VH48				
NV480,630	VH299				
NV600	VH44				
NV730,770	VH47				
NV777	VH42				
NV788	VH43				
NV850	VH38				
NV870,890	VH37				
NV2000,2010	VH30				
NV3000,7000,7200	VH40				
<b>More?....</b>		<b>Too Many Models To List Here! PLEASE ENQUIRE!</b>			
					
<a href="http://www.wes.com.au/">http://www.wes.com.au/</a>					

**More?.....  
Too Many Models  
To List Here!  
PLEASE ENQUIRE!**



<http://www.wes.com.au/>



Suit	Code	Suit	Code	Suit	Code	Suit	Code
<b>Panasonic Cont'...</b>							
NV7500,7800	VH40	VCR5000	VH14	M10,11,20,21,NX10	VH80	KV14VMIAS	VH142
NV8400	VH30	VCR6000	VH14	VBS7500,7600	VH80	SL8000,8080	VH70
NV8600	VH35	VCR7000	VH180	VTC5000,5005,5300	VH80	SLC5E,6E,7E,8	VH60
NV8610,8620	VH40	VCR7000	VH182	VTC5350,5400,5500	VH80	SLC9,	VH65
NV-D38,48	VH39			VTC5550	VH85	SLC30,34,35,40	VH68
NV-D80	VH201			VTC6000	VH80	SLF1,F30	VH68
NV-FS1	VH305			VTC9100,9300	VH85	SLVX10,20,25	VH176
NV-F55	VH330			VTC9355,9500	VH85	SLVX35	VH79
NV-F70	VH310			VHR120	VH79	SLVX30	VH72
NV-F96	VH330			VHR270	VH173	SLVX50	VH71
NV-FS90	VH315			VHR190,194,219	VH174	SLVX90,95,700	VH172
NV-FS100	VH317			VHR30,774	VH174	SLVX800	VH360
NV-G7,9	VH49			VHR60,630	VH179	SLVX810	VH177
NV-G10,11,12,16	VH48			VHR1100	VH88	SLVX811	VH178
NV-G20,21,22	VH39			VHR1300	VH88	SLV757	VH175
NV-G30,40	VH34			VHR1500,2500	VH81	SVT5000	VH172
NV-G33,45,46	VH36			VHR2370	VH88		
NV-G38	VH39			VHR2700	VH209		
NV-G50,500	VH304			VHR3100,3200	VH82		
NV-G400	VH303			VHR4100,5100	VH79		
NV-H65	VH33			VHR5300	VH171		
NV-H70	VH31			VHR5810	VH173		
NV-H75	VH201			VHR7100,7200	VH79		
NV-HD70,100	VH337			VHR7400,7440	VH171		
NV-J1,J3,J4	VH34			TLS900	VH371		
NV-J11	VH320						
NV-J30,J33	VH34						
NV-J35	VH36						
NV-J36	VH34						
NV-J45	VH319						
NV-J101	VH34						
NV-L10,L15,L20	VH34						
NV-L25	VH36						
NV-M7	VH32						
NV-P10	VH34						
NV-SD1	VH340						
NV-SD10	VH336						
NV-SD20,25	VH335						
NV-SD200,220	VH346						
NV-SD250,270	VH346						
NV-SD400,420,450	VH343						
TC14SV10	VH343						
TC21SV10	VH343						
<b>NEC</b>							
B5	VH70						
DS6000A	VH165						
DX1600	VH160						
DX3000	VH163						
N830,831,832	VH14						
N833,834,835	VH14						
N895	VH17						
N901,904	VH160						
N911,912	VH161						
N9011,9013	VH160						
N9033,9034,9040	VH160						
N9052,9053	VH160						
N9063,9065,9066	VH160						
N9073,9077,9083	VH160						
N9280	VH166						
N9401,9402	VH160						
N9530,9570	VH164						
N9610,9680	VH163						
PVC754E	VH60						
RV225	VH14						
RV300,310	VH10						
RV320,330,340,350	VH14						
RV360,370,375,380	VH14						
VP100	VH14						
<b>PYE</b>							
65VR20	VH46						
VRD022	VH24						
VRD100	VH191/VH193						
VRD300L	VH191/VH193						
VRD100L	VH75						
VRS012,022	VH24						
<b>PIONEER</b>							
VH780D	VH163						
<b>USUALLY HITACHI</b>							
PV300	VH155						
<b>PRESIDENT</b>							
<b>PYЕ</b>							
65VR20	VH46						
VRD022	VH24						
VRD100	VH191/VH193						
VRD300L	VH191/VH193						
VRD100L	VH75						
VRS012,022	VH24						
<b>RANK</b>							
PVC754E	VH60						
RV225	VH14						
RV300,310	VH10						
RV320,330,340,350	VH14						
RV360,370,375,380	VH14						
VP100	VH14						
<b>SABA</b>							
VR6005	VH20						
VR7000	VH10						
VR7730	VH10						
<b>SAMSUNG</b>							
PB/PK/PX990,1,2	VH78						
PB30R,VB306	VH76						
VB300,350	VH77						
VB336	VH77						
VB370	VH375						
VB617,627,629	VH75						
VB705,710,711,712	VH75						
VB713,720,721,729	VH75						
VB900,910,911,920	VH75						
VB930,950,970,971	VH75						
VB972,978,981,990	VH75						
VB/VX1230	VH76						
VB1260,1261	VH76						
VB/VK/VX1530	VH77						
VB/VK/VX1560,1561	VH77						
VB1850	VH375						
VD711,714	VH75						
VX510,616	VH75						
VX971,972	VH75						
SV30BV	VH376						
<b>SANYO</b>							
<b>SONY</b>							
<b>TEAC</b>							
MV306,307							
MV330							
MV400,430,435							
MV445,450							
MV606							
MV1400,1440							
MV1480							
MV2020							
MV3010,3050							
MV6010							
<b>TELEFUNKEN</b>							
VR440							
VR520							
VR540							
VR743							
VR780							
VR1935							
VR2925							
VR7979							
<b>TEMPEST</b>							
TE77R							
TE99R							
TE90H,900							
TE970R							
<b>TITAN</b>							
VCR1500							
<b>TRACKTON</b>							
VCR-32							
VCR-417TR							
<b>TRACKTON</b>							
VCR-32							
VCR-417TR							
<b>TOSHIBA</b>							
V21,31,33,35,53							
V55,V57							
V63							
V71,73,75,							
V81,83,84,85,86,93A							
V300							
V500							
V5250							
V5470							
V8600							
V8700							
V9600							
<b>VIDEO-PRO</b>							
VCR8025 with PCB							
VCR8025 PIN type							
							



# Video Repair Parts

## □ AC Heads

### AUDIO CONTROL HEADS

#### DAEWOO / DEITRON / TEMPEST / TRACTON / ESC / VIDEO-PRO

Original Part No	Suit	Code
97PA450300	TE970/VCR32/VCR8025	VBR4503
97S8005520	DVR6158D/TE99R/VRD300L	VBR5520

#### FUNAI / PALSONIC / TEAC

Original Part No	Suit	Code
6204-15-06		FU1506
62D62041520	MV3010,30,50, VCR9688	AC1520

#### LG GOLDSTAR

Original Part No	Suit	Code
3041R-0005A	Akai VSJ200, 215, 411, 416, 700, 711, 716 LG AF293, 493, 993, AC250, 450, 950	AC0005
225-402C W903H	LG	AC5402

#### HITACHI

Suit	Code
VTM598, 838	AC4061

#### JVC

Suit	Code
HRJ200,400	PEHE0247
HRD170,171 etc	PU59253
HRD520, etc	PU60617-3

#### JVC ERASE HEAD

Original Part No	Suit	Code
TDK6B50, L491	HRDX20, 22	PU60616
QAH0010-002	HRJ255,455,655,755., Philips VR288,388. 4822-249-1057	AC0002

#### NATIONAL / PANASONIC

Suit	Code
NV300.	VBR0050
NV600,777,788,RTV322	VBR0061
NV-G7,10,12,30 etc. & NV250,280,370 etc. , & RTV301, VR6520.	VBR0070
NV-G7,10,12,30 etc. & NV250,280,370 etc. , & RTV301, VR6520.	VBR0091
NVH70A	VBR0100
NV-G7,10,12,30 etc. & NV250,280,370 etc. & RTV301, VR6520.	VBR0103A
NV730, NV770	VBR0105A
NV-G20, NV-H75	VBR0112
NV-G20, NV-H75	VBR0125
NVL15	VBR0129
NV600,777,788,RTV322	VBR0156
NVF55, NVJ11	VED0160
NVSD10,20,30,NVHD70,100	VED0182
NVH70A	VEH0233
	VEH0237
NV-G7,10,12,30 etc. & NV250,280,370 etc. & RTV301, VR6520.	VEH0247
NVH70A	VEH0248
NV730, NV770	VEH0259
NVSD220, 270, 420, 620, 670	VED0363
NVSD220, 270, 420, 620, 670	VED0412

#### NEC

Original Part No	Suit	Code
79501140, 79501094		AC1140
79501145	N9033,N9034	AC1145
79501153	DX3000,N9052,9053,9530	AC1153
97SA311200	D284,DVK10W,DVK824,MV3080,MV6094, etc.	AC1200
82417PAI	N901, N911	AC2417
16190362	N9072/73/83, 9401/2, 9570	AC3620


#### SAMSUNG

Original Part No	Suit	Code
6526 4606 510	VB627	AC5033
6900 0291 032	VB300, 370, etc.	AC1032
66603-0006-00	SV10,11,12,30,80,140	AC600






#### SHARP

Original Part No	Suit	Code
RH-EDU0031GEZZ	VC381 etc.	DU0031
RH-EDU0040GEZZ		DU0040
RH-EDU0054GEZZ	VC100 etc.	DU0054
RH-EDU0056GEZZ	VC651X etc.	DU0056
RH-EDU0057GEZZ	VC782 etc.	DU0057
RH-EDU0058GEZZ	VCH851 etc.	DU0058
RH-EDU0070GEZZ	VCF18,VCA111,etc..	DU0070
RH-EDU0083GEZZ	VCA36, VCA37, VCA50	DU0083
RH-EDU0085CEZZ	VCA200, VCA460, VCH600, etc.	DU0085
RH-EDU0088GEZZ	VCA220,270,420,470.	DU0088

**MORE MODELS  
AVAILABLE SEE:  
<http://www.wes.com.au/>**



**NOTE. In some cases the PCB may differ.  
However, the head is interchangeable.**



<http://www.wes.com.au/>



## ☐ Motors

### VIDEO MOTORS




MORE MODELS  
AVAILABLE SEE:  
<http://www.wes.com.au/>

## ☐ Akai


### AKAI CAPSTAN MOTOR

Original	BM-386236J1,
Part No	DFX-67B3VWA1
Suit	VS422,425, VS465,756, VSF10,12
Code	VM3862




### AKAI LOADING MOTOR

Original	BM-348088,
Part No	MMN-5C2RP
Suit	VS1,3,4 VS6,8,etc.
Code	VM3480




### AKAI PC DRUM MOTOR BLOCK

Original	BM-M3223A020A
Part No	
Suit	VS105,112, VS115,116, VS165,etc.
Code	VM3223



### AKAI PC DRUM MOTOR BLOCK

Original	BM-M3224A020A,
Part No	BM-M3224A5010
Suit	VS240
Code	VM3224




### AKAI DRUM MOTOR BLO...

Original	BM-M3225A501A,
Part No	BM-M3225A020A
Suit	VS35 VS965
Code	VM3225




### AKAI DRUM MOTOR BLOCK

Original	BM-M3227A5030,
Part No	BM-M3227A020A
Suit	VS465
Code	VM3227



### AKAI CAPSTAN MOTOR

Original	BM-373098
Part No	
Suit	VS35
Code	VM3730



### AKAI MOTOR

Original	BM733648JI
Part No	
Suit	VS66, VS53
Code	VM3648




### AKAI CAPSTAN MOTOR

BM419269N3
Suit
Code

### BM42850N3

Suit	VSG445,858,
Code	VM2850




### AKAI DRUM MOTOR

Original	74680RB0004A,
Part No	743K000205-65
Suit	VSG280, 480, 485. VSJ200, 416, VSJ700, 716.
Code	VM0004




### AKAI CAPSTAN MOTOR

Original	4680RA0002A,
Part No	B, 4680RA0003A
Suit	VSJ200, 215, 411, VSJ416, 700, 711, 716. GVC003A, VHRVK210, VN204, AC250, 450, 950, AF293, 493, 993
Code	VM0002




### AKAI DRUM MOTOR

Original	BM419324N2,
Part No	BM419324N4, SDV-0302A
Suit	VSG705
Code	VM9324



### AKAI LOADING MOTOR

Original	BM433593N1
Part No	
Suit	VSG280, VSG2DPL VSG765, 790, 875.
Code	VM3593






# Video Repair Parts

## Daewoo

### DAEWOO CAPSTAN MOTOR


FITS TEMPEST, TRACTON, ESC, VIDEO-PRO

Original Part No	97S8102300, Sony BHF-3108C
Suit	TE970R, VCR32
Code	VM8025




### DAEWOO DRUM MOTOR

Original Part No	97SA398910, Sony U-14C
Suit	DVR6158D, TE99R...
Code	VM8910




### DAEWOO CAPSTAN MOTOR

Original Part No	97S8102400, Sony BHF-3108B
Suit	DVR6158D, TE99R, etc.
Code	VM2400



### DAEWOO TEMPEST LOADING MOTOR


Original Part No	97S8102000
Suit	DVR6158, VCR32, 52, VCR8025, TE970R, 99R...
Code	VM0244



### DAEWOO DRUM MOTOR

FITS TEMPEST, TRACTON, ESC, VIDEO-PRO

Original Part No	97SA393010, Sony U-10A
Suit	TE970R, VCR32, VCR8025
Code	VM3010



## Goldstar / LG

### GOLDSTAR LG

OEM Mechanism  
Old: was an NVG mech  
New: used as mech for other brands like Mitsubishi and more recently Akai...

SEE LG GOLDSTAR

MORE MODELS

AVAILABLE SEE:


<http://www.wes.com.au/>



## Funai / Teac / Palsonic


### FUNAI TEAC PALSONIC CAPSTAN MOTOR

Original Part No	62D60030360
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	VM0360



### FUNAI TEAC PALSONIC LOADING MOTOR

Original Part No	62D806511301
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	VM6158



## Hitachi


### HITACHI CAPSTAN MOTOR

Original Part No	5571471, 5571458
Suit	VT518, etc.
Code	VM1458




### HITACHI CAPSTAN MOTOR

Original Part No	5578764
Suit	VT100,120, VT125,128, VT130,135, VT138,etc.
Code	VM5579



### HITACHI CAPSTAN MOTOR

Original Part No	5578014 5577352
Suit	VT11,17, VT33,38, VT39,etc.
Code	VM5579



### HITACHI CAPSTAN MOTOR

Original Part No	GP10123, GP10112
Suit	VTM428, VTM448
Code	VM10112





## HITACHI CAPSTAN MOTOR

Original 5571743  
Part No  
Suit VTM728, etc.  
Code VM1743




## HITACHI CAPSTAN MOTOR

Original 5571475  
Part No  
Suit VTM598E,  
VTM838E  
Code VM1475



## HITACHI MOTOR & MODE SW

Original 7794932  
Part No  
Suit VTM575E  
Code MEC4932



### JVC


#### JVC

A primary OEM  
for older VCR




## JVC LOADING MOTOR

Original PU48854M  
Part No  
Suit HR7200, 7650, D120, D  
121, HRD125, 140, 150,  
157, 160, 220, 225, 250,  
725, N830, 831, 832, 833  
, RV340, 350, 360, 370, V  
CR1500, & AKAI, etc.  
Code VM2115



## JVC LOADING MOTOR


Original PQ41996A, PQ41996B,  
Part No PU60437  
Suit HRD230, 320,  
HRD370, 430.  
Code VM4199



## JVC DRUM MOTOR


PU46414P, PU44619  
HR3300, 3330, 36  
60, HV1000, 2000,  
RV300, Also AKAI,  
HITACHI, NORMENDE  
& TELEFUNKEN and  
some early SHARPs.

Code  
VM2120




## JVC MOTOR

Original PU55371V  
Part No  
Suit HRD110, 111, HRD120  
, 121, 225, GE8100, 930  
0, N830, 831, 833, RV36  
0, 310, etc.  
Code VM5371



## JVC CAPSTAN MOTOR

Original PU58635V  
Part No  
Suit HR-D160, 170, 171,  
180, 210, 211, 217,  
227, 230, 310, 320,  
321, 370, 430, 470,  
500, etc.  
Code VM5863




## JVC CAPSTAN MOTOR

Original PU57647V  
Part No  
Suit HRD152, 157, 158,  
HRD565, 546, etc.  
MV800, VR2925,  
2930, 2970  
Code VM5764




## JVC MOTOR

Original PQ40244A-2  
Part No  
Suit HRD140 etc.  
Code VM0244




## JVC REEL MOTOR

Original PU58636W  
Part No  
Suit HRD170, HRD180,  
HRD200, HRD530  
And more  
Code VM5864




## JVC CAPSTAN MOTOR

Original PU60201V  
Part No  
Suit HRD300, HRD337,  
HRD530, HRS5000E  
And more  
Code VM6020



## JVC/PHILIPS CAPSTAN MOTOR

**PU61285**  
Suit HRD-X20, 22,  
VR3241, 3245.  
Code VM6128



## PU60892-1-5


Suit HRD520, 600, etc.  
Code VM6089



# Video Repair Parts

## JVC CAPSTAN

Suit	HRD540,910
Code	PU61003




## BELT PULLEY ONLY

Original	PTU96031-678C
Part No	
Code	PTU96031

## JVC LOADING MOTOR

Original	PQ43676B-5
Part No	
Suit	HRJ200, HRJ400
Code	VM6282




## JVC CAPSTAN MOTOR

Suit	HRJ220, 221,HRJ625, etc.
Code	PU61435-1-6




## JVC / PHILIPS DRUM MOTOR STATOR

Original	JVC PDZ0141-1-2, Philips 482236210274
Part No	
Suit	HRJ220, 221, 425, HRJ435, 625, 635, Philips VR255-75, 357-75 VR555-75, 656-75
Code	PDZ0141



## JVC / PHILIPS DRUM MOTOR STATOR #1

IC	JCM5039 (30 pin)
Original	PDZ0141-2-2, PDZ0181-1-2
Part No	
Suit	HRJ255, 455, HRJ655, 155, Plus many more!



## JVC/PHILIPS DRUM MOTOR STATOR #2

Original	QAR0021, 4822- 249-10296
Part No	
Suit	VR288, 388.
Code	VM0181




## JVC/PHILIPS CAPSTAN MOTORS

Original	Suit	Code
QAR0032- 003/5	HRJ255, 455, 655, 755.	VM2003
QAR0018- 006	VR288, 399, 588, 988.	VM1094




## JVC LOADING MOTOR

Original	PQ43676B-5
Part No	
Suit	HRJ200, HRJ400
Code	VM6282



## JVC LOADING MOTOR

Original	PU60628-3-2, QAR0023-001
Part No	
Suit	HRJ255, 455, HRJ655, 755.




## JVC CAPSTAN MOTOR

Original	PU61487-2-5
Part No	
Suit	HRJ435, 635, HRS9400, ...
Code	PU61487



## JVC MECHANISMS WITH MOTOR


Some JVC Motors are available only bundled with their gear assemblies. Please refer to the Idler / Misc listing in this section.



## LG / Goldstar

### LG GOLDSTAR LOADING MOTOR

Original	414-051A
Part No	



Also some Mitsubishi

### LG GOLDSTAR LOADING MOTOR / BRACKET

Original	4811R0011A
Part No	
Suit	AF293, 493, 993, AC250, 450, 950.
Code	VM0011





## LG GOLDSTAR CAPSTAN MOTOR

Original Part No	414-102A
Suit	GHV1290, 1291, GHV1296, 1910,etc.
Code	VM4102




## LG GOLDSTAR CAPSTAN MOTOR

Original Part No	414-108A
Suit	VCP100, 101, VCP105, 106,
Code	VM4141




## LG GOLDSTAR MITSUBISHI CAPSTAN MOTOR

Original Part No	414-029A
Suit	AV61 GHV1232 GHV1240,etc.
Code	VM4144



## LG GOLDSTAR CAPSTAN MOTOR (A)

Original Part No	414-120A, GVC017A, CXA8005
Suit	RA211X
Code	VM4121



## LG GOLDSTAR CAPSTAN MOTOR (B)


Original Part No	414-120B
Suit	RG20, RA20, RA21.
Code	VM4120

Version "B" Differs from "A"



## LG GOLDSTAR MITSUBISHI DRUM MOTOR


Original Part No	414-081A
Suit	AV63,64
Code	VM4108



## Mitsubishi


### MITSUBISHI SUPPLY REEL MOTOR

Original	288P028060 or 288P028A60
Suit	HS303, 304, 320, HS330, 700, etc. AV11, 21, 29, 31, AVT10, 20, 30, TR101, 201...
Code	VM8060




### MITSUBISHI/AWA REEL MOTOR

Original	288PO46010
Part No	
Suit	AV11, 21, HS30, 330,
Code	VM6010




### MITSUBISHI/AWA LOADING

Original	288P06701
Part No	
Suit	AV49, 58, 63, AV337, 411, HS337, 411, HSE10-70, and more....
Code	VM0244



### MITSUBISHI LOADING MOTOR

Suit	Many brands and models.
Code	VM6158



### MITSUBISHI PULLEY

The plastic one is broken, replace it with this brass one.  
Requires glue, (14-36)

Original	631D581010
Part No	
Suit	HSMX Series.
Code	PLY101



### MITSUBISHI CAPSTAN MOTOR

Original	288P08904
Part No	
Suit	HSE17, 27, HSE52, 82.
Code	VM8904



### MITSUBISHI CAPSTAN MOTOR

Original	288P11701
Part No	
Suit	HSM34, HSM380V, HSMX2, 18, HSMX38
Code	VM1701





# Video Repair Parts

## □ NEC


### NEC CAPSTAN MOTOR

Original Part No	VM2700
Suit	VN20, DVR2700, DVR4773
Code	VM2700



### NEC CAPSTAN MOTOR

Original Part No	61308788-54, 079-V1-5015, 192-9197-006
Suit	DVR4773, VHR120, 1309, VN30, 32.
Code	VM5015




## □ National

### NATIONAL/MITSUBISHI


#### GENERAL PURPOSE LOADING MOTOR

Original Part No	288P04401
Suit	Many brands and models.
Code	VM6158



### LOADING MOTOR

Original Part No	VEM0218</br>&nbsp;NV250
Suit	NV250 NV280 NV450 NV470 NV870
Code	VM218




### NATIONAL REEL MOTOR

Includes sleeve.

Original Part No	KFN56FB8A
Suit	NV777,788
Code	VM568


#### Rubber Sleeve only

Code	Cost
VIT400	\$0.95




### NATIONAL LOADING MOTOR

Original Part No	VEM0242
Suit	NV-G7 & others.
Code	VM0242



## NATIONAL LOADING MOTOR


Original Part No	VEM0211
Suit	NV250, 280, 450, 730, 770, 870, etc.
Code	VM0211



Suit also GOLDSTAR


## NATIONAL REEL MOTOR

Original Part No	VEM0212
Suit	NV730,770
Code	VM0212



## NATIONAL CAPSTAN MOTOR


Original Part No	MAX13V9LP
Suit	NV600 etc.
Code	VM1390



## □ Panasonic

### PANASONIC STATOR

Suit	NVG20, etc.
Code	VEK2944




### PANASONIC STATOR

Suit	NV-L20,L25,NV-J1, J35,& More...
Code	VEK4105




### PANASONIC CAPSTAN STATOR

Suit	NVSD10, NVSD20, NVSD30
Code	VEK5927




### PANASONIC LOADING MOTOR

Suit	NVSD10,ETC.
Equiv.	VEM0427
Code	VM0427



### BUSH PULLEY / WORM


Code	VDP1434
	VDG0866






## PANASONIC CAPSTAN BEARING

Suit NVSD10,etc.  
Code VXD0140



## PANASONIC CAPSTAN MOTOR

Original VEK8024,  
Part No VEK8239  
Suit NVSD220, 270,  
NVSD420,  
NVHD620, 670.  
Code VM8024



## PANASONIC LOAD MOTOR UNIT

Motor & Mechanism.

Suit NV-SD220,  
NV-SD270  
Code VEM0604



### □ Philips

#### PHILIPS


Early models  
See Sharp & JVC  
Later models  
See Teac Funai



### □ Samsung


#### SAMSUNG TEMPEST CAPSTAN MOTOR

Original 90002201303,  
Part No 47690520124,  
R432274361  
Suit VB520, 900, Akai  
VS200, TE90H  
Code VM0900



#### SAMSUNG CAPSTAN MOTOR

Original 64769-053-330,  
Part No 64769-052-020  
Suit PB970, 971,  
PB972, TE90H.  
Code VM3330



## SAMSUNG TEMPEST CAPSTAN MOTOR


Original 64769052094,  
Part No 64769052095  
Suit PB980, 981,  
PB982, TE77R.  
Code VM2094



## SAMSUNG TEMPEST DRUM MOTOR

The motor only from  
above assembly

Original 64769052066  
Part No  
Suit PB980, 981,  
PB982, TE77R.  
Code VM1215



## SAMSUNG CAPSTAN MOTOR

Original 66829-0024-02,  
66829-0027-02  
Part No  
Suit PB30R, 31R,  
VB30R, 31R,  
VB300, 370,  
VB3260.  
Code VM2402




## SAMSUNG CAPSTAN MOTOR

Original 647 6905 2236,  
647 6905 2253  
Part No  
Suit VB1230,1260,  
VB1560,1580,  
and more...  
Code VM2253



## SAMSUNG CAPSTAN MOTOR


Original 66823-0059-00  
Part No  
Suit SV10, 11, 12,  
SV30, 80, 140  
Code VM5900



## SAMSUNG LOADING MOTOR

Includes Gears, Motor, etc.

Original 67179-0068-00  
Part No  
Code MEC6800






# Video Repair Parts

## Sanyo


### SANYO MOTOR

Original 613-017-0699  
 Part No VTC6500  
 Suit VM2215




### SANYO REEL MOTOR

Original 4-527V-10800  
 Part No RM11  
 Suit VTC5000,  
 VTC5005,  
 VTC5300,  
 VTC5400  
 Code VM2210




### SANYO LOADING MOTOR

Original 613-021-9527,  
 613-121-9960,  
 3-942-091-01  
 Suit SRT500P,  
 TLS900P, 924P,  
 TLS2000,  
 TLSS2500P  
 Code VM9527



### SANYO CAPSTAN MOTOR

Original 613-089-9156  
 Part No TLS1000  
 Suit VM9156



### SANYO CAPSTAN MOTOR

Original 613-130-9425  
 Part No SRT500P,  
 TLS900P,  
 TLS924P,  
 TLS2000,  
 TLSS2500P  
 Code VM9425



### SANYO CAPSTAN MOTOR

Original 645-008-1880  
 Part No VHR310, 590  
 Suit VM1880




## SANYO CAPSTAN MOTOR

Original 645-008-1897  
 Part No VHR510, 530,  
 VHR610, 630  
 Suit VM5008



## SANYO CAPSTAN STATOR


Original 613 085 7279, 613  
 Part No 132 3520  
 Suit VHR310, 420, etc.  
 Code VM3520



## Sharp

### SHARP LOADING MOTOR

Original RMOTM1049GEZZ  
 Part No VCA10X,30,103,  
 105,505,etc...  
 Suit VM1049




### SHARP CAPSTAN MOTOR

Original RMOTN2051GEZZ  
 Part No VCA62X, VCA63X  
 Suit VM2051




### SHARP CAPSTAN MOTOR

Original RMOTP 1029 GEZZ  
 Part No VC381, VC383,  
 VC9100, VC9300  
 Suit VM2127




### SHARP MOTOR

Original RMOTM1017GEZZ  
 Part No VC300 series. and  
 more....  
 Suit VM0244



### SHARP CAPSTAN MOTOR

Includes pulley.  
 Original RMOTP1026GEZZ  
 Part No VC3300 and others.  
 Suit VM1026






## SHARP CAPSTAN MOTOR

Original Part No RMOTP1059GEZZ

Suit MV740, VC100,488,  
VC581,582,583,  
VC584,585,5F3,  
VR6441,6541,6940

Code VM1059




## SHARP REEL MOTOR

Original Part No RMOTV 1010 GEZZ

Suit VC481,581,  
6441,6641,etc.

Code VM1010



## BRASS PULLEY

Original Part No NPLYV0121GEZZ


Code MP121

## SHARP CAPSTAN MOTOR

Original Part No RMOTP1079GEZZ

Suit VC600, VC700 series

Code VM1079




## SHARP CAPSTAN MOTOR

Original Part No RMOTP1066GEZZ

Suit VC400 series

Code VM1066



## SHARP DRUM MOTOR

Original Part No RMOTP1077GEZZ

Suit VC581,2,3, VC6826V3  
and others.

Code VM1077



## SHARP DRUM MOTOR

Original Part No RMOTP1092GEZZ,  
RMOTP1084GEZZ

Suit VCA101, 103, VCA502,  
VCD801, VR6443, etc.

Code VM1092




## SHARP DRUM MOTOR

To suit MANY VCA,  
VCD & VCH series.  
Philips VR6349.

Original Part No RMOTP1096GEZZ


Code VM1096



## SHARP CAPSTAN MOTOR

Original Part No RMOTN2001GEZZ,  
RMOTN2003GEZZ


Suit VC772,781,782,785,78  
6,787,793,VCA101,etc.  
Code VM2001



## SHARP CAPSTAN MOTOR

Original Part No RMOTN2012GEZZ  
,RMOTN2022GEZZ

Suit VCA101x  
Code VM2012




## SHARP CAPSTAN MOTOR

Original Part No RMOTN2020GEZZ

Suit VCA101X etc.


Code VM2020



## SHARP CAPSTAN MOTOR

Original Part No RMOTN2055GEZZ


Suit VCA220, 270, VCA420,  
470.  
Code VM2055



## SHARP DRUM MOTOR

Original Part No RMOTP1139GEZZ,  
RMOTP1141GEZZ

Suit VCA220, 270, VCA420,  
470.  
Code VM1139



## SHARP LOADING MOTOR

Original Part No RMOTM1078GEZZ

Suit VCA220, 270,VCA420,  
470.  
Code VM1078



## SHARP CAPSTAN MOTOR

Original Part No RMOTN2067GEZZ

Suit VCA240, 290,VCA490.  
Code VM2067






# Video Repair Parts

## SHARP LOADING MOTOR

Original Part No	RMOTM 1029 GEZZ, RMOTM 1034 GEZZ
Suit	Many models eg. VCA500 series
Code	VM6158




USED IN MANY BRANDS, DAEWOO,  
DEITRON, TEMPEST,...

## SHARP REEL MOTOR

Original Part No	RMOTV1007GEZZ
Suit	ORION
Code	VM2122


## BRASS PULLEY

Original Part No	NPLYV0121GEZZ
Code	MP121




## SHARP DRUM MOTOR

Original Part No	RMOTP1102GEZZ, RMOTP1107GEZZ
Suit	VCA10X etc.
Code	VM1107




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2010GEZZ
Suit	VCA103X etc.
Code	VM2010



## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2019GEZZ
Suit	VCA105X, VC103X, VC505X etc.
Code	VM2019



## SHARP CAPSTAN MOTOR

Original Part No	RMOTN-2028-GEZZ
Suit	VCA10,30,35,45, VCA60,615,H80, VR3260,3360, VR6349,6449, VR6549, etc..
Code	VM2028




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN-2038, 2047, 2048-GEZZ
Suit	14VT10X1, VCA33,34,38,39, VCA48,49,63,64, VCH83,84,85,87, VR3261, VF22,etc.
Code	VM2038



## SHARP REEL MOTOR

Original Part No	RMOTV 1008 GEZZ, RMOTV 1004 GEZZ
Suit	ORION
Code	VM2121



## BRASS PULLEY

Original Part No	NPLYV0121GEZZ
Code	MP121


## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2052GEZZ
Suit	VCA36X, VCA50X and others.
Code	VM2051




## SHARP DRUM MOTOR

Original Part No	RMOTP1116GEZZ
Suit	VCA36,37,41,50, VCA53,62,63,67,72, VCA93,94,97,98, and more...
Code	VM1116



## SHARP LOADING MOTOR

Original Part No	RMOTM 1062 GEZZ
Suit	VCA36,37,41,50,53, VCA53,62,63,67,72, VCH93,94,97,98, VCMH83, 93, VT3428, 5128
Code	VM1062




## SHARP VIDEO MOTOR

Original Part No	RMOTN2053GEZZ
Suit	Many Models
Code	VM2053



## SHARP CAPSTAN PULLEY

The plastic one is broken, replace it with this brass one.  
Requires glue, (14-31)  
Suit VCA Series.  
Code PLY101



## SHARP DRUM MOTOR

Original Part No	RMOTP-1151-GEZZ
Suit	VCH680, VCH900
Code	VM1151





## Sony


### SONY

Very early VHS models were made by Sanyo.




### SONY CAPSTAN MOTOR

Original	8-835-382-01/03
Part No	
Suit	SLVX50,etc..
Code	VM8203



### SONY CAPSTAN MOTOR

Original	3-740-369-02
Part No	
Suit	SLVX20
Code	VM6902




### SONY CAPSTAN MOTOR

Original	F2QKB38 394702801,
Part No	62D60030354,
Suit	KV21VM3MT
Code	VM9500




### SONY CAPSTAN MOTOR

Original	8-835-489-01/11
Part No	
Suit	SLVX810
Code	VM8911




### SONY CAPSTAN MOTOR

Original	8-835-394-11, 8-835-
Part No	394-01
Suit	SLVX55, SLV777
Code	VM9411




### SONY CAPSTAN MOTOR

Original	1-698-409-14, 1-698-
Part No	409-11
Suit	SLVX812, SLVX822
Code	VM9140



### SONY LOADING MOTOR


Original	X-3943-883-1
Part No	
Suit	SLVX812, SLVX822
Code	VM8831



### SONY CAPSTAN BEARING

Suit Above Motors.

Original	X-2625-356-2
Part No	
Suit	SLVX757, 777, SLVX810, 815, etc...
Code	BR3562



### SONY LOADING MOTOR

Original	X-3727-784-1 RF- 270RH
Part No	
Suit	SLVBS511, SLVF10, 11, SLVP33, SLVX810
Code	VM7841



### SONY CAPSTAN MOTOR

Original	169897111, 169897114
Part No	
Suit	SL-VEZ1, 10, 11, SL-VEZ22, 44, 66, SL-VEZ7, 70, 77.
Code	VM7111



### SONY LOADING MOTOR CAM

Original	X39475771
Part No	
Suit	SL-VEZ1, 10, SL- VEZ7, 70. SL-VKH1, 10, SL-VKH7, 70.
Code	VM5771



### SONY CAM MOTOR

Original	X37333021
Part No	
Suit	SL-VX810 SL-VX811
Code	VM3021



## Teac / Philips

### TEAC/PHILIPS CAPSTAN MOTOR

Original	4822-311-10805
Part No	
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	VM8050






# Video Repair Parts

## □ Video Belts

## □ Cross Reference



### VIDEO BELT KIT SUBSTITUTION LIST

The following list has been compiled from information received from our customers and is offered as possible suggestions for usage. Please advise us if you find any errors or additions.

*Thank you.*

**PLEASE NOTE THE PRICES  
OF THE KITS ARE ON THE  
PREVIOUS PAGE**

Suit	Code
------	------

#### AKAI

VP77	VBK74
VS1,2,5	VBK3
VS3,4,6,8	VBK55
VS10	VBK4
VS11,12	VBK97
VS15	VBK55
VS22,26,35	VBK91
VS53,55,75	VBK91
VS112,115	VBK71
VS155,165	VBK71
VS200	VBK93
VS240,515	VBK71
VS7100	VBK40
VS7300	VBK1
VS9300,9500	VBK34
VS9700	VBK2
VS9800	VBK34
VSP3	VBK81

#### AIWA

HV-G900BPG	VBK87
------------	-------

#### AMSTRAD

DD9904	VBK129
UF22	VBK120
VCR6000	VBK87

#### AWA/THORN

2H20D, 4H40D	VBK123
AV1,ATV1	VBK37
AV12,14	VBK76
AV47,49	VBK111
AV51,52	VBK76
AV58,59	VBK111
AV61	VBK80
AV62	VBK100
AV337	VBK111
AV400,410,	VBK76
AV411,412,421	VBK111
TR102	VBK76

#### BLAUPUNKT


RTC250,256,350	VBK131
RTV222	VBK. 8
RTV301	VBK49
RTV311,434	VBK50
RTV321	VBK48
RTV322	VBK43
RTV328	VBK52
RTV350,356,456	VBK131
RTV424,444	VBK46
RTV716,725,785	VBK131
RTX200	VBK11

#### CASIO

VX2000	VBK88
--------	-------

#### COMPUTAR

CTR3024	VBK118
---------	--------



<http://www.wes.com.au/>

Suit	Code	Suit	Code
<b>DEITRON</b>		<b>GOLDSTAR</b>	
DVR6158D	VBK103	GHV1232,1240,1246	VBK80
		GHV1296	VBK102
		VCP100,105,110,	VBK119
		VCP120,126,	VBK119
		VCP4100	VBK80
<b>DISTAR</b>		<b>GENERAL</b>	
DS757	VBK97	VG220A	VBK32
		VGX510	VBK99
		VGX540	VBK109
		VGX625,645	VBK109
		VGX715,720	VBK110
		VGX815,820A	VBK87
<b>E.S.C.</b>		<b>JVC</b>	
VCR8025	VBK85	CP5000E	VBK75
		CR6000E,6060E	VBK75
		HR2200	VBK74
		HR2650	VBK45
		HR3300,3600	VBK53
		HR3330	VBK. 7
		HR3360,3660	VBK54
		HR4100	VBK20
		HR7200	VBK45
		HR7650,7655	VBK36
		HR7600	VBK36
		HR7700	VBK. 4
		HR-D110,111	VBK64
		HR-D120,125	VBK64
		HR-D140,141,143	VBK78
		HR-D150,152,156	VBK78
		HR-D157,158,160	VBK78
		HR-D170,171,180	VBK77
		HR-D190	VBK78
		HR-D220,225	VBK64
		HR-D250,275	VBK78
		HR-D320,370,430	VBK86
		HR-D455	VBK78
		HR-D520,521,522	VBK116
		HR-D540,580	VBK124
		HR-D565,566	VBK78
		HR-D600,610,620	VBK116
		HR-D725,755	VBK78
		HR-D790	VBK125
		HR-D830	VBK116
		HR-DX20,22	VBK116
		HR-J200,400	VBK128
		HR-J220,221	VBK128
		HR-J255,455	VBK133
		HR-J600	VBK127
		HR-J625,635	VBK128
		HR-J655,755	VBK133
<b>HMV</b>		<b>KAMBROOK</b>	
HV1000	VBK41	KVP120	VBK119
HV2000	VBK53		
HV3000	VBK54		
HV4000	VBK45		
HV7000	VBK4		
HV8000	VBK36		
PP24	VBK74		
<b>GAC</b>		<b>MARANTZ</b>	
VB910	VBK81	MV740A	VBK61
		See Sharp/Philips	
<b>G.E.</b>		<b>MASUDA</b>	
6900	VBK45	M22	VBK80
64007300	VBK64		
8100	VBK64		
8900	VBK36		
9300	VBK64		
<b>GENERAL</b>		<b>MITSUBISHI</b>	
VGX930A	VBK102	(SEE ALSO AWA)	
		HS337,338	VBK111
		HS347,349	VBK111
		HSE11,21,41	VBK118
		HSM54,59	VBK118
		HSMX1,X2	VBK118
		HSMX7	VBK126
<b>NORMENDE</b>		<b>NORMENDE</b>	
VR200		VR200	VBK41



Suit	Code	Suit	Code	Suit	Code	Suit	Code
<b>NATIONAL/PANASONIC</b>							
NV-MI,M3	VBK51	PIONEER	VBK83	SANYO	VBK105	TEAC	VBK87
NV250,280	VBK50	VBH-780D	VBK83	VHR120	VBK105	MV306,307,308,330P	VBK120
NV300,333,340	VBK12			VHR1100,1300	VBK89	MV314,315	VBK120
NV370	VBK49			VHR1500	VBK89	MV3410,4810	VBK120
NV450,470	VBK50			VHR2500	VBK104	MV400,430	VBK88
NV600	VBK48			VHR2700	VBK92	MV435,440	VBK88
NV730,770	VBK52			VHR3100,3500	VBK90	MV445,450,616	VBK87
NV750	VBK47			VHR3700	VBK90	MV7,77,777	VBK131
NV777,788	VBK43			VHR4100,5100	VBK105	MV1400,1414TV	VBK88
NV850	VBK46			VHR5300,5700	VBK105	MV1480	VBK87
NV870	VBK50			VHR7100,7200	VBK105	MV2020TV	VBK88
NV2000,3000	VBK11			VHR7500,7900	VBK105		
NV7000	VBK10			VHR-D500,D700	VBK90		
NV7200,7500	VBK8			VHR-D4400,4600	VBK105		
NV8170	VBK95			VHR-D4800,4890	VBK105		
NV8400	VBK35			VHR-D5810	VBK105		
NV8600,8610,8620	VBK9			VHR-S-700	VBK106		
NV-G7,9,10,11,12	VBK79			M10,M20N,M50,NX10	VBK59		
NV-G16,30	VBK79			VTC5000,5005	VBK58		
NV-H70A	VBK79			VTC5300,5400	VBK57		
<b>THE LATER MODELS USE ONE BELT ONLY eg.</b>							
NVD48,80,				VTC5500	VBK27		
NV-G20,21,28,				VTC6500	VBK60		
NV-G33,38,45,48,				VTC9300,9500	VBK6		
NV-H65,75,NV-L25,							
FS1,90,100, RTV740,..							
Code	VDV0169						
Cost	3.05						
<b>NEC</b>							
B5	VBK13						
DS6000	VBK83						
DX1600,3000	VBK83						
N830EA,831A,833EA	VBK64						
N901,904,911,912	VBK70						
N9033,9034,9040	VBK83						
N9052,9053	VBK83						
N9063,9065,9066	VBK83						
N9073,9083,9280	VBK83						
N9401,9402	VBK83						
N9530,9570,9580	VBK83						
N9610,9680	VBK83						
PVC754E	VBK63						
VCP1	VBK83						
VCR5000	VBK64						
VH81,91	VBK105						
VN23,26,64	VBK123						
VN30,32,32	VBK105						
VN35,70,71	VBK105						
<b>ORION</b>							
Some units may have different mech's for the same model No.							
The following is a general guide							
for the most likely "VBK" to suit.							
NATIONAL MECH. TYPES eg.							
VH2A MK11	VBK11						
SHARP MECH. TYPES eg.							
VH3C, VN2B	VBK39						
ORION MECH. TYPES eg.							
2B	VBK84						
RVP-114	VBK121						
VC10P	VBK117						
VCP	VBK117						
VCRLS,VDLJ,VLBK	VBK130						
<b>PALSONIC</b>							
VCR5000	VBK99						
VCR6000	VBK88						
VCR7000	VBK100						
VCR8000	VBK102						
VCR9000	VBK87						
VCR9500	VBK122						
<b>PIONEER</b>							
VBH-780D	VBK83						
<b>PANASONIC</b>							
SEE NATIONAL							
<b>PHILIPS</b>							
VR107,110	VBK132						
VR155,255,455	VBK128						
VR210,275,299	VBK132						
VR256	VBK128						
VR257,357,357,399	VBK132						
VR401,501,502	VBK39						
VR456,656	VBK128						
VR457,499,610,620	VBK132						
VR555,655,755	VBK128						
VR601,701,901	VBK39						
VR656	VBK128						
VR757,799,810	VBK132						
VR820,857,899	VBK132						
VR856	VBK128						
VR3360	VBK102						
VR3442	VBK116						
VR6440,6540	VBK61						
VR6441	VBK62						
VR6442,6443	VBK69						
VR6448,6475	VBK102						
VR6520	VBK69						
VR6540	VBK61						
VR6542,6543	VBK69						
VR6548,6549	VBK102						
VR6743	VBK69						
VR6541,6575,6937	VBK62						
VR6640,6740,6940,6840	VBK61						
VR9489	VBK131						
<b>PRESIDENT</b>							
PV300,500	VBK117						
<b>PYE</b>							
VRS012,022	VBK39						
VRD100	VBK107						
VRD300	VBK103						
<b>RANK</b>							
RV300	VBK41						
RV310	VBK7						
RV320	VBK54						
RV330	VBK4						
RV340	VBK45						
RV350	VBK36						
RV360,370,380	VBK64						
VP100	VBK74						
<b>SAMSUNG</b>							
VB617,617C	VBK98						
VB627,629	VBK98						
VB711	VBK97						
VB711A	VBK107						
VB750	VBK107						
VB900A,910	VBK81						
VB970,971,972	VBK97						
VB2215P	VBK81						
VB8220	VBK107						
PB981R	VBK107						
<b>SONY</b>							
MHCU800	VBK134						
SLC5E	VBK14						
SLC6E	VBK28						
SLC7E, SLT7E	VBK14						
SLT9ME	VBK22						
SL5400,5600,5800	VBK31						
SL8000,8080	VBK13						
SL8500	VBK13						
SLVX10PS,20PS	VBK105						
SLVX25PS	VBK105						
SLVX37,X57	VBK122						
<b>TANDY</b>							
2B	VBK84						
<b>TEAC</b>							
VHR120	VBK105						
VHR1100,1300	VBK89						
VHR1500	VBK89						
VHR2500	VBK104						
VHR2700	VBK92						
VHR3100,3500	VBK90						
VHR4100,5100	VBK105						
VHR5300,5700	VBK105						
VHR7100,7200	VBK105						
VHR7500,7900	VBK105						
VHR-D500,D700	VBK90						
VHR-D4400,4600	VBK105						
VHR-D4800,4890	VBK105						
VHR-S-700	VBK106						
M10,M20N,M50,NX10	VBK59						
VTC5000,5005	VBK58						
VTC5300,5400	VBK57						
VTC5500	VBK27						
VTC6500	VBK60						
VTC9300,9500	VBK6						
<b>TELEFUNKEN</b>							
VR200	VBK41						
VR400	VBK54						
VR440	VBK41						
VR449	VBK54						
VR500	VBK54						
VR540	VBK4						
<b>TEMPEST</b>							
TE77R	VBK87						
TE90H	VBK97						
TE99R	VBK103						
TE900A	VBK81						
TE970	VBK85						
<b>TITAN</b>							
VCR1500	VBK45						
VCR1600	VBK64						
<b>TRACKTON</b>							
VCR-32	VBK85						
VCR-417TR	VBK87						
<b>TOSHIBA</b>							
V31,33	VBK21						
V55,57	VBK64						
V63	VBK78						
V71,73,74,75	VBK101						
V81,83,84,85	VBK101						
V93	VBK112						
V500	VBK113						
V5310T,5310C	VBK33						
V5250,5280	VBK15						
V5470,5475,7540	VBK29						
V8600,8700	VBK16					</	



# Video Repair Parts

## Belt Kits

### VIDEO BELT KITS

Code number and cost listing. Primary models listed only, due to space. For other models, see Cross-Reference Pages.

Suit	Code	Suit	Code
AKAI VS7300	VBK1	AKAI VS112, 115	VBK71
AKAI VS9700	VBK2	HITACHI VT33E	VBK72
AKAI VS2E/V5E	VBK3	HITACHI VT640, 660, 860	VBK73
AKAI VS10, JVC HR7700	VBK4	JVC 2200, AKAI VP77	VBK74
HITACHI VT5000E	VBK5	JVC CR 5000E, 6000E, 6060E	VBK75
SANYO 9300/9500	VBK6	AWA AV12, AV14	VBK76
JVC HR3330	VBK7	JVC HRD170, 370	VBK77
NATIONAL NV7200EN	VBK8	JVC HRD140 etc	VBK78
NATIONAL NV8600/NV8620	VBK9	NATIONAL NVG7, 9, 16	VBK79
NATIONAL NV7000	VBK10	GOLDSTAR VARIOUS	VBK80
NATIONAL NV2000	VBK11	AKAI/SAMSUNG/TEMPEST 900	VBK81
NATIONAL NV300/NV340	VBK12	FISHER FVH-520	VBK82
SONY SL8000/SL8080	VBK13	NEC N9530A	VBK83
SONY C5E/C7E/T7E/T9E	VBK14	ORION VH2B	VBK84
TOSHIBA V5250/V5280	VBK15	SAMSUNG and equivalents	VBK85
TOSHIBA V8600	VBK16	JVC HR-D430EA	VBK86
SHARP VC7300	VBK17	TEAC MV330P, 450, 445	VBK87
SHARP VC6300	VBK18	TEAC MV400, 430, 435 etc	VBK88
SHARP VC6000	VBK19	SANYO VHR-1300	VBK89
JVC HR4100	VBK20	SANYO VHR-3100	VBK90
TOSHIBA V31/V33	VBK21	AKAI VS22	VBK91
SONY SLT9ME	VBK22	SANYO VHR-2700	VBK92
SHARP VC2300K	VBK23	AKAI VS200	VBK93
SHARP VC387	VBK24	FISHER FVHP620, 710, 720	VBK94
SHARP VC3300	VBK25	NATIONAL NV8170	VBK95
SHARP VC220N	VBK26	FISHER FVH-P530	VBK96
SANYO VTC5500	VBK27	TEMPEST TE90H	VBK97
SONY SLC6E	VBK28	SAMSUNG VB617, etc	VBK98
TOSHIBA V5470/V7540	VBK29	PALSONIC VCR5000	VBK99
SHARP 7650	VBK30	PALSONIC VCR7000	VBK100
SONY SL5400/SL5600	VBK31	TOSHIBA V71, 73 etc	VBK101
TOSHIBA V5310C/V5310T	VBK33	SHARP VC-A105	VBK102
AKAI 9300/9500/9800	VBK34	TEMPEST TE99R	VBK103
NATIONAL NV8400	VBK35	SANYO VHR-2500	VBK104
RANK RV350, HMV8000	VBK36	SANYO VHR-4100	VBK105
AWA ATVI ATI	VBK37	SANYO VHR-S700	VBK106
SHARP 300 & 9000 SERIES	VBK39	TEMPEST TE77R, PB980R	VBK107
AKAI VS7100	VBK40	HITACHI VT138	VBK108
HMV1000-RANK RV300	VBK41	GENERAL VGX540/625/645	VBK109
HITACHI 3000	VBK42	GENERAL, FUNAI	VBK110
NATIONAL NV777	VBK43	AWA, MITSUBISHI	VBK111
HITACHI 8000/8050	VBK44	TOSHIBA V93	VBK112
JVC HR2650/HR7200	VBK45	TOSHIBA V500	VBK113
NATIONAL NV850	VBK46	HITACHI VT9500	VBK114
NATIONAL NV750	VBK47	HITACHI VT6500, 6800	VBK115
NATIONAL NV600	VBK48	JVC HRD520, 522, 600	VBK116
NATIONAL NV370	VBK49	PRESIDENT PV300, PV500	VBK117
NATIONAL NV470	VBK50	MITSUBISHI HSE11, MX1, 2	VBK118
NATIONAL NV-M1	VBK51	GOLDSTAR KAMBROOK	VBK119
NATIONAL NV730/770	VBK52	TEAC MV314, 315	VBK120
JVC HR3300	VBK53	ORION RVP-114	VBK121
JVC HR3660	VBK54	SONY SLVX37	VBK122
AKAI VS3/VS4	VBK55	NEC VN23, 26, 64 & AWA	VBK123
SHARP VC8300	VBK56	JVC HRD540 / 580	VBK124
SANYO VTC5300	VBK57	JVC HRD790	VBK125
SANYO VTC5000	VBK58	MITSUBISHI HSMX7	VBK126
SANYO M10/M20/NX10	VBK59	JVC HRJ600	VBK127
SANYO VTC6500	VBK60	JVC HRJ220, 221, 625	VBK128
SHARP VC400 SERIES	VBK61	AMSTRAD DD9904	VBK129
SHARP VC581, 582, 583 etc	VBK62	ORION VCRLS, VDLJ, VLBK	VBK130
NEC PVC754E	VBK63	PHILIPS VR9489-39	VBK131
JVC HR-D110/D120/D225	VBK64	PHILIPS VR155 TO VR755	VBK132
HITACHI VT8500	VBK65	JVC LP30005-003, -005	VBK133
HITACHI VT 9300	VBK66	SONY MHCU-800	VBK134
HITACHI VT7E, VT8E	VBK67	10 KITS ASSORTED LESS 10%	
HITACHI VT19E/20E/63E/88	VBK68	50 KITS ASSORTED LESS 20%	
SHARP 600 & 700 SERIES	VBK69	100 KITS ASSORTED LESS 25%	
NEC 901A, 911A	VBK70		

MORE MODELS AVAILABLE SEE:

<http://www.wes.com.au/>

MOST VCR USE ONLY ONE BELT?...  
If only one belt! See following pages.





## □ Video Belts & Idler Tyres

### AKAI

Original Part No	Suit	Size	Code
VS12,3,4,5,8		77x1.8mm	BLT7800
MB387289J	VS12,F10		BLT3872
MB364011	VS112,115, VS165,etc.		BLT4011
MB420053N	VSG mech.		BLT4200
BM433627N	VSG Mech	72x2x2mm	BLT3627

### JVC

Original Part No	Suit	Equiv.	Code
HRD170,180,370,400, HRD530, HRS5000, 5500.		PQM30003-19	
HRD160,200,230, HRD400,530, S5000, etc.		PQM30003-20	
PU48941-2	HR7200,etc.	PU50350	BLT4894
	HR-D540, 580.		PU61006

### NEC/DAEWOO

#### CAPSTAN BELT

Original	79TD 3675
Part No	
Suit	NEC VN23, VN26, AWA 2H20D,4H40D, and others.
Code	BLT3675

#### LOADING BELT

Original	97S5500100, 79TD4460
Part No	
Suit	VN23,26, AWA 2H20D,4H40D,
Code	BLT4460

#### LOADING BELT

Original	16629251
Part No	
Suit	N901,904,911,etc
Code	BLT9251

#### REEL BELT

Original	97S5501800
Part No	
Suit	VN20
Code	BLT1800

#### REEL BELT

Original	97S 550 2300, 79TD
Part No	3940
Suit	VN22, VN25, NEC, AWA, and others.
Code	BLT3940

#### REEL BELT

Original	97S 550 0400
Part No	
Suit	D284G, D884G, DVK10W, 224D, DVK424D, 824D4, MV3080, 6080.
Code	BLT5500

### PANASONIC/NATIONAL


Code	
VDV0074	
VDV0122	
VDV0135	
VDV0138	
VDV0148	
VDV0149	
VDV0151	
VDV0152	
VDV0153	
VDV0169	
VDV0235	
VDV0382	



### PANASONIC GEAR KIT

Kit combines VXP0767 VDV0159 and washers.

Code	VXP0917K
------	----------



### SAMSUNG




Original Part No	Suit	Code
65274-	VB1230, etc. PB991,	VDV0149
603-210	etc. VX & VR,...	
65274-	VB300, 306, 320, 336	BLT4603
603-910		
61794-	SV10, 11, 12, 30, 0009-00	BLT6009
	80, 140	



### SHARP

#### MAIN BELT

Original Part No	NBLTK0067AJ00	Suit	VCA220, 270, 420, 470
Code	BLT0067		



#### CAMCORDER BELT

Original Part No	NBLTK0054GEOO
Code	BLT0054



#### REEL BELT

Original Part No	VCA36,37,41,50,53,62,
Code	BLT0065

Original Part No	VCA67,93,94,97,98,...
------------------	-----------------------



### SONY

#### SYNCHRO BELT

Original Part No	Suit	Code
3-679-119-11	SLC30,32,33, SLC34,35,40.	BLT1911
3-977-510-01	SLVKH7,9	BLT1001




#### TOOTHED BELT

Original Part No	Suit	Code
3-736-013-01	SLV215,353,757, SLVX30,35,50, SLVX810,etc.	BLT1301
3-958-361-01	SLVX812, 822.	BLT6101

### TEAC PALSONIC

Original Part No	62D80650920
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	69X2






# Video Repair Parts

## □ Idler Tires

### VIDEO TYRES & BELTS

Part numbers quoted are original manufacturers' part numbers for the complete assembly. Tires only are supplied. When ordering please quote our VIT number only or you may receive the whole assembly! Many units are identical internally so you may find these tires will substitute with other part numbers, other brands, etc.



### AKAI TYRES

Original Part No	Code
BV321761 TYRE	VIT12
BV321762 TYRE	VIT16
BV321979 TYRE	VIT20
BV327815L T/UP IDLER	VIT24
BV327815S T/UP IDLER.	VIT28
MI327773 FF/REW IDLER	VIT32
PU42164 TYRE	VIT34
PU42165-2 T/UP IDLER	VIT35
BL-B353110 TYRE	VIT455
PU44917 TYRE	VIT36
PU44918-2 REW IDLER	VIT40
PU46381 UNLOAD ASS	VIT44
PU48907A T/UP DISK	VIT48
PU48907B SUPPLY DISK	VIT52
PU48967A REEL IDLER	VIT56
MZ364046J1 TYRE	VIT60
65153600011 IDLER TYRE	VIT90

### HITACHI TYRES

Original Part No	Code
6866971 TYRE	VIT80
6412654 TYRE	VIT84
6413114 TYRE	VIT88
6413144 TYRE	VIT92
6413202 TYRE	VIT96
6413633 TYRE	VIT100
6414221 TYRE	VIT104
6861471 TYRE	VIT108
6861482 TYRE	VIT112
6861505 TYRE	VIT116
6875386 TYRE	VIT120
6875371 TYRE	VIT124

### JVC TYRES

Original Part No	Code
PU44918 T/UP DISK	VIT200
PU44918-4 F/F IDLER	VIT204
PU48811D, PU48806 IDLER.	VIT206
PU48907C T/UP DISK	VIT208
PU48907D SUPPLY DISK	VIT212
PU48907E T/U DISK	VIT214
PU48967B REEL IDLER	VIT216
PU49281 REWIND IDLER	VIT220
PU49283 PLAY IDLER.	VIT224
PU51402A T/UP IDLER	VIT228
PU55373 T/UP CLUTCH.	VIT232
PU55374-3-8 REEL TYRE	VIT236
PU58645-1-4 TYRE	VIT240

### MITSUBISHI

Original Part No	Code
521D097010 REEL	BLT9701
521D96010 LOAD.	BLT9601

### NEC

Original Part No	Code
16172931 IDLER	VIT450
16178173 25.5x30.5x3.5	VIT454
16178173 26.5x33x3.5	VIT455

### PANASONIC TYRES

Original Part No	Code
VXA1491 FF/REW IDLER	VIT280
VXP0242 REWIND IDLER	VIT300
VXP0243, VXP0599 IDLER	VIT304
VXP0245 F/F IDLER	VIT308
VXP0292 REWIND IDLER	VIT312
VXP0329 FF/REW IDLER	VIT316
VXP0331 PLAY IDLER.	VIT320
VXP0343 PLAY IDLER.	VIT324
VXP0344 FF/REW IDLER	VIT328
VXP0401 FF/REW IDLER	VIT332
VXP0433 PLAY IDLER.	VIT336
VXP0463 FF/REW IDLER	VIT340
VXP0488 PLAY IDLER.	VIT344
VXP0515 FF/REW IDLER	VIT348
VXP0521 IDLER 24X30X3	VIT352
VXP0521 IDLER 23X30X3	VIT353
VXP0581 FF/REW IDLER	VIT356
VXL0404 IDLER UNIT	VIT380
VXL-0997 MOTOR TYRE	VIT390
MOTOR SLV NV730,777,788	VIT400

### SANYO TYRES

Original Part No	Code
143-0-551T-01400 REW IDLR	VIT500
143-0-547T-00200 FF IDLR	VIT502
143-0-551T-01600 REW IDLR	VIT504
143-0-661T-03800 LOAD RLR	VIT508
143-0-662T 01201 REEL DR Also known as 143-0-741T-20001	VIT512
143-0-741T-11101 FWD RLR	VIT516
143-0-4104-0010 TYRE	VIT520
143-0-4104-0020 TYRE	VIT530

### SHARP TYRES

Original Part No	Code
NDAIV1007GEZZ SPINDLE	VIT604
NIDL0005GEZZ IDLER	VIT608
NIDL0006GEZZ IDLER.	VIT612
MLEVF0027GEZZ F/F IDLER	VIT614
NIDR-0004GEZZ REW IDLER	VIT616
NBLTK0054GEOO Camcorder	BLT0054
NPLYV0014GEZZ IDLER BLOCK	VIT620
NPLYV0041GEZZ PULLEY	VIT624
NPLYV0051GEZZ PULLEY	VIT628
NPLYV0107GEZZ PULLEY and NPLYV0111GEZZ PULLEY	VIT632

### SONY

Original Part No	Code
X-3653-310-0	VIT700
X-3653-315-0	VIT704
X-3659-324-0	VIT708
X-3671-053-0	VIT712
X-3671-015-0	VIT716
A-6706-348B	VIT720

### SAMSUNG-TEMPEST

Original Part No	Code
65153600011/100 IDLER	VIT90
5253-701-1105 IDLER	VIT750

### TOSHIBA

Original Part No	Code
70316057	VIT804
70353048 PAUSE LEVER TYRE	VIT808

### AWA-THORN

Original Part No	Code
641B10101/2 IDLER	VIT65
522P002101 IDLER	VIT70



## Pinch Rollers

### Akai

#### AKAI PINCH ROLLERS FROM VS SERIES


The original pinch roller used in some VS series Akai VCR's was a one piece type. The roller only for this assembly is VPR67. The one piece assembly has been upgraded and if a complete assembly is ordered then a new TWO piece type (VPR150) will be supplied. The roller only for VPR150 is a VPR69. We recommend using VPR150 for reliable service.



OLD TYPE


#### AKAI ROLLER ASSEMBLY

Original	BL-387501J1
Part No	BL-V1075A180D
Equiv.	VS22,26,35,55,66,75,7 7,VS422,425,465,725, VSA650,VSF10,11, 220,221,400,410,V SF422,425,430,600
Suit	VPR150
Code	VPR150



#### AKAI PINCH ROLLER


Original	BL433609N3, N4
Part No	VSG280, VSG2DPL,
Suit	VSG765, VSG790, VSG875.
Code	VPR156



## Daewoo

### DAEWOO

Original	97SB381800, 79TD3701
Part No	
Suit	VN22,25, NEC, AWA, etc
Code	VPR185



### DAEWOO


Original	97SA310700
Part No	
Suit	D284G, etc.,
Code	VPR187



## Funai / Teac

### FUNAI/TEAC


Original	8059-06-301
Part No	
Suit	VCR417 & More...
Code	VPR180



## Goldstar / LG / NEC


### GOLDSTAR

Original	333-209
Part No	
Code	VPR170



### GOLDSTAR / NEC PINCH ROLLER

Original	340-070A, 340-073A, 340-195A, 386-401A, 4930-0138A, NEC 79VG1020
Part No	
Suit	W903H, VN36, P23H, etc.
Code	VPR171



### GOLDSTAR LG PINCH ROLLER


Original	4261R0011A
Part No	
Suit	AC250, 450, 950, AF293, 493, 993, Akai VSJ200, 215, 411, VSJ416, 700, 711, VSJ716, etc...
Code	VPR230



## Hitachi

### HITACHI PINCH ROLLER

Original	6975768, 6384352
Part No	
Suit	VTM598E, VTM838E
Code	VPR220





# Video Repair Parts

## □ JVC / Philips

### JVC


Original Part No	PQ43558
Suit	HRD520, 640, 830, HRDS5000, HRDX20EA, Philips VR3241, VR3275
Code	VPR143

Lifter to suit  
PQ32415 \$1.59



### JVC

Original Part No	PQ42006B
Suit	HRD170,etc. HRD200,210, HRS5000,HRS5500, HRS9000
Code	VPR141




### JVC PINCH ROLLER

Original Part No	PQ45921E, PQ45921A6
Suit	HRJ600
Code	VPR139




### JVC

Original Part No	PQ40134B
Suit	HRD110,120, HRD121,225, NEC N531,830,833 GR8100, 9300, and others.
Code	VPR140




### JVC PINCH ROLLER ARM

Original Part No	JVC PQ46327A-2 Philips 482252811051
Suit	HRJ425, 435, HRJ625, etc. Philips VR656-75, VR555-75
Code	VPR142



### JVC / PHILIPS PINCH ROLLER

Original Part No	LP40105-001A/B 4822-402- 11057
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	VPR165




## □ Mitsubishi

### MITSUBISHI

Orig. 948D20010 or 789C007020  
Suit HSE11,12,21,

#### ORIGINAL

Code	VPR160
------	--------



### MITSUBISHI PINCH ROLLER


Original Part No	948D044001
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	VPR175



## □ NEC

### NEC


Suit	VN26,26 NEC 79TD3683 97SA300600
Code	VPR186



## □ National

### NATIONAL NV-M


Original Part No	VXL1674 VXL1772
Suit	NV-MC10 NV-MC30, MS50
Code	VPR118 VPR136



### NATIONAL

VXL1858 or VXL1743  
NV-G20,21,22,25,  
NV-G28,40,45,...  
NV-D38,D48, NV-  
H65,H75, RTV740,  
etc...

Code	VPR120
------	--------



### NATIONAL

Original Part No	VXP0330
Suit	NV2000, 3000, Series
Code	VPR130






## Panasonic

### PANASONIC

Original NVSD Mech.  
Part No VXL2246




### PANASONIC PINCH ROLLER

Original VXL2676, VXL2785  
Part No

Suit NVSD220, 270, 420,  
NVHD620, 670.  
Code VXL2676

### Roller Only

Code  
VPR123




## Sharp

### SHARP

Original MLEVFO281GEZZ  
Part No


Suit VCA10,30,35,60,105,  
111,115,125,505,etc...  
Code VPR134



### SHARP

Original MLEVFO416GEZZ  
Part No

Suit VCA36X,37X,50X  
Code VPR416



## Philips / Teac

### PHILIPS TEAC PINCH ROLLER - UPDATE

Original 4822 528 70774, 8619

Part No 119 175

Suit MV7, 77, 777, RTV785,  
VR9489,  
Code VPR274



(Differs to original by roller shaft diameter)

### ROLLER ONLY - 2 TYPES 2.5mm & 3mm

#### 3.0mm BEARING SHAFT

ROLLERS ONLY  
Fits the new VPR274

Code  
VPR125

#### 2.5mm BEARING SHAFT

Roller only. Suit original.

Code  
VPR124

VPR274 (Above) will replace assemblies in ALL units!




## Sony

### SONY PINCH ROLLER

A-6759-344-A, X-3669-  
307-1, X-3670-063-1,  
X-3679-264-1, X-3691-  
646-1

Suit SLC9, 34, 40, etc.  
Code VPR195



## Samsung


### SAMSUNG

Original 61523002101

Part No

Suit VB300, VB370, etc.

Code VPR190




X3749-173-4, X3749-770-1

SLV215,353

Suit SLV757,777,  
SLVX30,X50,  
SLVX810,etc.

Code VPR200



## Sanyo


### SANYO PINCH ROLLER

Original 613-151-8803

Part No

Suit VHR510,530,  
VHR590,610,  
VHR630,650.

Code VPR205






# Video Repair Parts

## □ Video Pinch Roller Listing

### VIDEO PINCH ROLLERS AND ASSEMBLIES

Please note that the substitution listing is to be used as a guide only. There are many more models which are not listed. Please measure the roller required and choose from the dimensions listed.


Suit	Amm x Bmm x Cmm	Code
ORION VC-RLS, VL-BF, UD-LS	15 X 18 X 4	VPR35
GOLDSTAR 434-037D GHV SERIES.	18 X 17 X 4	VPR40
SONY ALL LATE MODEL VHS SLVX30,35,50,etc. Sharp VCA, VCH, etc.. ROLLER ONLY FROM VPR134 Philips VR6448, 6449, 6548, 6591,etc... Goldstar RG20, AWA AV66,etc... * Please Note! Similar outer dimensions to VPR121 *D = 7.7mm	14 X 18 X 3 X *	VPR50
SONY SLVX37, KV14VMIAS	17 X 19 X 4	VPR52
SONY SL-C5, C7, J7, T7, T9, 8000, 8080	16 X 19 X 3	VPR55
AKAI-VS10,9300, 9500, 9800, AKAI VP77, * HMV VP77 JVC-HR2200, 3300, 3330, 3660, RANK VP100 PALSONIC VCR5000, 6000	15 X 21 X 4	VPR56
NATIONAL NV250, 280, 370, 430, 450, 460, 470, 730, 770, 830, 850, 870, 2000, 3000, 7000, 7200, 8400, 8600, 8610, 8620 NV-G7, 9, 10, 11, 16, 30, ORION VH-1, 2, 2B PHILIPS VR6920, GENERAL VGX540A, 625A	18 X 23 X 3	VPR57
SANYO VTC5000, 5005, 5300, 5400, 5500, 6000, 6500, 9100, 9300, 9350, M10, M20, M30, M50 and others.	15 X 19 X 4	VPR58
NROLR0005GEZZ SUITS EARLY MODEL SHARP VC6000, 6300, 7000, 8000, 9000, ALL 300 SERIES plus VC2300, 3300 ORION VH3 AKAI VS11, 12, TEMPEST TE77R, TE90H, DISTAR DS757, PHILIPS VR401, 501, 502, 701, 901 AKAI VS11, PYE VRD100L SAMSUNG VB750, VB970, 971, VB8220 PLUS OTHERS. THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST.	18 X 20 X 4	VPR59
HITACHI-VT7, 11, 14, 17, 33, 35, 88E, 4000, 4200, 5000, 6500, 6800, 7000, 8500, 9300, 9500, 9700, and FISHER FVH-P520, 530 and others.	15.5 X 22 X 4	VPR60
AKAI- VS9700	16.5 X 20 X 4	VPR61
AKAI- VS1, 2, 3, 4, 5, 6, 8, 15 and others.	13 X 18 X 3	VPR64
AKAI- VS112, 155, 165, 240, 515	18 X 20 X 3	VPR66
AKAI- VS33, 35, 53, 55, 66, 422, 425, 426, 427, 725, VSF10, 11, 220, 400, 410, 422, 425, 430, 600 * NOTE. THIS SUITS THE ONE PIECE TYPE ASSEMBLY. * SEE DETAILS ON THE NEXT PAGES FOR "AKAI PINCH ROLLERS"	18 X 18 X 3	VPR67
AKAI VS202, 303, 606, 607 VSP8	16 X 20 X 3	VPR68
AKAI VS22, 35, 53, 66, 422, 425, 725 VSA77, VSF10, 11, 400, 410, 422, 425, 430, 600 * NOTE. THIS SUITS THE 2 PIECE TYPE ASSEMBLY.	18 X 18 X 3	VPR69
NEC ALL 900 & MANY 9000 SERIES, DX1600, DX3000, Original P/No. 016-17-8363, PALSONIC VCR9688, TEAC MV3010, 30, 50, MV4010, 6010.	16 X 19 X 4	VPR70
NEC DS6000A, N9073, N9570	15 X 17 X 4	VPR71
TEAC/FUNAI MV305, 307, 330, 400, 417, 430, 435, 440, 445, 450, MV1440TV, MV220TV GENERAL VGX815A PLUS EQUIVALENTS eg. CASIO, TANDY etc.	15 X 19 X 4	VPR72
MITSUBISHI AV SERIES AV12, 14, 47, 51, 58, 59, 400, 410, HS SERIES HS30, 304, 306, 307, 310, 318, 319, 337, HS338, 347, 349, 400, 410, 411, 412, SOME HSE SERIES HS-E10, 20, 70, 347 THORN TR102	15 X 18 X 4	VPR75



**TOO  
MANY  
MODELS  
TO  
LIST  
HERE!**

**IF YOUR  
VCR  
IS NOT  
LISTED,**

**PLEASE  
ENQUIRE!**




**MORE SUBSTITUTES  
AVAILABLE SEE:**

<http://www.wes.com.au/>



## VIDEO PINCH ROLLERS AND ASSEMBLIES


Suit	Amm x Bmm x Cmm	Code
MITSUBISHI HSE11, 12, 21, 27, 31, 41,.. Also HSM and HSMX Series. SAMSUNG SV10, 11, 12, 30, 80, 81, 140	14 X 17 X 3	VPR76
HITACHI VT100, 128, 135, 138, 168, FISHER FVH-P905, 908, 910, 911,etc.	15.5 X 19 X 4	VPR78
FISHER FVH-P620, 710, 720, 725	15.5 X 21 X 4	VPR80
NATIONAL- NV100, 600, 300, 333, 777, 788, and BLAUPUNKT equivalents.	16 X 23 X 3	VPR87
JVC HR2650, 7200, 7600, 7610, 7655, 7650, 7700 GE-V9600 * HMV4000, 7000 RANK RV330, 340, 350 * T/FUNKEN VR530	17 X 21 X 4	VPR90
HRD170, 180, 200, 210, 230, 300, 320, 330, 337, HRD370, 377, 400, 430, 470, 530, 700, 750, 950, HRS5000, 5500, 9000,etc..	17 X 17 X 4	VPR104
JVC HR-D110, 111, 120, 121, 125, 140, 150, 160, 225, 250, 455, 565, 566, 755, NEC ALL 800 SERIES N830, 833, 895 ETC TOSHIBA V55, 57, 71, 73, 75, 81, 83, 84, 85, 86 GENERAL GE8100, 9300 THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST	17 X 18 X 4	VPR105
JVC HR-D230, D520, D521, D530, D540, D580, D600, D610, D620, HR-D830, HR-DX20EA, HR-S5800, & PHILIPS VR3241/75	16 X 17 X 4	VPR106
Philips VR2020, 2022, 2023, 2021, 2024	12.5 X 20.5 X 3	VPR107
SHARP all VC400 & 500 series eg. VC481, 581 etc. AKAI VS200 & VSP3, DEITRON DVR6158, ESC VCR8025, Philips VR6440, 6441, 6540, 6541, 6640, 6641, 6740 etc. Tempest TE99, TE900, TE970R, Trackton VCR32, VCR52, Orion VCP Samsung VB617C, 627, 629, 900, 910 etc. Marantz MV740A Goldstar GHV1232, 1240, 1246, 1291, 1295, 1296, etc Videopro VCR8025 THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST.	18 X 17 X 4	VPR108
NEC VN22, 23, 25, 26 97SB361200 DAEWOO DVR4773 70322134 2H20D 4H40D TOSHIBA V31, 33, 51, 53, 8600, 8650, 9600, VP88	15 X 17.5 X 3	VPR110
SHARP P/No. ROLR0013GEZZ Suit VC-6V3, VC600, 682, 685, 693 SHARP 700 SERIES VCA101, 103, VCH851, etc. PHILIPS 6442, 6443, 6520, 6542, 6543, 6549 etc. THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST	18 X 18 X 4	VPR113
SANYO 6130372161 VHR1300, 1500, 2500, 2700	16 X 23 X 3	VPR115
SANYO VHR3100, 3300, 3700, VHR-D500, D700	16 X 18 X 3	VPR116
SANYO VHR120, 4100, 5100, 5200, 5300, 5700, 7100, 7200, 7500 VHR-D4600, D4800, S700, VN-20, 31, 32, 70, 71, NEC VH81, 90, 91.	15.5 X 18 X 3	VPR117
ROLLER ONLY FROM VPR120, VXL1743 & VXL2676 Panasonic NVG series NVG20,21,22,25,40 AND MANY OTHERS. Panasonic NVJ, NVL, NVF, NVD series. SHARP LATE VCA SERIES BLAUPUNKT RTV560,740, etc... TEAC/FUNAI MV3410,4810 *	14 X 18.5 X 3 X *	VPR121
Please Note! Similar outer dimensions to VPR50 and VPR123 *D = 8.3mm		
ROLLER FROM VXL2785 (NOT VXL2676 - Check "C") Panasonic NVHD620A, 670A, NVSD220A, 270A, 420A. GOLDSTAR AF293, 493, 993, AC250, 450, 950. AKAI VSJ200, 215, 411, 416, 700, 711, 716. SANYO VHR-VK210, NEC VN204 * Please Note! Similar outer dimensions to VPR50 and VPR121	14 X 18.5 X 2.5	VPR123
NEW! - PHILIPS BLAUPUNKT TEAC, etc,	12.5 X 17 X 2.5	VPR124



**TOO  
MANY  
MODELS  
TO  
LIST  
HERE!**

**IF YOUR  
VCR  
IS NOT  
LISTED,**

**PLEASE  
ENQUIRE!**



**MORE SUBSTITUTES  
AVAILABLE SEE:  
<http://www.wes.com.au/>**



# Video Repair Parts


## Overhaul Kits

## JVC OEM

### OVERHAUL KITS

The following kits are manufactured by the original corporations in Japan and contain all the parts which they recommend to be replaced when the VCR is being serviced.


Please note that many brands use the following kits. We have listed as many models as we are aware of and/or space would allow.



Typical VHS VCR Tape Transport Components

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D120, HR-D225, NEC N830, 831, N833, GE GEV-7300, GEV-8100, GEV-9300, RANK RV360, RV370, 380.
Code	PTU96075



PQM3003	BELT(D=46mm)
PQM3003-7	BELT(D=116mm)
PQM3003-8	BELT(D=28mm)
PQM3004	BELT(D=27mm)
PQM30017-5	SLIT WASHER X2
PQM30017-8	SLIT WASHER X2
PQ40134B	PINCH ROLLER
PU48907D	REEL DISK ASS.
PU48907E	REEL DISK
PU51390A	TENSION BAND
PU51402A	T'UP IDLER ARM
PU55373	T'UP CLUTCH
PU55374-3-8	IDLER ARM

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D455, HR-D725, TOSHIBA V63
Code	PTU96078-2



PQM30003-10	BELT(D=55mm)
PQM30003-14	BELT(D=30mm)
PQM30017-12	SLIT WASHER X2
PQM30017-8	SLIT WASHER
PQ40252B-4	P'ROLLER & ARM
PQ40262E	TENSION BAND
PU55822A-10	CASSETTE MECH.
PQM30001-138	TENSION SPRING
PQM30019-14	PAD

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D160, 171, HR-D180, HR-D211, 230, HR-D300, 320, HR-D321, 337, HR-D470, 530, HR-D750, HR-S5000 HR-S5500
Code	PTU96079



PQM30003-20	BELT(D=19mm)
PQM30017-28	SLIT WASHER
PQM30017-5	SLIT WASHER X2
PQ41948A	TENSION BAND
PQ42006B	P'ROLLER & ARM
PU58645-1-4	IDLER ARM

### ORIGINAL JVC OVERHAUL KIT

Suit	HR-D540, HR-D580
Code	PTU96082




PQM30003-23	BELT(D=64mm)
PQM30017-12	SLIT WASHER
PQM30017-8	SLIT WASHER
PQ43501B-11	TENSION BAND
PQ43921B-2	P'ROLLER & ARM
PU61004-1-3	IDLER GEAR UNIT
PU61005-1-4	CLUTCH UNIT
PU61006	TIMING BELT



## ORIGINAL JVC OVERHAUL KIT


Suit	HR-D520, HR-D521, HR-D600, HR-D610, HR-D620, HR-D830
Code	PTU96083



PQM30003-23	BELT(D=64mm)
PQM30003-24	BELT(D=93mm)
PQM30017-12	SLIT WASHER
PQM30017-8	SLIT WASHER
PQ43501B-11	TENSION BAND
PQ43558A	P'ROLLER & ARM
PU60618-1-3	IDLER GEAR UNIT
PU60953-1-2	CLUTCH UNIT

## ORIGINAL JVC OVERHAUL KIT


Suit	HR-7200 & Equiv. GE GEV6900, HMV HV4000, RANK RV340
Code	PTU96095



PQM30003	BELT(D=45mm)
PQM30003-2	BELT(D=64mm)
PU48941-2	BELT(D=29mm)
PU49164	BELT(D=88mm)
PQM30017-5	SLIT WASHER X2
PQM30017-6	SLIT WASHER X2
PU48907C	REEL DISK
PU48907D	REEL DISK
PU48967B	IDLER ASSEMBLY
PU51367A	PINCH ROLLER
PU51390A	TENSION BAND
PU51402A	TAKE UP IDLER
PU53462A	TAKE UP CLUTCH

## ORIGINAL JVC OVERHAUL KIT

Suit	HR-7600, HR-7650, HR-7655, GE GEV8900, HMV HV8000, RANK RV350
Code	PTU96097-2




PQM30003	BELT(D=46mm)
PU48941-2	BELT(D=29mm)
PU49164	BELT(D=88mm)
PQM30017-5	SLIT WASHER X2
PQM30017-6	SLIT WASHER X2
PU48907D	REEL DISK
PU48907E	REEL DISK
PU48967B	IDLER ASSEMBLY
PU51367A	PINCH ROLLER
PU51390A	TENSION BAND
PU51402A	TAKE UP IDLER
PU53462A	TAKE UP CLUTCH

## □ National Panasonic OEM

### PANASONIC "G" MECHANISM PARTS KIT


Contains VXL1490, VXL1743, VXP0878, VDG0597, VML1849, VMX1079, washers and C rings. As the G mech is very popular this kit will suit many models eg. NV-G20, 21, 22, 33, 40, NV-D38, 48, FS1, H65, 75 etc, + RTV740, 560, etc.

Code	VUA4104
------	---------



### PANASONIC "G" MECH VIDEO MAINTENANCE PARTS KIT

Suit	NVD38, 48, NVF55, 65, 66, 70, 75, 77, NVG33, 220, 300, NVJ1, 10, 11, 30, 35, 45, NVL10, 15, 20, P10, etc.
Code	VUA4116KIT



VDG0574	Main Cam Gear
VDG0343	Sub Cam Gear
VDG0348	Centre Gear
VDG0547	Clutch Gear
VXP0917	Pulley Unit
VDG0448	Loading Gear
VXP0878	Gear Unit
VML1861	Detent Arm
VDG0342	Ring Gear
VDV0169	Timing Belt
VXL1861	Play Arm
VDG0564	Load Gear T
VDG0419	Load Gear




# Video Repair Parts

## JVC Replacement

### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. Suit JVC HR3330, HR3600, 3360, HR3660 and eq's. Contains; PU47752 Take up clutch, PU46381 Unloading idler Belts, tyres, Pinch roller


Code  
VUD1101



### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. JVC HR7200 7650, 2650 etc Contains; Idler assemblies PU51402A PU48967B, Take up clutch PU53462A belt kit Tyres pinch roller



Code  
VUD1102



### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. JVC HRD-110, 120, etc. NEC N830, 831, 833 Contains; PU55373 Take up clutch, PU55374-3-8 PU51402A Idler arms Belts and Pinch roller.


Code  
VUD1103



## ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV730, 770... Contains; VXP0581 Idler, VDG0177 Gear, VDP0908 Roller, VXZ0165 Tension band Belts, roller Circlips, etc.


Code  
VUD4091



## ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV250, NV280, 470, 870... Contains; VXP0521 Idler, VDP0908 Roller, VXZ0165 Belts Pinch roller Circlips and Washers.


Code  
VUD4093



## ECONOMY OVERHAUL KIT - NATIONAL

NATIONAL NV300, NV333, 340... Contains; VXP0434 Idler, VXP0401 Idler, VDP0908 Roller, VXZ0129 Tension band Belts & p'roller Circlips, washers.

Code  
VUD4099





## National Panasonic Replacement

### ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV2000 Contains; VXZ0076 Tension band, VDP0908 Roller, VXP0329 Idler, VXP0331 Idler, VXPO351 Clutch, VXP0332 Brake belts, pinch roller Circlips & Washers


Code  
VUD4087



## ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV370, NV850... Contains; VXP0521 Idler, VDP0908 Roller, VXZ0165 Belt All belts, Pinch roller, Circlips and Washers.

Code  
VUD4092



## ECONOMY OVERHAUL KIT - NATIONAL


Original & Non-original parts. NATIONAL NV-G7→18 NVG30/H70/65... Contains; VXP0521 Idler, VXL1371 Roller ass'y, VXZ0165 Tension band Belts Washers and Circlips

Code  
VUD4103

### ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV7000, 7200... Contains; VXP0343 Idler, VXP0344 Idler, VDP0908 Roller, VXZ0078 Tension band belts, roller Circlips, and washers.

Code  
VUD4088






## □ Idlers & Gears

### □ Akai

#### AKAI IDLER ASSEMBLY

Original MI327773  
Part No  
Suit VS2,3,4, 5,6,8,15.  
Code VIA32




#### AKAI IDLER

Original MI361964  
Part No  
Suit VS606  
Code VIA38




#### AKAI EJECT CAM GEAR

Original MZ-360428  
Part No  
Suit VS105, 112, VS115,116  
Mech. "A"  
Code MZ360428



#### AKAI CAM GEAR

Suit VS112,165. Mech. "A"  
Code MZ360429



#### AKAI CAM GEAR No.1

From cassette housing VS303  
Code  
MZ353166



#### AKAI IDLER

Original MI361964  
Part No  
Equiv. BL-B35110  
Suit VS202,303  
Code VIA25




#### AKAI IDLER ASSEMBLY

Original BV-327815  
Part No  
Suit VS2,3,4, VS5,6,8,15.  
Code VIA35




#### AKAI IDLER ASSEMBLY

Original MZ366960  
Part No  
Suit VS105,112, 115,116,  
155,165, 240,515,X9...  
Code VIA50




#### AKAI EJECT CAM

Original MZ364677 Also  
Part No MZ367952  
Suit VS112 Mech. "B"  
Code GR3679



#### AKAI CAM GEAR


Suit VS112,165. Mech. "B"  
Code MZ364676



#### AKAI CAM GEAR No.4


From cassette housing VS303

Code  
MZ353169




#### AKAI CLUTCH GEAR

Original ML373043  
Part No  
Suit VS25,35, VS53,55  
Code ML3730




#### AKAI GEAR ASSEMBLY

Original MI387294J  
Part No  
Code GR3872



#### AKAI GEAR

Suit VS22,26,35 etc.  
Code MZ368795T1





# Video Repair Parts


## AKAI GEAR

Original	MZ-368794T
Part No	VS35,53,55
Suit	MZ368794
Code	




## AKAI GEAR CAM JOINT

Original	MZ368797T
Part No	VS22
Suit	GR3687
Code	




## AKAI LOADING ARM

Original	MZ-V1075A090A
Part No	VS35,etc.
Suit	GR5090
Code	




## AKAI LOADING GEAR

Original	VT780025
Part No	VS1,2,3,4 VS5,6,8
Suit	GR7800
Code	




## AKAI LEVER ROLLER LINK

Original	BL-B353126
Part No	VS202,VS303
Suit	BL3531
Code	



## AKAI EJECT LEVER

Original	ML749693
Part No	
Suit	VS6,8,15,etc.
Code	ML749




## SPRING TO SUIT

Code	ZG749
------	-------




## AKAI LOADING ARM

Original	ML-368792T
Part No	
Suit	VS35,53,55
Code	ML368792




## AKAI LOADING ARM

Original	ML-368793T
Part No	
Suit	VS35,53,55
Code	ML368793



## AKAI ARM SHUTTER

Cassette lid opening	
Code	ML387349




## AKAI LOADING ARM

Original	MZ-V1075A100A
Part No	VS35,etc.
Suit	GR5100
Code	




## AKAI GEAR

Suit	VSF12 etc.
Code	MZ387333J



## AKAI LOADING GEAR

Use with	GR7800
Original	VT780026
Part No	
Code	GR7802




## AKAI ARM OPENER

Original	ML-353161
Part No	
Suit	VS202,VS303
Code	ML3531



## AKAI ARM


Suit	VS422, VS425
Code	ML387321






## AKAI TAKE-UP TAPE GUIDE

Original Part No	MS-372186J1
Suit	A/C head block. VS35, 53, 55
Code	MS372186



## AKAI CLUTCH DISC

Original Part No	MZ387298J3
Suit	VS965 VSF30, 300, VSF261, 441, VSF510, 600, VSG10, 43, 50.
Code	MZ387298




## AKAI \*

**VS422,425,465,765,965, VSA650,F10,F11,F12,F30,F600**

Avoid repairs bouncing because of cassette jamming. Fit/check/replace the following when servicing any of the above models.


**Mod:** Insert MZ732818 to support the Front loading slider and stop it from jumping the Front loading gear



## \*AKAI SPACER OUTSERT

Modification part. Mount under "Hook" part.

Code	MZ732818
------	----------



## \*AKAI AIR DAMPENER

Check spring retainer (Hook) Replace if worn.


Original Part No	ML391745J3
Code	ML3917



## \*AKAI SHAFT GEAR EJECT


Machined brass Replace if shaft broken.

Code	MS732791
------	----------




## AKAI SLIDE LEVER

Original Part No	ML420168N2
Suit	VSF440, VSG204, 216, VSG246, 305, VSG315, 317, VSG415, 445.
Code	LEV0168




## AKAI GEAR

Original Part No	MZ420123N
Suit	VSG204, 211, VSG405, 511, VSG740, 855, VSG2200, etc.
Code	GR4201




## AKAI LOADING ARM

Original Part No	MZ424917N00
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4917




## AKAI LOADING ARM

Original Part No	MZV1102A090A
Suit	VSG10,11,30, 33,34,35,40, 43,44,45,50, 54, etc.
Code	GR2090




## AKAI LOADING ARM

Original Part No	MZV1102A100A
Suit	VSG10,11,30, 33,34,35,40, 43,44,45,50, 54, etc.
Code	GR2100




## AKAI CASSETTE LOADING ARM

Original Part No	BL424913N06
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	ARM4913




## AKAI GEAR

Original Part No	MI420023N4
Suit	VSG204, 311, VSG405, 511, VSG740, 855, VSG2200, etc.
Code	GIA4203



## AKAI CAM GEAR

Original Part No	MZ420345J
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4245






# Video Repair Parts

## AKAI PINCH GEAR

Original Part No	MZ420067N
Suit	VSG204,...212, VSG405, 740, VSG2100, etc.
Code	GR4267




## AKAI CAM GEAR

Original Part No	MZ420064N
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4264




## AKAI MAIN CAM GEAR

Original Part No	MZ420122N1
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	MCG4222



## AKAI CAM GEAR

Original Part No	MZ428103N
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4203




## AKAI CAM GEAR

Original Part No	MZ428104N, MZ420328N
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4204




## AKAI FRONT LOADING GEAR

Original Part No	MZ420124N3
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4224




## AKAI REDUCTION GEAR

Original Part No	MZ420348J
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	GR4248




## AKAI LEVER M BRAKE

Suit	VSDG411 VSG204,211, VSG311,405, VSG858,etc.
Code	LEV4299




## AKAI ARM LOADING BLOCK END

Original Part No	Arm BL433561N7, End BL438155C
Suit	VSG260, 262, 265, VSG460, 465, VSG765, 875, VSP170, etc.
Code	BL438155C



## AKAI SLIDE LOADING PLATE

Original Part No	ML433567N1
Suit	VSG260, 262, 265, VSG460, 465, VSG765, 875, VSP170, etc.
Code	ML433567



## AKAI DISK REEL

Suit	VSG2, 260, 261, 262, VSG263, 265, 267, 270, VSG271, 275, 276, 277, VSG2DPL, PLEAD, 460, VSG465, 467, 470, 475, VSG477, 768, 875, VSP170.
Code	MT433537N



### □ Akai - See Goldstar LG

## AKAI - SEE GOLDSTAR - LG

Suit VSJ200, 215,  
VSJ411, 416,  
VSJ700, 711,  
VSJ716, etc.

LG Electronics


See Goldstar  
AF293, 493,  
AC250, 450.



### □ Daewoo / NEC / AWA / Tempest


## DAEWOO / NEC / AWA IDLER PLATE

Original Part No	97SB382300
Suit	VN22, 25, & more...
Code	VIA3955



## DAEWOO / NEC / AWA CAM GEAR


Original Part No	97S2714900, 79SB3928
Suit	VN22, VN25, NEC, AWA, & More.
Code	MCG3928






## DAEWOO / NEC / AWA GEAR TAKE-UP

Original Part No	97SB382410, 79TD3956
Suit	VN22, VN25, NEC, AWA, & More.
Code	GIA3956



## DAEWOO / NEC / AWA GEAR RELAY


Original Part No	79TD3665, 97SB0900700
Suit	VN23,24,26,27,67, 2H20D, 4H40D, DVR4773
Code	GR9366



## DAEWOO / TEMPEST CAM GEAR

97S2705600  
Deitron DVR6158D,  
Tempest TE99R, 970R,  
ESC VCR32, VCR8025.

Code  
GR5600




## DAEWOO / TEMPEST IDLER CLUTCH

Original Part No	97SA387600
Suit	Tempest TE970 VIDEO PRO VCR8025 Trackton VCR32 etc.
Code	VIA110



## DAEWOO / TEMPEST IDLER CLUTCH

Original Part No	97SA507200
Suit	Tempest TE970 VIDEO PRO VCR8025 Trackton VCR32 etc.
Code	VIA100



## DAEWOO IDLER ASSEMBLY

Deitron DVR6158D,  
Tempest TE99R  
Code  
VIA102




## DAEWOO SPRING

Original Part No	97S3019200
Suit	DVR4773 VN20, etc.
Code	DAE9200




## DAEWOO RATCHET

Original Part No	97S2904900
Suit	DVR4773, VN20, etc.
Code	DAE4900




## DAEWOO IDLER GEAR SET

Original Part No	79TD4348,
Suit	97SB335500
Code	VN20, DVR4773, etc...




## DAEWOO / TEMPEST RF CONVERTER

Six pins	
Original Part No	MCB9VA0103
Suit	DVR6158, 6358, VCR32, 52, 8025, TE99R, etc.
Size	44x53x18mm
Code	RFVR0103




## DAEWOO IDLER

Original Part No	79TD3689,
Suit	97SA301200
Code	VN23, 26, 64, NEC, AWA, & others.




## DAEWOO IDLER PLATE

Original Part No	97SA301400,
Suit	79TD3690
Code	VN23, VN26, NEC, AWA, and others.




## DAEWOO MASTER CAM GEAR

Original Part No	79TD3663
Suit	NEC VN23, VN26, AWA 2H20D, 4H40D
Code	MCG3663



## DAEWOO RELAY GEAR

Original Part No	79TD3664
Suit	NEC VN23, VN26, AWA 2H20D, 4H40D
Code	GR3664






# Video Repair Parts

## DAEWOO / NEC / AWA SLIDE PLATE

Original Part No	97S0900200
Suit	2H20D, 4H40D, VN23, 24, VN26, 27 VN64.
Code	PSM9002




## DAEWOO CLEANER ROLLER

Original Part No	79V15058
Suit	VN30, VN35
Code	RL5058



## DAEWOO CAM GEAR

Original Part No	97SA2701400
Suit	D284G, D884G, DVK10W, 224D, DVK424D, 824D4, MV3080, 6080.
Code	CAM1400



## DAEWOO LEVER

Original Part No	97S0901400
Suit	D284G, D884G, DVK10W, 224D, DVK424D, 824D4, MV3080, 6080.
Code	LEV1400



## DAEWOO CLEANER

Original Part No	97S2701800
Suit	D284G, D884G, DVK10W, 224D, DVK424D, 824D4, MV3080, 6080.
Code	LEV1500



## Funai / Teac / Palsonic

### FUNAI HOOK TRIGGER

Original Part No	8059-10-14
Code	FU1014




### FUNAI LEVER TRIGGER

Original Part No	8059-10-13
Code	FU1013



### FUNAI PLATE BRAKE

Original Part No	8059-10-11
Code	FU1011




### FUNAI ACTUATE BASE

Original Part No	8059-10-09
Code	FU1009




## FUNAI ARM RG ACTUATE

Original Part No	8059-17-01
Code	FU1701



## FUNAI CLUTCH ASSEMBLY

Original Part No	8059-09-302
Code	FU9302




## FUNAI GEAR ASSEMBLY, P

Original Part No	8059-09-305
Code	FU9305




## FUNAI WORM WHEEL ASSEMBLY

Original Part No	8000-22-313
Code	FU2313



## FUNAI EJECT ACTUATE ARM

Original Part No	8059-11-14
Code	FU1114



## FUNAI GUIDE POST

Original Part No	8059-03-04
Code	FU304



## FUNAI GUIDE POST


Original Part No	8059-03-05
Code	FU305






## FUNAI GEAR

Original 8059-09-06  
Part No  
Code FU906




## FUNAI GEAR

Original 8059-09-306  
Part No  
Code FU9306




## FUNAI BEARING ASSEMBLY

Original 8059-11-302  
Part No  
Code FU1302




## FUNAI LOADING PULLEY

Original 8059-11-03  
Part No  
Code FU1103




## FUNAI WHEEL ASSEMBLY WORM

Original 8059-16-321  
Part No  
Code FU6321




## FUNAI FRONT LOAD GEAR

Original 8059-16-319  
Part No  
Code FU6319




## FUNAI LOADING GEAR LEFT

Original 8059-03-06  
Part No  
Code FU306



## FUNAI LOADING GEAR RIGHT

Original 8059-03-07  
Part No  
Code FU307




## FUNAI LOADING GEAR

Original 8059-11-04  
Part No  
Code FU1104




## FUNAI CAM ASSEMBLY

Original 8059-11-303  
Part No  
Code FU1303



## FUNAI BRAKE RUBBER DAMPER

Original 8059-02-23  
Part No  
Suit GENERAL, TEAC etc.  
Code FU223



## FUNAI TEAC PALSONIC IDLER & PLATE

Original 62D806509303  
Part No  
Suit MV3010, 3030, 3050,  
MV4010, 6010, Palsonic  
VCR9688  
Code GR9303




## FUNAI TEAC PALSONIC MAIN GEAR

Original 62D80651104  
Part No  
Suit MV3010, 3030, 3050,  
MV4010, 6010, Palsonic  
VCR9688  
Code GR1104



## FUNAI TEAC PALSONIC GEAR CASE

Original 62D806515301  
Part No  
Suit MV3010, 3030, 3050,  
MV4010, 6010, Palsonic  
VCR9688  
Code GR5153






# Video Repair Parts

## FUNAI TEAC PALSONIC CLUTCH

Original Part No	62D06509302
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	VIA9302




## FUNAI TEAC PALSONIC CAM GEAR

Original Part No	62D806511302
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	MCG1302



## FUNAI TEAC PALSONIC LOAD SUPPLY

Original Part No	62D806303305
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	ARM3033




## FUNAI TEAC PALSONIC LOAD TAKE-UP

Original Part No	62D806503305	OVSA-05503
Suit	MV3010, 3030, 3050, 4010, 6010, Palsonic VCR9688	MV3410, 4810.
Code	ARM5033	ARM5503




## FUNAI TEAC PALSONIC MAIN BRAKE T/U

Original Part No	62D806510301
Suit	MV3010, 3030, MV3050, 4010, MV6010, 6010G, VCR9688, etc.
Code	MBA0301



## FUNAI TEAC PALSONIC MAIN BRAKE SUPPLY

Original Part No	62D806510302
Suit	MV3010, 3030, MV3050, 4010, MV6010, 6010G, VCR9688, etc.
Code	MBA0302




## FUNAI TEAC IDLER ASSEMBLY

Original Part No	OVSA-06334
Suit	MV3410 MV4810T
Code	VIA6334




## FUNAI TEAC LOADING ARM SUPPLY

Original Part No	OVSA-04215
Suit	MV3410 MV4810T
Code	ARM4215




## FUNAI TEAC IDLER

Original Part No	OVSA08820
Suit	MV3420,MV4820.
Code	VIA8820



## FUNAI TEAC IDLER CLUTCH

Original Part No	OVSA08859
Suit	MV3420,MV4820.
Code	VIA8859




## FUNAI TEAC LOAD ARM SUPPLY

Original Part No	OVSA08818
Suit	MV3420, 4820.
Code	ARM8818



## FUNAI TEAC LOAD ARM T/U


Original Part No	OVSA08858
Suit	MV3420, 4820.
Code	ARM8858



□ LG / Goldstar / NEC / Teac


## LG GOLDSTAR COMPLETE ASSEMBLY

Original Part No	321-149B
Code	VIA1149



## LG GOLDSTAR IDLER ONLY


Original Part No	386-075A
Code	VIA6075






## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-149B  
Part No  
Code VIA1149




## LG GOLDSTAR IDLER ONLY

Original 386-075A  
Part No  
Code VIA6075




## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-256A  
Part No  
Code VIA1256




## LG GOLDSTAR IDLER ONLY

Original 386-139A  
Part No  
Code VIA6139




## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-218A  
Part No  
Code GR1218




## LG GOLDSTAR IDLER ONLY

Original 431-021A  
Part No  
Code VIA1021




## LG GOLDSTAR CLUTCH

Original 432036A  
Part No  
Code GR2036




## LG GOLDSTAR GEAR ASSEMBLY

Original 433-015A  
Part No  
Code GR3015




## LG GOLDSTAR CAM GEAR

Original 435-042B/A  
Part No  
Suit GHV51,GHV  
1232,GHV1  
246,GHV124  
6,etc.  
Code GR5022




## LG GOLDSTAR GEAR

Original 435-047A  
Part No  
Suit GHV1240  
Code GR5047




## LG GOLDSTAR GEAR ASSEMBLY

Original 435-054A  
Part No  
Code GR5054




## LG GOLDSTAR CENTRE UNIT

Complete  
assembled unit  
Original 321-369A  
Part No  
Suit VCP100  
Code MEC1369




## LG GOLDSTAR PULLEY CENTRE

Original 432-021A  
Part No  
Code PC4320



## LG GOLDSTAR MECHANISM PLATE

Plate & idler  
Original 256-218B  
Part No  
Code MEC2562






# Video Repair Parts


## LG GOLDSTAR GEAR

Original Part No	435-132A Subs 435-169A 435-146A 435-053A
Suit	AV65, GHV1296, VCR8000
Code	GR5132




## LG GOLDSTAR IDLER ASSEMBLY

Original Part No	337-005A
Suit	AV66, RG20, RA21H.
Code	VIA7005




## LG GOLDSTAR MECH

Original Part No	321-397C
Suit	AV66, RG20
Code	MEC1397




## LG GOLDSTAR IDLER

Original Part No	386-197A
Suit	VCP100, 101, VCP105, 106, VCP111, 115.
Code	VIA6197




## LG GOLDSTAR DOOR OPENER

Original Part No	465-006A
Code	GS5006




## LG GOLDSTAR CLUTCH ASSEMBLY

Original Part No	435-038A
Code	VXP0600




## LG GOLDSTAR DOOR OPENER

Original Part No	465-018A 465-007A
Code	GS5018




## LG GOLDSTAR GEAR HOUSING

Original Part No	321-232A
Suit	GVH1290, 1291, GHV1296, 1910.
Code	MEC3212




## LG GOLDSTAR MODE CAM GEAR

Original Part No	374-003A
Code	MCG3740




## LG GOLDSTAR / TEAC AUTO HEAD CLEANER

Original Part No	386-296A 386-296C
Code	RL6296




## LG GOLDSTAR LEVER & PINCH GEAR KIT

Original Part No	333-206A 435-245A
Suit	AV66, RG20
Code	KIT5245




## LG GOLDSTAR GEAR DRIVE

Original Part No	New 435-104A Old 435-055A
Suit	GHV1232 GHV1240 GHV1246 and others...
Code	GR5104




## LG GOLDSTAR GEAR

Original Part No	433-023A
Suit	AV66, RG20
Original Part No	433-023A
Code	GR3023



## LG GOLDSTAR / NEC CAM GEAR


Original Part No	435-433A NEC 79VG1047 VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	GR5433





## LG GOLDSTAR / NEC CAM GEAR

Original Part No	435-441A NEC 79VG1055 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GR5441




## LG GOLDSTAR / NEC WORM GEAR

Original Part No	437-020A NEC 79VG1063 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GR7020




## LG GOLDSTAR / NEC LOAD GEAR

Original Part No	435-437A NEC 79VG1051 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GR5437




## LG GOLDSTAR / NEC LOADING GEAR SUPPLY

Original Part No	435-435A NEC 79VG1049 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GR5435




## LG GOLDSTAR / NEC IDLER

Original Part No	386-396A NEC 79VG1031 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GIA6396




## LG GOLDSTAR / NEC GEAR P/S

Original Part No	435-442A NEC 79VG1031 VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	GR5442




## LG GOLDSTAR / NEC CLUTCH SUPPLY

Original Part No	337-007B
Suit	VN36, VNG67, VHG104, 5, 6, and more!
Code	GR7007




## LG GOLDSTAR / NEC CLUTCH TAKE-UP

Original Part No	337-008A
Suit	VN36, VNG67, VHG104, 5, 6, and more!
Code	GR7008




## LG GOLDSTAR CAM GEAR

Original Part No	4470R-0022A
Suit	W903H
Code	GR4470



## LG GOLDSTAR / NEC HEAD CLEANER

Original Part No	386-394A NEC VN36
Suit	P23H, P433H, P933H,RN800H, RN830H,T293H, T493H,VHG104, VNG67.
Code	ARM6394




## LG GOLDSTAR HEAD CLEANER

Original Part No	4261R0003A
Suit	AF293, 493, 993,AC250, 450, 950.
Code	ARM0003



## LG GOLDSTAR IDLER ARM

Original Part No	4261R0008A
Suit	AF293 AC250 Akai VSJ200 VSJ215
Code	VIA0008




## LG GOLDSTAR IDLER ARM

Original Part No	4261R0009A
Suit	AF493, 993,AC450, 950.Akai VSJ411, 416,VSJ700, 711,VSJ716, only.
Code	VIA0009



## LG GOLDSTAR LOAD ARM SU

Original Part No	4470R0026A
Suit	AF293, 493, 993,AC250, 450, 950.
Code	ARM0026





# Video Repair Parts

## LG GOLDSTAR LOADING MOTOR / BRACKET

Original Part No 4811R0010A

Suit AF293, 493,  
993.AC250, 450,  
950.  
Code VM0011

## LG GOLDSTAR LOAD SHAFT

Original Part No 1261R0010A

Suit AF293, 493,  
993.AC250, 450,  
950.  
Code ARM0010

## LG GOLDSTAR DRIVE GEAR

Original Part No 4470R0005A

Suit AF293, 493,  
993.AC250, 450,  
950.  
Code GR0033

## LG GOLDSTAR UP / DOWN GEAR

Original Part No 4470R0044A

Suit AF293, 493,  
993.AC250, 450,  
950.  
Code GR0044

## LG LOADING ARM

Original Part No 4471R-0015A

Suit V8844W  
Code ARM0015

## LG LOADING ARM

Original Part No 4471R-0017A

Suit V8824W  
Code ARM0017

## GRUNDIG

SEE JVC (Early) &  
PANASONICe.g.  
GV469M = "K" Mech'**GRUNDIG**VS940VPT = NVF65 Except  
for different Cassette Housing.

## □ Hitachi


### HITACHI IDLER ASSEMBLY

Original 6886971

Part No

Suit VT11.

Code VIA155




### HITACHI TYRE DRIVE IDLER

Original 6889931

Part No

Suit VT11,17,168

Code VIA160




### HITACHI IDLER ASSEMBLY

Original 6886792

Part No

Suit VT100,120,VT130,etc.

Code VIA145




### HITACHI CLUTCH ASSEMBLY

Original 6804834

Part No 6896954

Suit VTM728


Code MEC4834



### HITACHI MECHANISM

Suit VTM740

Code MEC7874



### HITACHI CLEANING ROLLER


Original 7472125

Part No

Suit VTM598E

Code VTM838E

Code RL2125




### HITACHI IDLER ASSEMBLY

Original 6861505

Part No


Code VIA116






## HITACHI COG DRIVE IDLER

Original	6886824
Part No	
Suit	VT138,20E
Code	VIA150




## HITACHI LOADING GEAR LEFT

Original	7429651
Part No	
Suit	VTM598
Code	GR9651




## HITACHI LOADING GEAR RIGHT

Original	7429661
Part No	
Suit	VTM598, 728, VTM818, 838
Code	GR9661



## HITACHI MECHANISM


Original	7794876 Old
Part No	7794873 With
	7794931
Suit	VTM748E Motor, Switch, Slide plate, etc.



## HITACHI BRACKET FL (R)

### CASSETTE LOADER RIGHT


Original	6804982
Part No	6804987
Suit	VTM598, 728, VTM748, 818, VTM838, etc.
Code	MEC4982



## JVC


## JVC IDLER ASSEMBLY

Original	PU46381
Part No	
Suit	HR3300,3330, HR3660,4100
Code	VIA210




## JVC TAKE-UP CLUTCH

Suit	HR3330, HR3660
Code	PU49280



## JVC IDLER ARM

Suit	HR2650 (3mm shaft)	HR2200 (4mm)
Code	PU52190A	PU48811D




## JVC TAKE-UP CLUTCH

Suit	HRD110, HRD120, HRD125, etc.
Code	PU55373




## JVC TAKE-UP CLUTCH

Suit	HR3300, HR3330, HR3660, HR4100, HR4110,etc.
Code	PU47752




## JVC IDLER ASSEMBLY

Original	PU48967B
Part No	
Code	VIA216




## JVC TAKE-UP CLUTCH

Suit	HR7200 etc.
Code	PU53462A




## JVC IDLER ASSEMBLY

Original	PU55374-3-8
Part No	
Suit	HRD110, GE8100 N830, RV360.
Code	VIA236



## JVC IDLER ASSEMBLY

Original	PU51402A
Part No	
Suit	HR7200,7300, HR7600,7650, HR7655,D110,D111 HRD120,D121,D225, N830, etc
Code	VIA228






# Video Repair Parts


## JVC IDLER

Original Part No	PU61004-1-3
Suit	HR-D540 HR-D580
Code	PU61004




## JVC CLUTCH UNIT

Original Part No	PU60953-1-2
Suit	HRD520, 521, HRD600, 610, HRD620, 830, HRDX20, 22, etc.
Code	PU60953




## JVC IDLER

Original Part No	PU58645-1-4
Suit	HR-D series.
Code	VIA240




## JVC AIR DAMPER

Suit	HR7200
Code	PU51252




## JVC CLUTCH UNIT

Original Part No	PU61005-1-4
Suit	HR-D540 HR-D580
Code	PU61005




## JVC MECHANISM

Original Part No	PU57658B-6
Suit	HR-D series.
Code	MEC658



## JVC CLUTCH MECH. ASSEMBLY

Original Part No	PU55822A-10
Equiv.	PU55822A-8
Suit	HRD455,725.
Code	PU55822




## JVC PINCH ROLLER LIFTER

Suit	HRD520,640,830 HRDS5000 HRDX20 VR3241,3275 and others.
Code	PQ32415




## JVC DRIVE GEAR ASSEMBLY

Suit	HR7600, HR7650
Code	PU51859A-2




## JVC DRIVE GEAR ASSEMBLY

Suit	HRD110, HRD111, HRD120, HRD121.
Code	PU51859C-11




## JVC DRIVE GEAR ASSEMBLY

3 pin connector.	
Suit	HRD455, 725 and others 3 pin connector.
Code	PUS36689V




## JVC DRIVE GEAR ASSEMBLY

2 pin connector.	
Suit	HRD455, HRD725, HRD755.
Code	PUS36689X




## JVC DRIVE GEAR ASSEMBLY

2 pin connector.	
Suit	HRD158, HRD160, 257,etc.
Code	PUS36689W



## JVC IDLER GEAR UNIT


Original Part No	PU60618-1-3
Suit	HRD520,521, 525,600, 830,X20,etc.
Code	PU60618





## JVC PLATE ASSEMBLY

Suit	HRD637, 825, HRDX20, X22, X24, X42, HRDJ400, 415, 615
Code	PQ43555C10



## JVC PLATE ASSEMBLY

Suit	HRD540 HRD92
Code	PQ44326A-3



## JVC ROLLER BAR

Suit	HR7650, 7700 etc.
Code	PU49042A



## JVC "GEAR-1"

Found in PUS26805U  
cassette housing

Suit	HRD120, 140, HRD141, 142, HRD143, etc.
Code	PQ40059



## JVC "GEAR-2"


Suit	NEC N830, Toshiba V55 JVC HRD120,140,141, 142,143,150,225, 250,565,725,etc...
Code	PQ40060



## JVC GEAR

Suit PUS26805  
cassette housing.

Suit	HRD120,140, HRD141,142, HRD143,150, HRD225, etc.
Code	PQ40065



## JVC CAM GEAR

Suit PUS26805  
cassette housing.

Suit	HRD150,225, HRD250,265, HRD565,725, & MORE.
Code	PQ30028



## JVC LIMITER SPRING

Fits between  
PQ30028 & PQ40066

Suit	HRD110,120,140,150,220,250,455 ,565,725,755, N382,830,831,895, MV800,RV360,380, GE8100,V55,V63, VR2925,2970
Code	PQ40068-2



## JVC LOAD GEAR

Suit PUS26805  
cassette housing.


Suit	HRD120,140, HRD141,142, HRD143,150, HRD225, etc.
Code	PQ40066



## JVC SLIDE GEAR


Suit PUS26805  
cassette housing.

Suit	HRD150,225, HRD250,265, HRD565,725, & MORE.
Code	PQ40067



## JVC LOADING GEAR 2

Original	PQ30193-1-2
Part No	HRD140,150, 250,455,
Suit	565,725, 755, N895, etc...
Code	PQ30193



## JVC DOOR OPENER


Suit PUS26805  
cassette housing.

Suit	HRD150,225, HRD250,265, HRD565,725, & MORE.
Code	PQ40074




## JVC GUIDE ARM

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ43567A-13



## JVC H.LOADING GEAR

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ43570B






# Video Repair Parts


## JVC LOADING ARM

Suit	HRD540, 580, HRD640, etc. HRJ200, etc.
Code	PQ43537B




## JVC LOADING ARM

Suit	HRD540, 580, HRD640, etc. HRJ200, etc.
Code	PQ43542D-4




## JVC LOADING ARM

Suit	HRD220, 221, HRJ625, etc.
Code	PQ46332A-3




## JVC TENSION ARM

Original Part No	PQ46303A-8, 4822 4037 1294
Suit	HRJ220, 221, 425, 435, HRJ621, 625, 635, etc. VR155, 357, 455, VR656 and more.
Code	PQ46303A




## JVC TENSION ARM LEVER

Original Part No	PQ35012-1-5 4822 4021 0367
Suit	HRJ220, 221, 425, 435, HRJ621, 625, 635, etc. VR155, 357, 455, VR656 and more.
Code	PQ35012




## JVC GUIDE ARM

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ46325B




## JVC PULLEY

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ35016-1-3




## JVC POLE BASE (T)

Suit	HRD910 HRJ200
Code	PU61103-2-7



## JVC POLE BASE (S)

Suit	HRD910 HRJ200
Code	PU61151-2-7




## JVC GEAR UNIT

Suit	HRD640
Code	PU61246-1-5




## JVC CLUTCH

Suit	HRD640
Code	PU61245-1-3



## JVC CONTROL CAM

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ20822-2-7




## JVC TENSION SPRING

Code	PQ43500
------	---------



## JVC LOADING ARM TAKE-UP


Suit	HRD230, 320, HRD370, 430
Code	PQ41985B-3






## JVC LOADING ARM SUPPLY

Suit	HRD230, 320, HRD370, 430
Code	PQ41979A-5




## JVC CAM GEAR UNIT

Suit	HRJ600
Code	PU61389




## JVC IDLER

Suit	HRJ600
Code	PU61390




## JVC CAM GEAR UNIT

Suit	HRJ600
Equiv.	PU61317-1-3
Code	PU61317-1-4




## JVC CLUTCH GEAR UNIT

Suit	HRJ600
Equiv.	PU61388-1-3
Code	PU61388-2




## JVC CENTRAL CAM

Suit	HRJ600
Code	PQ11649-1-3




## JVC CONTROL PLATE

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ11658-1-15



## JVC CAM GEAR


Original	PQ20250-1-1
Part No	
Suit	HRD170, HRD180, HRD530
Code	PQ20250



## JVC SUPPLY POLE

Complete kit  
Suits many late  
models.

Code	PTU96102E
------	-----------



## JVC STOPPER BLACK

Suit Tape Loading (S) Pole  
Base PQ61151-2-7 From  
Kit PTU96102E


Suit	HRD540,830, HRD910,etc.. HRJ200,etc..
Code	PQ45894



## JVC TAKE-UP POLE

Complete kit Suits  
many late models.


Code	PTU96103E
------	-----------



## JVC STOPPER WHITE


Suit Tape Loading (T)  
Pole Base PQ61103-2-7  
From Kit PTU96103E

Suit	HRD540,830, HRD910,etc.. HRJ200,etc..
Code	PQ45895




## WASHER TO SUIT "STOPPERS" ABOVE

Code	PQM30017-41
------	-------------



## JVC SLIDE PLATE

Original	4822 4668
Part No	3023
Suit	HRD910, VR253, VR454, etc.
Code	PQ44581B






# Video Repair Parts


## JVC CHANGE GEAR

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ46354




## JVC IDLER ARM

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ46312B-8




## JVC CLUTCH ASSEMBLY

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ46323A-1




## JVC LEVER METAL

Original Part No	Old PQ46342A-6 New PQ46342C-9 Philips 402240371302 482240210387
Suit	HRJ425, 635, etc. VR555-75, etc.
Code	PQ46342



## JVC LOADING ARM

Suit	HRJ220,221, HRJ625,etc
Code	PQ46337A-7




Only one type of arm in JVC  
Beware - There are two types  
used in Philips, See below !

## JVC/PHILIPS LOADING ARM - TAKE 2


Original Part No	Philips 4822-402-10625, Many models.
Code	ARM625

This gear has a smaller hole !  
Beware - There are two types  
used in Philips, See above !




## JVC CONTROL CAM

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ21684-1-3



## JVC HEAD CLEANER

Suit	HRJ600, etc.
Code	PQ44840B-5



## JVC HEAD CLEANER

Suit	HRJ400
Code	PQ46019




## JVC CLEANER

Suit	HRJ220, HRJ221, HRJ625
Code	PQ46419




## JVC CHANGE ARM ASSEMBLY

Original Part No	PQ46353A-1 PQ46353A-2
Suit	HRJ425, 435, HRJ625, 635,
Code	655, 755
	PQ46353




## JVC IDLER ARM

Original Part No	LP40114-002D LP40114-004A 4822-402-11053
Suit	HRJ255, 455, HRJ655, 755.
Code	VR288, 388.
	ARM4002




## JVC CLUTCH UNIT

Original Part No	LP40115-002C/D 4822-522-10701
Suit	HRJ255, 455, HRJ655, 755.
Code	VR288, 388.
	VIA5002



## JVC TENSION BRAKE

Original Part No	LP40109-003D 4822-402-11056
Suit	HRJ255, 455, HRJ655, 755.
Code	VR288, 388.
	TB9002





## JVC CAM GEAR

Original Part No	LP30229-001B LP30229-002F
Suit	HRJ255, 455, HRJ655, 755.
Code	MCG9001



## JVC CAM GEAR

Original Part No	4822-528-11256
Suit	VR288, 388, VR588, 788, VR888, 988.
Code	MCG9002



## JVC DIRECT GEAR

Original Part No	LP40122-001A, LP40122-002A, LP30463-002A 4822-522-10699
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR2001



## JVC CLEANER

Original Part No	LP40369-001B/D PQ46418-1-2 4822-528-11247
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	ARM9001




## JVC SLIDE PLATE

Original Part No	LP10080-002E/F 4822-466-11932
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	PSM0002




## JVC LIMIT GEAR 1

Original Part No	LP30239-002E/F 4822-522-10704
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR9003



## JVC LIMIT GEAR 2

Original Part No	LP30240-002C/G, 4822-522-10705
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR9004



Colour Supplied May Vary. (stock is grey)

## JVC LIMIT GEAR 2

As above but black


Code GR9004

Colour Supplied May Vary.  
(stock is grey)




## JVC LOAD ARM TAKE-UP

Original Part No	LP40103-002B 4822-402-11063
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR3002



## JVC LOADING ARM SUPPLY

Original Part No	LP30224-001A 4822-402-11063
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR3003



## JVC DRIVE GEAR

Original Part No	LP30243-001B/C 4822-522-10702
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR3004




## JVC RELAY GEAR

Original Part No	LP30242-001A LP30242-002A 4822-522-10703
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR3005




## JVC CASSETTE GEAR

Original Part No	LP30237-002A/B 4822-522-10698
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR7002



## JVC CLEANING ARM

Original Part No	PQ46436A-1
Equiv.	PQ46418-1-2
Suit	HRJ425
Code	PQ46436





# Video Repair Parts


## JVC TAKE-UP LEVER

Original Part No	PQ21686-1-3
Suit	HRJ615
Code	PQ21686



## JVC U-MATIC E. ROLLER ASSEMBLY

Suit	CR6060
Code	PU41155A



## JVC U-MATIC RING DRIVE ROLLER


Suit	CR8300
Code	PU42645A



## Mitsubishi / AWA


### MITSUBISHI/AWA IDLER

Original Part No	522P002010
Suit	AV12,14,51
Code	VIA910
Code	AV52,400,etc.




### MITSUBISHI/AWA GEAR

Original Part No	641D799010
Suit	AV12,51,400,
Code	GR7990
Code	410,TR102,etc.




### MITSUBISHI/AWA CAM GEAR (A)

Original Part No	641B093010
Suit	AWA/Mitsubishi
Code	GR9301
Code	




### MITSUBISHI IDLER ASSEMBLY

Original Part No	522B01701
Suit	HS337, HS338, HSE20
Code	etc...
Code	VIA1701



## MITSUBISHI/AWA GEAR

Original Part No	641D797010
Suit	AWA AV12 AV400
Code	GR7970
Code	




## MITSUBISHI/AWA CAM GEAR (B)

Original Part No	641B094010
Suit	AWA AV11, 12, 14, 51, 52, AV400, 410, HS306, 307, 318, HS319, 400, 410, TR102
Code	GR9401
Code	




## MITSUBISHI DRIVE GEAR

Original Part No	622D227010
Suit	HS521V,531V,541V, HS551V,581V, HS651V,661V, HSM60V,HSX3, HSX10,20,etc.
Code	GR2270
Code	




## MITSUBISHI MAIN CAM

Original Part No	641B32301
Suit	HSMX1,X2
Code	MCG2301
Code	



## MITSUBISHI MAIN CAM #2

Original Part No	641B32401
Suit	HSMX1,X2
Code	MCG2401
Code	



## MITSUBISHI PINCH CAM

Original Part No	641B31402
Suit	HSMX1,X2
Code	CAM1402
Code	



## MITSUBISHI PINCH CAM


Original Part No	641B63002
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	CAM3002
Code	






## MITSUBISHI "R" CAM

Original Part No	621C23501 621C235010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	GR5010




## MITSUBISHI PINCH CAP

Original Part No	641B62801 641B628010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	PC2801




## MITSUBISHI LOADING ARM

Original Part No	592B04701-0	592B04801-0
Suit	HSM50,HSMX3,5,7,10,20	HSM50,HSMX3,5,7,10,20
Code	ARM701	ARM801




## MITSUBISHI GEAR JOINT

Original Part No	621C257010 621C25703 621C257030
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	GR5701




## MITSUBISHI GEAR MAIN

Original Part No	641B63702 641B637020 641B63701/0
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	GR3702



## MITSUBISHI CAM PLATE

Original Part No	641A31101 641A311010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	CP1101




## MITSUBISHI GEAR IDLER

Original Part No	522C07702 522C077020 522C07701/0
Suit	HSMX1,X2, HSE11,17, HSE82,etc.
Code	GIA7702




## MITSUBISHI CLEANING ROLLER

Original Part No	621C03301 621C033010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	RL3301




## MITSUBISHI PINCH GEAR

Original Part No	621C24001 621C240010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	GR4001



## MITSUBISHI REEL IDLER

Original Part No	522B05703 522B057030 522B05701/0
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	GIA5703




## MITSUBISHI PULLEY WORM

Original Part No	621C25901 621C259010
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	PW5901




## MITSUBISHI LOAD ARM UNIT [T]

Original Part No	593C826010 593C826020
Suit	HS521, 621,HS640, 7424.
Code	GR6020



## MITSUBISHI DRIVE GEAR

Original Part No	641B793010
Suit	HS521, 621,HS640, 7424.
Code	GR7930






# Video Repair Parts

## MITSUBISHI CAM GEAR

Original Part No	641B792010
Suit	HS521, 621, HS640, 7424.
Code	GR2010



## MITSUBISHI LOAD WORM GEAR

Original Part No	621C504010
Suit	HS521, 621, HS640, 7424.
Code	GR4010



## MITSUBISHI TIME-LAPSE VCR

### PULLY GEAR


Original Part No	641C790010
Suit	HV5440 HVBZ71 VT35354NBS
Code	PLY0010



## NEC

## NEC REEL DRIVE ASSEMBLY


Original Part No	16192683
Suit	9000 series, DS6000, DX1600, DX3000
Code	MEC2683



Note: Requires ARM582 (\$3.95)


## NEC CR SLIDING ARM

Suit	N9073 N9401 and other early models. Required when replacing MEC2683 Mech.
Code	ARM582




## NEC IDLER PLATE

Original Part No	79TD3955
Code	VIA3955




## NEC CAM GEAR

Original Part No	97S2705700
Suit	VN20
Code	GR5700




## NEC MECHANISM

Original Part No	97SB335300
Suit	VN20
Code	MEC5300



## NEC REEL DRIVE ASSEMBLY


Original Part No	16178173
Suit	N901, 911
Code	MEC8179



## NEC MODE CAM ASSEMBLY


Inc.Motor.

Original Part No	16185091
Suit	Late 9000 & DX1600,3000
Code	MCA5091



## NEC MODE CAM ASSEMBLY


Original Part No	16179645
Suit	N901
Code	MCA9645



## NEC MODE CAM ASSEMBLY


Inc. Motor.

Original Part No	16179832
Suit	N911 and Early 9000
Code	MCA9832




## NEC IDLER ASSEMBLY

Original Part No	16180801
Suit	N901,911, N912,etc.
Code	VIA460



## NEC LOADING GEAR

Original Part No	16443362
Suit	N901, 911, etc.
Code	GR3362






## □ Orion

### ORION IDLER


Original Part No	850A200026
Part No	850A200038
Code	GIA2026



## □ Panasonic


### PANASONIC IDLER

Original Part No	VXP0243
Part No	NV8400, NV8600, NV8610
Code	VIA304




### PANASONIC CLUTCH ASSEMBLY

Original Part No	VXP0265
Code	VIA312




### PANASONIC LOADING PULLEY

Code	VDP0985
------	---------



### PANASONIC IDLER

Original Part No	VXP0245
Suit	NV8400, NV8600, NV8610.
Code	VIA308



### PANASONIC IDLER

Original Part No	VXP0329
Suit	NV2000 NV3000
Code	VIA316



### PANASONIC IDLER

Original Part No	VXP0331
Suit	NV2000 NV3000
Code	VIA320




### PANASONIC IDLER

Original Part No	VXP0344
Suit	NV7000 NV7200
Code	VIA328




### PANASONIC SUPPLY REEL

Suit	NV7000 NV7200 NV7800 etc...
Code	VXR0103




### PANASONIC SUPPLY GEAR

Suit	NV100
Code	VXP0402



### PANASONIC IDLER PACK

Suit	NV300 etc.
Code	VXL0997




### PANASONIC GEAR

Code	VDG0235
------	---------




### PANASONIC DISC DRIVE

Code	VDG0335
------	---------



### PANASONIC INTERMEDIATE GEAR (B)

Suit	NV370
Code	VDG0115






# Video Repair Parts

## PANASONIC PULLEY GEAR


Suit NV870  
Code VDG0142



## PANASONIC IDLER ASSEMBLY


IDLER VXP0343

Suit NV7000  
NV7200  
Code VIA324




## PANASONIC TAKE-UP CLUTCH ASSEMBLY

Original VMLS0081  
Part No  
Code VIA385




## PANASONIC TAKE-UP GEAR

Suit NV100  
Code VXP0403




## PANASONIC TAKE-UP IDLER

Original VXP0433  
Part No  
Suit NV300 etc.  
Code VIA336




## PANASONIC CAM GEAR

Suit NV2000,  
NV3000,  
NV7000,  
NV7200  
Code VDG0035




## PANASONIC SHAFT GEAR

Suit NV777  
Code VDG0119




## PANASONIC DRIVE GEAR (2)

Suit NV850  
Code VDG0143



## PANASONIC GEAR

Suit NV370 etc.  
Code VDG0155




## PANASONIC ROLLER POST

Suit NV730,  
NEC 911A  
Code VXP0444A




## PANASONIC TAKE-UP IDLER

Suit NV600  
Original VXP0488  
Part No  
Code VIA344




## PANASONIC KICK GEAR

Suit NV450,  
NVG10,  
NVG30  
Code VDG0178




## PANASONIC INTERMEDIATE GEAR (A)

Suit NV450,  
NVG10,  
NVG30  
Code VDG0189



## PANASONIC PULLEY GEAR


Suit NVG30  
Code VDG0275






## PANASONIC WIPER ARM

Suit NVG7, 9,  
NVG10, 11,  
NVG12, 16.  
Code VML1756




## PANASONIC INTERMEDIATE GEAR

Suit NV370,  
NV777,etc.  
Code VDG0146




## PANASONIC GEAR

Suit NV370 etc.  
Code VDG0156




## PANASONIC GEAR

Suit NV370,  
NV777  
Code VDG0177




## PANASONIC IDLER

Suit NV777,  
NV788  
Original Part No VXP0463  
Code VIA340




## PANASONIC INTERMEDIATE GEAR (B)

Suit NV450,  
NVG10,  
NVG30  
Code VDG0188




## PANASONIC CAM GEAR

Suit NV370,450,  
NVG10,30,etc.  
Code VDG0200




## PANASONIC DRIVE GEAR (B)

Suit NVG10  
Code VDG0278




## PANASONIC SUPPLY REEL GEAR

Suit NVG20  
Code VDG0337




## PANASONIC SUB CAM GEAR

Suit NVF51,S1,  
NVJ35,etc.  
Code VDG0343




## PANASONIC MAIN CAM GEAR

Suit NVFS1,  
NVJ35,etc.  
Code VDG0346



## PANASONIC CLUTCH DISC

Suit NVD48,FS1,  
NVH65,  
NVL25,  
RTV560,etc.  
Code VDG0349




## PANASONIC P5 SECTOR PULL GEAR

Suit NVG20, 22, NVG20, 22,  
NVJ700 NVJ700  
Code VDG0651 VDG0357



## PANASONIC PINCH CAM KIT

Suit NVD38,  
F55,FS1,  
NVG33,  
H65,J1,  
NVL20,W1,  
RTV740,etc.  
Code VDG0421






# Video Repair Parts


## PANASONIC GEAR

Suit	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV740,etc.	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV740,etc.
Code	VDG0483	VDG0334




## PANASONIC CLUTCH DISC

Suit	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV740,etc.
Code	VDG0547




## PANASONIC RING GEAR

Suit	NVF55,FS1, NVJ35,etc.
Code	VDG0342




## PANASONIC PLANET GEAR

Suit	NVF55,FS1, NVJ35,etc.
Code	VDG0345




## PANASONIC CENTRE GEAR

Suit	NVF55,FS1, NVJ35,etc.
Code	VDG0348




## PANASONIC CLUTCH DISC LEVER

Suit	NVD48,FS1, NVH65, NVL25, RTV740,etc.
Code	VDG0350




## PANASONIC LOADING GEAR (S)

Suit	NVD38, F55,FS1, NVG33,H65,J1, NVL20,W1, RTV560,etc.
Code	VDG0419




## PANASONIC RETAINER GEAR

Suit	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV560,etc.
Code	VDG0422




## PANASONIC LOADING CAM GEAR

Suit	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV560,etc.
Code	VDG0448




## PANASONIC MAIN CAM GEAR

Suit	NVD38, F55,FS1, NVG33, H65,J1, NVL20,W1, RTV560,etc.
Code	VDG0574




## PANASONIC GEAR

Suit	NVF55,FS1, NVJ45,etc.
Code	VDG0332




## PANASONIC GEAR KIT

Original Part No	VUA4100KIT
Suit	NVG mech' RTV560,etc.
Code	VUA4100




## PANASONIC SUB LOADING ARM

Suit	NVD38,FS1, NVG20,H75, NVL20,etc. RTV560,etc.
Code	VXL1480



## PANASONIC TENSION ROLLER


Suit	NVF55,FS1,etc
Code	VXA3516






## PANASONIC ROLLER

Suit NVSD10,etc.  
Code VXA4799




## PANASONIC CAPSTAN BEARING

Suit NVSD10,etc.  
Code VXD0140




## PANASONIC CLUTCH GEAR

Original Part No VXP0599  
Suit NV250...  
Code VIA360



## PANASONIC GEAR

Suit NV370 NV850  
etc.  
Code VXP0523




## PANASONIC CLUTCH GEAR IDLER

Suit NV370, NV370,  
780,850 780,850  
Code VXP0595 VDG0147




## PANASONIC CENTRE CLUTCH

Suit NV280 NVG7,  
10, NVG12  
etc.  
Code VXP0600




## PANASONIC LOADING GEAR

Suit NV370,  
NV850,etc.  
Code VXP0520




## PANASONIC RELEASE LEVER

Suit NVF55,FS1,  
NVG10,J45,etc.  
RTV560,etc.  
Code VML1860




## PANASONIC SUB LOADING ARM

Suit NVF55,J1, NVF55,J1,  
NVL25,etc. NVL25,etc.  
Code VXL1856 VXL1857




## PANASONIC POST UNIT

Suit NVF55,FS1,etc  
Code VXL1485



## PANASONIC CAPSTAN BRAKE

Suit NVG10,20,  
NVG30,etc.  
Code VXZ0185




## PANASONIC IDLER ASSEMBLY

Original Part No VXP0521  
Suit NV250,450, G10  
etc.  
Code VXP0521




## PANASONIC IDLER

Original Part No VXP0581  
Suit NV730,770.  
Code VIA350



## PANASONIC WORM WHEEL PACK

Suit NV250,280,450,470,  
730,770,870,etc.  
Code VXP0604






# Video Repair Parts

## PANASONIC CAM CAP

Code VMX1353



## PANASONIC SPACER


Code VMX0259



## PANASONIC GEAR PACK

Kit combines  
VDG0345 X3  
VDG0422 X1


Suit NVG mech'  
RTV560,etc.  
Code VXP0878



## PANASONIC "G" MECHANISM PARTS KIT

Contains VXL1490,  
VXL1743, VXP0878,  
VDG0597, VML1849,  
VMX1079, washers  
and C rings.


Code VUA4104



## PANASONIC PINCH CAM UNIT


Suit NVSD Mech.  
Code VDG0886

Suitable for the  
Pinch roller assembly  
VXL2246 (4-28)




## PANASONIC MAIN LEVER UNIT

Suit NVSD Mech.  
Code VXL2307




## PANASONIC IDLER ASSEMBLY

Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Equiv. VXL2229  
Code VXL2378




## PANASONIC ARM

Suit Super Drive  
Equiv. VXL2243  
Code VXL2394




## PANASONIC GEAR

NVSD10A  
Suit NVSD20A  
NVSD30A  
Code VDG0868



## PANASONIC AUTO HEAD CLEANER


Suit NVSD10, 20,  
NVSD400, etc.  
Code VXL2440



## PANASONIC AUTO HEAD CLEANER

Suit Super Mech.  
Code VXL2384

DISCONTINUED!  
Use VXL2440 above.



## PANASONIC CLEANER ROLLER


Suit NVHD620,670,  
NVSD200,230,  
NVSD270,280,  
NVSD420,430.  
Code VDP1668K



## PANASONIC SIDE PLATE


Includes opener  
lever VXL2250

Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXA4660



## PANASONIC SIDE PLATE


Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXA4806






## PANASONIC CASSETTE HOLDER

Suit	NVSD10, 20, 30	NVF65, 66, 70, 90
Equiv.		VXA3832
Code	VXA4661	VXA3840




## PANASONIC SHAFT ASSEMBLY

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1339




## PANASONIC SIDE PLATE

Suit	NVL20, 25, 'G' Mech
Code	VXA4076




## PANASONIC SIDE PLATE

Suit	NVG25, 28, 'G' Mech
Equiv.	VMD918 NVH65, 75,
Code	VXA3015




## PANASONIC SIDE PLATE

Original Part No	PCB# VEP00R12
Suit	NVJ45, etc.
Code	VXA4468




## PANASONIC SHAFT

Suit	NVG33, NVH75, etc.
Equiv.	VXP0987
Code	VXP0851




## PANASONIC BRAKE

Suit	NVSD10
Code	VXZ0312




## PANASONIC BRAKE

Code	VXZ0262
------	---------




## PANASONIC BRAKE

Suit	Super Drive
Code	VXZ0274




## PANASONIC SPRING

Code	VMB1288
------	---------




## PANASONIC BRAKE

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXZ0313




## PANASONIC BRAKE

Suit	NVG Mech.
Code	VXL2088




## PANASONIC BRAKE

Code	VXL1500
------	---------



## PANASONIC GEAR

Code	VDG0885
------	---------






# Video Repair Parts


## PANASONIC LOADING ARM

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXL2299




## PANASONIC LOADING ARM

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXL2300




## PANASONIC SUBLOAD ARM

Code	VXL2306
------	---------




## PANASONIC GEAR

Suit	NVSD10A, NVSD20A, NVSD30A
Equiv.	VDG0862
Code	VDG0957




## PANASONIC GEAR

Suit	NVSD10A, NVSD20A, NVSD30A
Equiv.	VDG0861
Code	VDG0956




## PANASONIC CLUTCH

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1409



## PANASONIC ARM


Original Part No	VXL1861, VXL1490
Suit	NV-J11 etc., NV-G, etc., RTV560, etc.
Code	VXL1861



## PANASONIC GEAR KIT


Kit combines VXP0767  
VDV0159 and washers.

Code	VXP0917K
------	----------




## PANASONIC CAM GEAR

Suit	NVSD20A
Code	VDG0913




## PANASONIC ARM

Code	VXL1244
------	---------



## PANASONIC GEAR

Suit	NV2000, NV3000, NV7000, NV7200, NV7800
Code	VDG0017



## PANASONIC CARRIAGE DOWN GEAR

Suit	NVSD1, NVSD10, NVSD20
Code	VDG0871



## PANASONIC WORM GEAR

As used with: VEM0427 Motor


Suit	NVSD10, 20, etc.
Code	VDG0866



## PANASONIC PULLEY MOTOR COUPLING

As fitted to: VEM0427 Motor

Suit	NVSD10, 20, etc.
Code	VDP1434






## PANASONIC MAIN CAM

Original Part No	VDG1220
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VDG1220




## PANASONIC IDLER ARM

Original Part No	VXL2678, VXL2792
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2792




## PANASONIC CONVERSION GEAR

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Original Part No	VDG1221
Code	VDG1221



## PANASONIC CENTRE CLUTCH

Suit	NVHD NVSD, NVSJ & NVFJ
Original Part No	VXP1732
Code	VXP2035




## PANASONIC CENTRE CLUTCH

Original Part No	VXP1850
Suit	NV-FJ600, NV-FJ720, NV-SJ720
Code	VXP2053




## PANASONIC TAKE-UP BRAKE

Original Part No	VXL2667, VEK8239
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2667




## PANASONIC LOADING ARM

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2670




## PANASONIC LOADING ARM

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2672



## PANASONIC REVIEW ARM UNIT

Suit	NVHD100,600, NVHS950, NVSD10,20, TC20S, TC21L, TC51RM52, SM52, VR743/75, AG526,
Code	VXL2310



## PANASONIC INCLINED BASE [T]

Suit	NV-SJ200A NV-SJ400A
Code	VXA5854



## PANASONIC MAIN LEVER

Suit	NV-SJ200A NV-SJ400A
Code	VML3166



## Samsung


### SAMSUNG

AKAI  
PALSONIC  
FUNAI  
GOLDSTAR  
TEAC




## SAMSUNG/AKAI IDLER

Original Part No	9000 250 3308 6900 025 0330
Suit	VS200 etc. and equiv.
Code	VIA40



## SAMSUNG IDLER

Code	VIA700
------	--------






# Video Repair Parts


## SAMSUNG/TEMPEST IDLER

Original Part No	5253-701-1105 65253-701-110
Suit	TE900, VB900, VB910, VB2215
Code	VIA710




## SAMSUNG/TEMPEST IDLER

Original Part No	66052-600-310
Suit	TE77R, VRD100, VCP90R, VB711, 750, VB8220, PB980, 981,
Code	VIA730



## SAMSUNG/AKAI/TEMPEST IDLER

Original Part No	65153-600-011 65153-600-100
Suit	TE90H, VS11, 12, DS757
Code	VIA720



## SAMSUNG TEMPEST REEL BRAKE

Original Part No	47647007205
Suit	VB520, 900, Akai VS200, TE900H
Code	RDB900



## SAMSUNG LOADING SHAFT


Original Part No	61043002500
Suit	VB300 VB370, etc.
Code	CH2500



## SAMSUNG PINCH DRIVE


Supplied locked into alignment.

Original Part No	67179-0069-01
Suit	VB300,etc.
Code	GR6901




## SAMSUNG GEAR RELAY S1

Original Part No	61474006101
Suit	VB300 VB370, etc.
Code	GR6101




## SAMSUNG GEAR RELAY S2

Original Part No	61474006201
Suit	VB300 VB370, etc.
Code	GR6201




## SAMSUNG GEAR RELAY T

Original Part No	61474006001
Suit	VB300 VB370, etc.
Code	GR6001




## SAMSUNG GEAR RELAY S3

Original Part No	61474006301
Suit	VB300 VB370, etc.
Code	GR6301




## SAMSUNG IDLER SUB ASSEMBLY

Original Part No	61604000301
Suit	VB300 VB370, etc.
Code	GR3001




## SAMSUNG GEAR ESCALATOR

Original Part No	61472005401
Suit	VB300 VB370, etc.
Code	GR5401




## SAMSUNG GEAR WORM WHEEL

Original Part No	61473005302
Suit	VB300 VB370, etc.
Code	GR5302



## SAMSUNG GEAR MASTER

Original Part No	61472005502
Suit	VB300 VB370, etc.
Code	GR5502







## SAMSUNG LOADING MOTOR


Includes Gears, Motor, etc.

Original	67179-0068-00
Part No	
Code	MEC6800




## SAMSUNG GEAR IDLER ASSEMBLY

Original	61453000101
Part No	
Suit	VB300 VB370, etc.
Code	GIA1001




## SAMSUNG LOAD SLIDE LEVER

Original	66602603510
Part No	
Suit	VB300 VB370, etc.
Code	LEV3510



## SAMSUNG GEAR LOAD LEFT

Suit	VB300 VB370, etc.
Original	61473004701
Part No	
Code	GR4701




## SAMSUNG GEAR LOAD RIGHT

Suit	VB300 VB370, etc.
Original	61473004501
Part No	
Code	GR4501




## SAMSUNG IDLER SUB-ASSEMBLY

Original	66054-609-411
Part No	
Code	GIA9411



## SAMSUNG GEAR CLUTCH

Original	66053-604-420
Part No	
Suit	VB1560
Code	GIA4420



## SAMSUNG LOAD GEAR R

Original	6526 460 6610
Part No	
Suit	PB990, VB1230, VB1260, 1530, 1850.
Code	GR6610




## SAMSUNG GEAR JOINT

Original	6520 360 5330
Part No	
Suit	PB990, VB1230, VB1260, 1530, 1850.
Code	GR5330




## SAMSUNG IDLER ASSEMBLY

Original	61603-0006-00
Part No	
Suit	SV10, 11, 12, SV30, 80, 140
Code	GIA600




## SAMSUNG CLUTCH ASSEMBLY

Original	61453-0003-00
Part No	
Suit	SV10, 11, 12, SV30, 80, 140
Code	VIA300




## SAMSUNG LOADING GEAR (L)

Original	61473-0107-00
Part No	
Suit	SV10, 11, 12, SV30, 80, 140
Code	GR1070



## SAMSUNG LOADING GEAR (R)

Original	61473-0105-00
Part No	
Suit	SV10, 11, 12, SV30, 80, 140
Code	GR1050






# Video Repair Parts

## SAMSUNG MASTER CAM GEAR

Original Part No	61472010011 614720104011G11
Suit	SV10, 11, 12, SV30, 80, 140
Code	MCG1001




□ Sanyo / Fisher / Sony



**SANYO**


## SAMSUNG WORM WHEEL

Original Part No	61473-0102-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	GR1020



## SAMSUNG SHAFT ARM (F/L)

Original Part No	61403-0073-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	ARM73



## SAMSUNG F/L ARM

Original Part No	AC66-30546A
Suit	SV220B SV435B
Code	LEV0546



## SAMSUNG GEAR

Original Part No	AC66-00039A
Suit	SV220B SV435B
Code	GR0039




## SAMSUNG CAM ARM

Original Part No	AC66-30013A
Suit	SVA130B
Code	ARM0013



## SAMSUNG DVD-VCR CENTRE GEAR


DVD-VCR Combo' unit.	
Original Part No	AC66-20581A
Suit	DVD-V5000 DVD-V7500 SV235, 240, SV245, etc.
Code	GRC2058






## SANYO/FISHER IDLER

Original 143-0-661T-03800  
Part No  
Code VIA508




## SANYO ROLLER WIND PULLEY

Original 143-0-4804-00100  
Part No Fisher FVH-PP530  
Code RWA530



## SANYO IDLER ASSEMBLY

Original 143-0-662T-1560 or  
Part No 613-037-4899  
Suit VHR2700 etc.  
Code VIA520




## SANYO IDLER ASSEMBLY

Original 143-0-581T-14001 or  
Part No 613-037-3410  
Suit VHR3500 etc.  
Code VIA530




## SANYO IDLER ASSEMBLY

Original 143-0-4904-00900 or  
Part No 621-010-1612  
Code VIA550




## SANYO IDLER ASSEMBLY

Original 613 037 4875  
Part No  
Suit VHR1100, 1300,1500  
Code VIA565




## SANYO ROLLER ASSEMBLY

Original 613-037-4905 or  
Part No 143-0-662T-15621  
Suit VHR3100, D500,etc  
Code VIA570




## SANYO/SONY GEAR

Original 613-0222-701  
Part No  
Suit VHR4100 SLVX10,20  
Code GR2701




## SANYO/SONY IDLER ASSEMBLY

Original 613-022-0134 Also  
Part No 613-093-3928  
Suit VHR4100 SLVX10,20  
Code GIA134




## SANYO IDLER CLUTCH

Original 613-085-7101  
Part No  
Equiv. 613-022-0141  
Suit VHR5700, 6700 etc.  
Code VIA568




## SANYO IDLER CLUTCH

Original 613-100-4696  
Part No SRT500P TLS900P  
Suit TLS924P TLS2000  
TLSS2500P  
Code VIA4696



## SANYO CAM GEAR

Original 613-022-2718  
Part No  
Suit VHR4100  
Code GR2718




## SANYO FRICTION GEAR

Original 613-022-0066  
Part No 613-102-0900  
Suit VHR4100,  
VHR5700,  
SVX10, 20,  
etc & Sony  
Code GR2266



## SANYO GEAR

Original 143-0-581T-13800  
Part No  
Suit VHR3100 etc.  
Code GR3800






# Video Repair Parts

## SANYO CAM-SLIDE


This new upgrade part may differ from your part. Includes instructions.

Original Part No	6130949240
Suit	VHR190 VHRD4800
Code	CSA9240



## SANYO GEAR (1)

Original Part No	613-151-9138
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	GR9138




## SANYO CLEANING ROLLER

Original Part No	613-158-5829
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	RL5829




## SANYO GEAR REEL

Original Part No	613-152-2756
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	GR2756




## SANYO GEAR

Original Part No	613-152-2770
Suit	VHR510, 530, VHR590, 610, VHR630, 650.
Code	GR2770




## SANYO GEAR

Original Part No	613-152-2763
Suit	VHR510, 530, VHR590, 610, VHR630, 650.
Code	GR2763




## SANYO PULLEY WHEEL

Original Part No	613-151-9701
Suit	VHR510, 530, VHR590, 610, VHR630, 650.
Code	GR9701




## SANYO GEAR

Original Part No	613-156-3841
Suit	VHR510, 530, VHR590, 610, VHR630, 650.
Code	GR3841




## SANYO GEAR CLUTCH

Original Part No	613-160-4186
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	GR4186



## SANYO CAM GEAR


Original Part No	613-156-4008
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	GR4008



## □ Sharp

### SHARP IDLER ASSEMBLY

Original Part No	NIDL0005GEZZ
Code	NIDL0005



## REPLACEMENT

Code	VIA608
------	--------


### SHARP IDLER ASSEMBLY

Original Part No	NIDR0004GEZZ
Code	VIA616




### SHARP IDLER ASSEMBLY

Original Part No	NPLYV0107GEZZ
Code	VIA632



### SHARP IDLER ASSEMBLY


Original Part No	NPLYV0111GEZZ
Code	VIA636






## SHARP MASTER CAM GEAR

Original Part No	NGERH1024GEZZ
Suit	300 series,etc, Philips 4802 522 37129
Code	MCG1024




## SHARP IDLER ASSEMBLY

Original Part No	NIDL0006GEZZ
Code	NIDL0006




## SHARP IDLER

Original Part No	NPLYV0051GEZZ, Philips 4802 528 77224 VIA628
Suit	
Code	MP121




## SHARP MOTOR PULLEY

Original Part No	NPLYV0121GEZZ
Suit	MOTORS, RMOTV1004GEZZ, RMOTV1007GEZZ, RMOTV1008GEZZ, RMOTV1010GEZZ
Code	MP121




## SHARP MASTER CAM GEAR

Original Part No	NGERH1043GEZZ
Suit	VC400 series etc.
Code	MCG1043



## SHARP LEVER


Original Part No	MLEVP0134GEZZ
Suit	VCF18, VCA105X
Code	LEV0134



## SHARP GEAR IDLER ASSEMBLY

With tape lock disable.


Original Part No	NGERH1122GEZZ
Suit	VCA105, 111X, etc.
Code	GIA1122



## SHARP GEAR IDLER ASSEMBLY


Without tape lock disable.

Original Part No	NGERH1128GEZZ
Suit	VCA115X,etc.
Code	GIA1128




## SHARP WORM WHEEL

Original Part No	NGERW1032GEZZ
Suit	VCA505X etc.
Code	GR1032




## SHARP MASTER CAM GEAR

Original Part No	NGERH1074GEZZ
Suit	VC600 series.
Code	MCG1074




## SHARP LEVER

Original Part No	MLEVP0135GEZZ
Suit	VCF18
Code	LEV0135




## SHARP LOADING GEAR

Original Part No	NGERH1022GEZ
Suit	VC481 etc.
Code	GR1022




## SHARP LOADING GEAR

Original Part No	NGERH1076GEZZ
Suit	VCH851
Code	GR1076



## SHARP LOADING GEAR

Original Part No	NGERH3010GEZZ
Suit	VC481 etc.
Code	GR3010






# Video Repair Parts


## SHARP CAM GEAR

Original Part No	NGERH1073GEZZ
Suit	VC600,700, 6F3, 6V3, etc.
Code	GR1073




## SHARP CASSETTE LOAD ARM

Original Part No	MARMP0029GEZZ
Suit	VC651, 684, VC685, 686.
Code	ARM29



## SHARP CASSETTE UNLOCK KEY

Original Part No	MARMP0026GEZZ
Suit	VC9300
Code	ARM26




## SHARP SPRING

Original Part No	MSPRT0140GEFJ
Suit	VC481 and other models.
Code	SPR140



## SHARP SPRING

Original Part No	MSPRD0092GEFJ
Suit	VC111X and other models.
Code	SPR92



## SHARP SPRING

This fits LANG9


Original Part No	MSPRD0021GEFJ
Suit	
Code	SPR21



## SHARP DOUBLE ACTION PLATE


Known as FIXING METAL.

Original Part No	LANGJ0009GEZZ
Code	LANG9




## SHARP LOADING GEAR

Original Part No	NGERH1119GEZZ
Suit	VCA111X
Code	GR1119



## SHARP BRAKE LEVER

Original Part No	MLEVP0101GEZZ
Suit	VCA101, 103, VCD801, etc.
Code	LEV0101



## SHARP TAPE GUIDE LEVER P5

Original Part No	MLEVP0273AJZZ
Suit	VCA200, 400, VCA600, 650.
Code	LEV0273




## SHARP CAM GEAR

Original Part No	NGERH1268GE00
Suit	VCA200, 250, VCA400, 450, VCA600, 650.
Code	GR1268



## SHARP LOADING GEAR

Original Part No	NGERH1120GEZZ
Suit	VCA, VCB, VCD, VCH, Series
Code	GR1120



## SHARP CAM GEAR


many VC-A & VC-H Series.

Original Part No	NGERH1129GEZZ
Suit	
Code	GR1129



## SHARP CASSETTE LOAD ARMS


Description	Left NGERW1035GEZZ	Right NGERW1034GEZZ
Suit	VCF18,111, etc.	
Code	GR1035	GR1034






## SHARP CASSETTE OPENER

Original	MLEVP0142GE00
Part No	VCA111X etc.
Suit	
Code	LEV0142




## SHARP CAM GEAR

Original	NGERH1109GEZZ
Part No	
Suit	VCA201
Code	GR1109




## SHARP CAM GEAR

Original	NGERH1118GEZZ
Part No	
Suit	VCA & VCH series Philips VCR's VR6448, 6548 etc
Code	GR1118




## SHARP CAM GEAR

Original	NGERH1108GEZZ
Part No	
Suit	VCA series Philips VCR's VR6448, 6548 etc.
Code	GR1108




## SHARP TAKE-UP LOADING GEAR

Suit	VCA36, 41, 62, VCA72, 93, 97, & More...
Code	GR1219




## SHARP MID DRIVE MASTER CAM

Original	NGERH1217GE00
Part No	
Suit	VCA36X ,VCA50X and others.
Code	MCG1217




## SHARP MID DRIVE MASTER CAM

Original	NGERH1218GE00
Part No	
Suit	VCA36X VCA50X and others.
Code	GR2180




## SHARP MECHANISM

Original	CCHSS0018GE02
Part No	
Suit	VCA35X etc.
Code	CH0018




## SHARP ARM

Original	MARMP0032GEZZ
Part No	
Suit	600 series.
Code	ARM32




## SHARP LEVER

Original	MLEVP0195GEZZ ,MLEVP0133GEZZ
Part No	
Suit	VCA101, 103, 111, VCD805, VCH80X, etc.
Code	LEV0195




## SHARP LOADING ARM

Original	MLEVF0420GEZZ
Part No	
Suit	VCA35X, 36X VCA50X, etc.
Code	LEV0420




## SHARP LOADING ARM

Original	MLEVF0422GEZZ
Part No	
Suit	VCA35X, 36X VCA50X, etc.
Code	LEV0422




## SHARP WORM WHEEL

From cassette housing Right	
Original	NGERW1033GEZZ
Part No	
Suit	VCA111 VCF18
Code	GR1033



## SHARP LOADING GEAR

Original	NGERH1121GEZZ
Part No	
Code	GR1121






# Video Repair Parts


## SHARP CLUTCH MID-DRIVE

Original Part No	NGERH1221AJZZ
Suit	VCA36X ,VCA50X and others.
Code	GR1221




## SHARP REEL PULLEY MID-DRIVE

Original Part No	NPLYV0147AJZZ
Suit	VCA36X, VCA50X, and others.
Code	VIA1470



## SHARP PLAYBACK GEAR

Original Part No	NGERH1224AJZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1224




## SHARP CASS HOUSE MID-DRIVE

Original Part No	NGERH1225GEZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1225




## SHARP SLIDER HOLDER RIGHT

Original Part No	LHLDX1010GEOO, LHLDX1012GEOO
Suit	VCA111, VCF18
Code	LDX1010




## SHARP SLIDER HOLDER LEFT

Original Part No	LHLDX1011GEZZ
Equiv.	LHLDX1013GEZZ
Suit	VCF18, VCA111
Code	LDX1011




## SHARP SLIDE PLATE

Original Part No	MSLIF0043GEZZ
Suit	VCA111X
Code	PS0043




## SHARP FRAME (R) MID-DRIVE

Original Part No	LHLDX1025GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1025




## SHARP FRAME (L) MID-DRIVE

Original Part No	LHLDX1024GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1024




## SHARP SLIDER MID-DRIVE

Original Part No	LHLDX1026GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1026




## SHARP GEAR MID-DRIVE

Original Part No	NGERH1226GEOO
Suit	VCA36X, VCA50X, and others.
Code	GR1226




## SHARP CLEANING ROLLER

Original Part No	CLEVP0239GEOO, CLEVP0239AJOO
Suit	VCA36X, VCA50X, and others.
Code	LEV0239




## SHARP MID-DRIVE

Original Part No	NGERH1227GEZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1227



## SHARP LOAD GEAR - SUPPLY


Original Part No	NGERH1220AJZZ
Suit	VCA36, 37, 41, 50, 53, VCA53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	GR1220






## SHARP OPEN LEVER

Original Part No	MLEVP0238AJZZ
Suit	VCA36, 37, 41, 50, 53, VCA53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0238



## SHARP CLUTCH LEVER

Original Part No	MLEVP0240AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0240




## SHARP ARM BRAKE - SUPPLY

Original Part No	MLEVP0244AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0244




## SHARP ARM BRAKE - TAKE-UP

Original Part No	MLEVP0242AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0242




## SHARP SLOW BRAKE

Original Part No	MLEVP0250AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0250




## SHARP PINCH DRIVE CAM

Original Part No	NGERH1216AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	GR1216




## SHARP LOCK LEVER - TAKE-UP

Original Part No	MLEVP0249AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0249




## SHARP SHIFTER

Original Part No	MSLIP0006AJZZ
Suit	VCA36, 37, 41, 50, 53, VCA53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	MSLIP0006




## SHARP CLUTCH CONNECT ARM

Original Part No	MLEVP0241AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0241



## SHARP REEL DISK

Original Part No	NDAIV1065AJOO
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	RD1065




## SHARP DRIVE LEVER

Original Part No	MLEVF0419AJZZ
Suit	VCA36, 37, 41, 50, 53, VC A53, 62, 63, 67, 72, VCH 93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0419




## SHARP MID-DRIVE HOUSE LEFT

Original Part No	LHLDX1027GEZZ
Suit	VCA36X, etc....
Code	LDX1027




## SHARP MID-DRIVE GEAR

Original Part No	NGERW1052GEZZ
Suit	VCA36X, etc.
Code	GR1052



## SHARP MID-DRIVE ARM

Original Part No	MARMP0053GEZZ
Suit	VCA36X, etc.
Code	ARM53






# Video Repair Parts


## SHARP POLE BASE - SUPPLY

Original Part No	LPOLM0050GEZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	SPB0050




## SHARP POLE BASE - TAKE-UP

Original Part No	LPOLM0051GEZZ
Suit	VCA36,37,41,50,53, VCA53,62,63,67,72 ,VCH93,94,97,98,V CMH83, 93,VT3428, 5128
Code	TPB0051




## SHARP GEAR

Original Part No	NGERH1196GEZZ
Suit	VCH91X VT3418 VT5118
Code	GR1196



## SHARP GEAR

Original Part No	NGERH1280GEZZ
Code	GR1280




## SHARP BREAK LEVER

Original Part No	MLEVP0279AJZZ
Suit	VCA200
Code	LEV0279




## SHARP BREAK LEVER

Original Part No	MLEVP0280AJZZ
Suit	VCA200
Code	LEV0280



## SHARP PULLEY

Original Part No	NPLYY0163GEZZ
Suit	VCA220, 270, VCA420, 470.
Code	PLY0163




## SHARP IDLER

Original Part No	NIDR0015AJZZ NIDR0015GEZZ
Suit	VCA200, 250,VCA400, 460. VCH600, 650,VT3448, 5148
Code	GIA0015



## SHARP IDLER

Original Part No	NIDR0018AJZZ NIDR0018GEZZ
Suit	VCA220, 270,VCA420, 470.
Code	GIA0018




## SHARP LEVER

Original Part No	MLEVP0301GEZZ
Suit	VCA220, 270,VCA420, 470.
Code	LEV0301




## SHARP SLIDE PLATE

Original Part No	MSLIP0010AJZZ MSLIP0010GEZZ
Suit	VCA220, 270,VCA420, 470.
Code	PS0010




## SHARP GEAR

Original Part No	NGERH1270GEZZ
Suit	VCA650
Code	GR1270




## SHARP GEAR

Original Part No	NGERH1271GEZZ
Suit	VCH650
Code	GR1271



## SHARP CASSETTE HOLDER


Original Part No	LHDX1031AJZZ
Suit	VCA200
Code	LDX1031






## SHARP CASSETTE HOLDER

Original Part No	LHLDX1030AJZZ
Suit	VCA200, 250,VCA400, 450,VCA600, 650.
Code	LDX1030




## SHARP HOUSING PANEL

Original Part No	LHLDX1028AJZZ
Suit	VCA650
Code	LDX1028




## SHARP CAM LEVER

Original Part No	MLEVP0237GEZZ
Suit	VCA36, 41, 50, 53,VCA62, 66, 67, 72,VCH83, 93, 94, 97,VCMH80, 83, 93,VT3428, 5128, etc.
Code	LEV0237




## SHARP BRAKE TAKE-UP

Original Part No	series videos MLEVP0128GEZZ
Suit	Suit most VCA, VCB, VCD, VCH,VCS, VCT, and VR, VT
Code	LEV0128



## SHARP BRAKE SUPPLY

Original Part No	series videos MLEVP0129GEZZ
Suit	Suit most VCA, VCB, VCD, VCH,VCS, VCT, and VR, VT
Code	LEV0129




## SHARP MASTER CAM GEAR

Original Part No	NGER1295AJ00
Suit	VCA240, 290,VCA490, etc.
Code	GR1295




## SHARP PULLEY

Original Part No	NPLYV0162GEZZ
Suit	VCA220, 470,VCA550, etc.VCH680, 705,VCH800, etc.
Code	PLY0162



## SHARP LEVER

Original Part No	MLEVP0336AJZZ
Suit	VCA220, 470,VCA550, etc.VCH680, 705,VCH800, etc.
Code	LEV0336



## □ Sony


### SONY

Very early VHS Models were manufactured by Sanyo.




## SONY ARM ASSEMBLY

Original Part No	X3727-776-1 X3749-173-4
Suit	SLV215,353 SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	GIA7761




## SONY GEAR

Original Part No	3-736-116-01
Suit	SLV215,353 SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	GR1601




## SONY CAM GEAR

Original Part No	3-736-143-01
Suit	SLV215,353 SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	GR4301



## SONY PRESS CAM

Original Part No	3-736-135-01
Suit	SLV353,757,SLVX30,X50,
Code	GR3501






# Video Repair Parts


## SONY GEAR

Original Part No	3-943-700-01
Suit	SLV215,SLVX35,X55,SLVX810,etc.
Code	GR7701




## SONY PULLEY

Original Part No	X3727-782-1
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR7821




## SONY WHEEL WORM

Original Part No	3-736-015-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR1501




## SONY GEAR

Original Part No	X3727-795-1
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR7951




## SONY CAM GEAR

Original Part No	3-736-170-01 3-736-170-03
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR7001




## SONY CLEANING ROLLER

Original Part No	A6747-264-A A6747-267-A
Suit	SLVX30. SLV215, 777,SLVX50, 810,etc.
Code	ARM264 ARM267



## SONY CAM GEAR

Original Part No	3-736-176-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	MCG7601




## SONY CAM ELEVATOR

Original Part No	3-952-182-01,3-736-136-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR8201




## SONY CAM GEAR

Original Part No	3-733-394-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR3940




## SONY STOPPER

Original Part No	3-736-111-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	STP1101




## SONY GEAR RIGHT THREADING

Original Part No	3-736-148-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR4801




## SONY ARM BLOCK

Original Part No	A6759074P
Code	GR5074




## SONY GEAR

Original Part No	3-736-147-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR1470



## SONY CHASSIS BLOCK

Original Part No	A6739-084-A
Suit	SLVX55
Code	MEC9804






## SONY PLATE SLIDE MODE

Original Part No	3-736-177-01
Suit	SLV215,353,SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	PSM7701



## SONY ARM TENSION REGULATOR

Original Part No	3-736-142-01
Suit	SLV757
Code	ARM4201




## SONY ARM

Original Part No	373614001
Suit	SLV757,SLVX811
Code	ARM4001




## SONY LOAD GEAR

Original Part No	3-946-922-01
Suit	SLVX37,SLVX57.
Code	GR2201



## SONY MECH

The following parts are from SONY mechanism to suit SLV7000, SLVT2000 SLVX315, 317, 325,SLVX327, 335, 425,SLVX427, 515, 517,SLVX522, 525, 527,SLVX825, 835, and maybe more we are unaware of!




## SONY ROLLER ASSEMBLY [CLEANER]

Original Part No	Sony X-3944-363-1
Suit	SLV7000,SLVK872, SLVT2000,SLVX31 2,SLVX315...842
Code	RL3631



## SONY REEL DRIVE ASSEMBLY

Original Part No	A-6739-102-A
Suit	SLV, SLVT,SLVX Series
Code	GIA9102




## SONY ELEVATOR CAM

Original Part No	3-958-151-01
Suit	SLV, SLVT,SLVX Series
Code	CAM5101



## SONY WORM WHEEL

Original Part No	3-958-157-01
Suit	SLV, SLVT,SLVX Series
Code	GR7010




## SONY GEAR

Original Part No	3-958-152-01
Suit	SLV, SLVT,SLVX Series
Code	GR5201




## SONY LOAD GEAR SUPPLY

Original Part No	3-958-476-01
Suit	SLV, SLVT,SLVX Series
Code	GR7601




## SONY GEAR PRESS

Original Part No	3-958-153-01
Suit	SLV, SLVT,SLVX Series
Code	GR5301



## SONY LOAD GEAR TAKE-UP\*

Original Part No	3-958-485-01,3- 958-485-02
Suit	SLV, SLVT,SLVX Series
Code	GR8502



## SONY GEAR\*

Original Part No	3-958-162-01,3- 958-162-02
Suit	SLV, SLVT,SLVX Series
Code	GR6202






# Video Repair Parts

## SONY PLATE SLIDE MODE\*

Original	3-958-163-04,
Part No	3-958-163-01
Suit	SLV, SLVT, SLVX Series
Code	LEV6304



## SONY CAM GEAR (OLD)

Suits OLD FRONT LOAD DRIVE GEAR (No Longer Available from Sony.) See KIT5602 Below if replacing both cam and gear, etc.

Original	3-958-161-01,
Part No	3-958-161-04
Code	CAM6104



## SONY FRONT LOAD DRIVE GEAR KIT\*\*

3-958-156-02 Gear Sony Is no longer available! Sony recommends 'Must use this kit to avoid "No tape loading or eject" problem when replacing GR5603' \*Includes gears & slide plate.


Suit	SLV, T, X Series, etc.
Code	KIT5602



## SONY FRONT LOAD DRIVE GEAR (NEW)\*


Original	3-958-156-01,
Part No	3-958-156-03
Suit	SLV, SLVT, SLVX Series
Code	GR5603

Use only with CAM6107  
(See info KIT5602 above!)



## SONY CAM GEAR (NEW)\*


Original	3-958-161-07
Part No	
Suit	SLV, SLVT, SLVX Series
Code	CAM6107



Use only with GR5603  
(See info KIT5602 above!)

## SONY SWITCH MODE


Original	1-413-896-21	1-413-897-11
Part No		
Code	PS9621	PSM9711



## SONY POWER SUPPLY


1-413-621-11  
Complete module  
from power cord to  
Connection sockets

Suit	SLV777
Code	PSM2111



## SONY CENTRE GEAR

Suit	SLVED225 825, 925, 929, SLZEZ121, 424, 727, etc.
Code	GRC2058



## SONY ARM OPEN LID

Original	397751401
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	ARM1401



## SONY PINCH PRESS GEAR

Original	397744101
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4103




## SONY TG8 DRIVE GEAR

Original	397744501, , New,
Part No	397744103
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4502



## SONY TG8 SUPPLY GEAR

Original	397744601
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4601



## SONY CLEANING ROLLER

Original	X39472551
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	RL2551





## SONY LOAD GEAR TAKE-UP

Original Part No	397745501, 397745502, NEW, 397745503
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5503



## SONY LOAD GEAR SUPPLY

Original Part No	397745101
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5501




## SONY GEAR ASSEMBLY & PULLEY

Original Part No	X397745101
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5851



## SONY LOAD SLIDE GEAR

Original Part No	397744201, 397744202, 397744203
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4202




## SONY REEL DIRECT GEAR

Original Part No	X39475841
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5841



## SONY CAMCORDER REEL [T]

Original Part No	X-3727-951-9
Suit	CCD-V888E and others. Take-Up reel clutch assembly.
Code	RT9519



## □ Toshiba

### TOSHIBA IDLER

Original Part No	70326538
Code	VIA820



## □ Teac / Philips


### TEAC / PALSONIC / FUNAI / GOLDSTAR / LG

Rebadging technology  
AND NOW PHILIPS



## PHILIPS TEAC GEAR KIT

Original Part No	4822 3101 0657
Suit	MV7, 77, 777, RTV250, 256, 350, RTV356, 725, 785, VR9489.
Code	GR10657



## TEAC/PHILIPS VCR SERVICE KIT-i

Original Part No	4822-310-31963
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	ES7118



## TEAC/PHILIPS VCR SERVICE KIT-b

Original Part No	4822-310-31955
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	ES7111



## TEAC/PHILIPS CLEANING ROLLER

Original Part No	4822-528-70773
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	RL7730





# Video Repair Parts

## Cassette Housings


### Akai

#### AKAI CASSETTE LOAD ASSEMBLY

Original Part No BV-V1102A150A

Suit VS422, VS425, VS765, VSA650, VSF10, VSF11, VSF12, VSF650, etc.

Code CH1102



## Daewoo / Tempest

#### DAEWOO TEMPEST CASSETTE HOUSING

Original Part No 97SA104100, 97SA104110

Suit DVR6158, VCR32, 52, VCR8025, TE970R, 99R.

Code CH8025



## Funai / Teac / Palsonic

#### FUNAI TEAC PALSONIC CASSETTE HOUSING

Original Part No 62D806516301

Suit MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688

Code CH6301




## LG / Goldstar

#### GOLDSTAR CASSETTE HOUSING

Original Part No 219-011A, 219-004A

Suit AV62, GHV1241, 46, 47, GHV51, KBV9012, M22, VCR7000, VR1500, etc.

Code CH9011




#### GOLDSTAR CASSETTE HOUSING

Original Part No 219-015B, 219-010B

Suit AV65, GHV1290, 91, 92, 93, GHV1392, 93, 1910, VCP4200, 4300, VCP4305, 4306.

Code CH9015




#### GOLDSTAR CASSETTE HOUSING

Original Part No 219-017B, 219A017F

Suit AV66, RG20

Code CH2190




## JVC / Philips

#### JVC CASSETTE HOUSING

Suit HRD540, 580, 920, HRDX20, 42, VR3241, etc.


Code PUS29499B



## JVC CASSETTE HOUSING

Suit HRD520EA, HRDX22

Code PUS29499C, PUS29499E



## JVC CASSETTE HOUSING

Suit HRD640, 910, HRJ200, 400.

Code PUS29499D, PUS29672A-5




## JVC CASSETTE HOUSING

Suit HRJ600

Equiv. PUS29662A4

Code PUS29662C1




## JVC CASSETTE HOUSING

Original Part No PUS26805U

Suit HRD140, 141, 142, HRD143, 150, 250, HRD455, 565, 566, HRD725, 755 and NEC N895.

Code CH2681




## JVC CASSETTE HOUSING

Original Part No PUS26805Q

Suit HRD110, 111, 120, HRD121, 220, 225, RV360, 370, GE8100, 9300, N830/1/3

Code CH2680




## JVC CASSETTE HOUSING

Suit HRD170, 180, HRD160, 200,

190,etc. HRD217, 530..

Code PUS28277F, PUS28277H




## JVC CASSETTE HOUSING

Original Part No PUS25908D-101

Suit HR2200, HR2650


Code PUS25908






## JVC CASSETTE HOLDER

Suit HR7700  
Code PU20934A



## JVC CASSETTE HOUSING

Suit HRJ220, 221,  
HRJ625, etc.  
Code PUS29724C-1



### Mitsubishi

## MITSUBISHI CASSETTE HOLDER

Bottom Unit.

Suit HS521, 621,  
HS640, 7424.  
Code CH1030



## MITSUBISHI CASSETTE HOUSING


Original Part No	590A256020
Suit	HSE11, HSM33, 57, HSM58, 68, HSM1000, HSMX1, X2.
Code	CH5602



### Panasonic

## PANASONIC HOUSING

Suit NVG10 etc.  
Equiv. VXA2562  
Code VXA2450




## PANASONIC DOOR KIT

Original Part No	VKF0225 & Spring VMB1171
Suit	NV370, NV600, NV788, NV850, etc.
Equiv.	VFK0225, VFK0266, VFK0335, VFK0336, VFK1715, etc.
Code	VXA1806



## PANASONIC CASSETTE HOLDER


Suit	NVSD10, 20, 30	NVF65, 66, 70, 90
Equiv.		VXA3832
Code	VXA4661	VXA3840



## PANASONIC SIDE PLATE


Includes opener  
lever VXL2250

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXA4660



## PANASONIC SIDE PLATE

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXA4806




## PANASONIC SHAFT ASSEMBLY

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1339




## PANASONIC SIDE PLATE

Suit	NVL20, 25, NVG25, 28, NVJ45, etc. 'G' Mech 'G' Mech
Type	6 Pin 2+5 Pin 6+4 Pin
Code	VXA4076 VXA3015 VXA4468



## PANASONIC SHAFT

Suit	NVG33, NVH75, etc.
Equiv.	VXP0987
Code	VXP0851



### Samsung


## SAMSUNG CASSETTE HOUSING

Original Part No	61227004705
Suit	VB520, 900, Akai VS200, Tempest TE900H
Code	CH0900



## SAMSUNG CASSETTE HOUSING

Original Part No	62052-0004-02
Suit	VB300, VB370, VB3260, etc.
Code	CH4020






# Video Repair Parts

## □ Sanyo

### SANYO CASSETTE HOUSING

Original Part No	613-152-0578
Suit	VHR510, 530, VHR630, 650.
Code	CH2057



### SANYO CASSETTE HOUSING

Original Part No	613 125 4862, 613 125 5487
Suit	SRT500, TLS1500, TLS900, 974.
Code	CH4862



## □ Sharp


### SHARP CASSETTE HOLDER

Original Part No	LHLDX3016GEZZ
Suit	VC581, etc.
Code	CH3016




### SHARP HOUSING ASSEMBLY

Original Part No	CHLDX3039
Suit	VC45, VCA101, VCH851
Code	CH3039



### SHARP CASSETTE HOUSING


Description	Without Cass' In SW	With Cass' In SW
Original Part No	CHLDX3050GE00	CHLDX3051GE00
Code	CH3050	CH3051



### SHARP CASSETTE HOUSING


Original Part No	CHLDX3052GE51/53	CHLDX3066GE58
Suit	VC-H91, B20, B60	

CH3052                    CH3066



### SHARP CASSETTE HOUSING

Original Part No	CHLDX3071GE02
Suit	VCA36, 37, 41, VCA50, 53, 62, VCA67, 72, 93, VCA94, 97, 98, inc. 'X' series.
Code	CH3071



## SHARP CASSETTE HOUSING


Original Part No	CHLDX3081TEV2
Suit	VCA220, 270, VCA420, 470.
Code	CH3081



## □ Sony


### SONY CASSETTE HOUSING

Original Part No	A6751-421-A
Suit	SLVX30, 50, 810, etc.
Code	CH1421




### SONY CASSETTE HOUSING

Original Part No	A6751-445-A, A6751-455-A, A6751-455-G
Suit	SLVX55, 710.
Code	CH1445



### SONY CASSETTE HOUSING

Original Part No	A6751-426-A	A6751-453-A
Suit	SLV777	SLV215, 353, etc.
Code	CH1426	CH1453




### SONY CASSETTE HOUSING

Original Part No	A6751496A, A6759603A, A6759623A, A6775357A
Suit	SLVX812, SLVX822



### SONY CASSETTE HOUSING

Original Part No	A6759619B, New A6759619C
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	CH9619





## Tension Bands


### Akai

#### VIDEO TENSION BANDS




#### AKAI TENSION BAND

Original	VT328134
Part No	
Suit	VS3, etc.
Code	TB3281




#### AKAI TENSION BAND

Original	ML500881
Part No	
Suit	VS22, 23, 25, 35, 37, 38, 53, 55, 66, 75
Code	TB5008




#### AKAI TENSION BAND

Original	BLB360350
Part No	
Suit	VS112, VS165, 505
Code	TB3603




#### AKAI TENSION BAND

Original	BVB35237
Part No	
Suit	VS303, 603, VS606, 607, etc.
Code	TB2377




#### AKAI TENSION BAND

Original	MZ420016N2
Part No	
Suit	VSG204,...212, VSG405, 511, VSG2100, etc.
Code	TB4200



#### AKAI TENSION BLOCK


Original	BL4335386
Part No	
Suit	VSG280, VSG2DPL, VSG765, 790, 875.
Code	ARM5386



## Funai / Teac / Palsonic

#### FUNAI TENSION BAND

Original	8059-08-302
Part No	
Suit	MV435, 445, VX2000, etc.
Code	TB8302



#### FUNAI TEAC PALSONIC TENSION BAND

Original	62D806508303
Part No	
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	TB8303




#### FUNAI TEAC TENSION BAND

Original	OVSA08816
Part No	
Suit	MV3420, MV4820.
Code	TB8816



#### FUNAI TEAC TENSION BAND


Original	OVSA-04658
Part No	
Suit	MV3410, MV4810T
Code	TB4658



## LG / Goldstar


#### GOLDSTAR TENSION BAND

Original	328-017B
Part No	
Code	TB8017




#### GOLDSTAR TENSION BAND

Original	328-033B
Part No	
Code	TB8033



#### GOLDSTAR / NEC TENSION BAND

Original	333-329A, 328-075A, NEC 79VG0998,VN36
Part No	
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	TB3329



#### GOLDSTAR / LG TENSION BAND

Original	4770R-0004A
Part No	
Suit	VSJ200, 215, 411, VSJ700, 711, 716. LG AF293, 493, 993, AC250, 450, 950.
Code	TB0004






# Video Repair Parts

## □ Hitachi

### HITACHI TENSION BAND


Original 7413665  
Part No  
Suit VTF778E  
Code TB3665



## □ JVC


### JVC TENSION BAND

Suit HRD170,180,  
210,217,300,321,  
370,400,440,441,  
470,500,530,700,  
HRS5000,9000 etc.  
Code PQ41948A




### JVC TENSION BAND

Suit HRD140,141,  
142,143,150,152,  
156,157,160,250,  
257,565,566,755,  
Code PQ41370B




### JVC TENSION BAND

Suit HRD520,521, 540,580,600,  
610,620,830,  
Code PQ43501




### JVC TENSION BAND

Equiv. PQ44734A-1  
Suit HRD640, HRD910  
Code PQ45527A-1




### JVC TENSION BAND

Suit HR7200,7300,7600,7650,  
HRD110,111,120,121,225,  
HV4000,8000,VCR1500,  
N830,831,833,  
RV340,350,360,370.  
Code PU51390A




## JVC TENSION BAND

Suit HR3300,3330,  
3660,3600,4100,  
HV1000,2000,3000,  
RV300,310,320,  
Code PUS45904A




## JVC TENSION BAND

Suit HRD455,725 NEC  
N895 TOSHIBA V63  
Code PQ40262E




## JVC TENSION BAND

Suit HR2200, HR2650  
Code PU48784B




## JVC TENSION BAND

Suit HRC3  
Code PU52993A




## JVC TENSION BAND

Original PQ46298A-3,  
Part No PQ46298A-5  
Suit HRJ220, HRJ221,  
HRJ625  
Code PQ46298



## JVC TENSION BAND


Suit HRJ600  
Code PQ34629A-3



## □ Mitsubishi

### MITSUBISHI TENSION BAND


Original 591B552010  
Part No  
Suit HSJ11,41, HSMX1,2  
Code TB2010






## MITSUBISHI TENSION BAND

Original Part No	614B62402, 614B624020
Suit	HSM50,X3, HSMX5,X7, HSMX10,20.
Code	TB2402



## MITSUBISHI TENSION BAND


Original Part No	621C557010
Suit	HS521, 621, HS640, 7424.
Code	TB7010



## □ NEC


### NEC TENSION BAND

Original Part No	16183551
Suit	DX1600,2000, DX3000,9053, DX9055,9066
Code	TB3551




### NEC TENSION BAND

Original Part No	16177851
Suit	DX9012,9014, DX9016,9033,
Code	TB7851




### NEC TENSION BAND

Original Part No	16188802
Suit	N9402A
Code	TB8802



### NEC TENSION BAND


Original Part No	79TD3959, DaeWoo
Suit	97SB382900
Code	TB2900



## □ Panasonic

### PANASONIC TENSION BAND

Suit	NV7000,7200, NV7500 and BLAUPUNKT RTV222
Code	VXZ0078




## PANASONIC TENSION BAND

Suit	NV300, 600, NV777, etc. AG6200, RTV321.
Code	VXZ0129




## PANASONIC TENSION BAND

Suit	NV250 etc. NV-G10 etc.
Code	VXZ0165




## PANASONIC TENSION BAND

Suit	NVG20, etc.
Code	VXZ0267




## PANASONIC TENSION BAND

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXZ0310



## PANASONIC TENSION BAND

Original Part No	VXL2671, VXL2793
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2671



## □ Samsung


### SAMSUNG TENSION BAND

Original Part No	6202 400 0501
Suit	VB300, VB370 & More.
Code	TB5001



## SAMSUNG TENSION BAND

Original Part No	61543-0071-00V
Suit	SV10,11,12, SV30,80,140
Code	TB7100






# Video Repair Parts

## Sanyo


### SANYO TENSION BAND

Original 143-0-711T  
Part No  
Suit VHR110, 13  
Code TB2000




### SANYO TENSION BAND

Original 613-160-5282  
Part No  
Suit VHR510, 530, VHR590,  
610, VHR630, 650  
Code TB5282




### SANYO TENSION BAND

Original 613-021-9701  
Part No  
Suit VHR4100,etc.  
Code TB9701




### SANYO TENSION BAND

Original 1430711T02101, Also  
1430711T02100, Also  
613-037-5377  
Part No  
Suit VHR3300, D500,etc.  
Code TB2101




### SANYO TENSION BAND

Original 143-2-5204-01500  
Part No  
Suit FVH-P620, 710,etc.  
Code TB1500




### SANYO TENSION BAND

Original 1430711T02021  
Part No  
Suit VHR2100, VHR2300,  
VHR2500, VHR2700, etc.  
Code TB2021



### SANYO TENSION BAND


Original 613-100-4573  
Part No  
Suit SRT500P, TLS900P,  
TLS924P, TLS2000,  
TLSS2500P  
Code TB4573



## Sharp


### SHARP TENSION BAND

Original LBNDK1002GEZZ.  
Part No  
Suit VCA10, 30, 60, 103,  
105, 106, 111, 505,  
605, D810, VCH80,  
VR6443, 6448,  
Code DK1002




### SHARP TENSION BAND

Original LBNDK3011GEZZ,  
Part No Philips 480240117243  
Code DK3011




### SHARP TENSION BAND

Original PBRKZ0003GEZZ,  
Part No LBNDK1001GEZZ  
Suit VC200X, 820X,  
600/700 series &  
Philips equiv.  
Code TB0003




### SHARP TENSION BAND

Original LBNDK3008GEZZ  
Part No  
Suit VC7300, VC7700, etc.  
Code DK3008




### SHARP TENSION BAND

Original LBNDK3014GEZZ,  
Part No 480240357605  
Suit 300, 400, 500, 6000  
and Philips  
Code DK3014




### SHARP TENSION BAND

Original VCA36, 37, 41,  
VCA50, 53, 62,  
VCA67, 72, VCH94,  
97, 98, VCMH38, H93.  
Part No  
Suit  
Code DK1008



### SHARP TENSION BAND


Original LBNDK1011AJZZ  
Part No  
Suit VCA220, 270,  
VCA420, 470.  
Code DK1011





## SHARP TENSION BAND


Original Part No	LBNDK1009GEZZ
Suit	VCH650X
Code	DK1009



### □ Sony

## SONY TENSION BAND

Original Part No	X3727-797-1
Suit	SLV215, 353, SLV757, 777, SLVX30, X50, SLVX810, etc
Code	TB7971




## SONY TENSION BAND

Original Part No	X-3943-886-1
Suit	SLVX812, SLVX822
Code	TB8861



## SONY TENSION BAND

Original Part No	X39475891
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	TB5891




### □ Mode Switches

### □ Akai

## VIDEO SWITCHES

FRONT PANEL SWITCHES  
CASSETTE-IN SWITCHES  
RECORD SWITCHES  
MODE SWITCHES  
ROTARY SWITCHES  
ROTARY ENCODERS  
SLIDE ENCODERS


**MORE AVAILABLE SEE:**  
<http://www.wes.com.au/>



## MICRO PUSH SWITCHES

Most videos use common types and some are brand specific. For our entire switch range see:


<http://www.wes.com.au/>



## AKAI PUSH SWITCH

Original Part No	ES349367
Suit	
Code	SW9367

Others see Section 10  
ELECTRONIC COMPONENTS




## AKAI SWITCH

Original Part No	ES-348089J1
Suit	VS4
Code	SW3480




## AKAI MODE SWITCH

Original Part No	VT372187, VT363354
Suit	VS112, 165, VS512, 515, VS516, etc.
Code	SW3721




## AKAI MODE SWITCH

Original Part No	ES387465J
Suit	VS422, 425, VS765, 965, VSA650, 1100, VSF10, G11, & MORE
Code	SW3874



## AKAI MODE SWITCH

Original Part No	ES353653A
Suit	VS202, 303, VS603, 606 VS607, etc.
Code	SW3536




## AKAI MODE SWITCH

Original Part No	ES-381310J1
Suit	VS22, 26, 35, VS53, 66, 75, VCA77, R8, etc.
Code	SW3813



## AKAI MODE SWITCH

Original Part No	ES433595, 047K120340-01
Suit	VSG280, VSG2DPL, VSG765, 790, 875.
Code	SW4001






# Video Repair Parts

## □ Deitron / Tempest / Tracton

### DIETRON / TEMPEST / TRACTON


Original Part No	5S30407011
Suit	TE99R, 970R, VCR32, 52, 8052, DVR6158D, etc.
Code	SW3040



## □ Funai / Teac


### FUNAI SWITCH ASSEMBLY

Original Part No	8059-16-320
Code	FU1620




### FUNAI LEAF SWITCH

Original Part No	6401-01-151
Code	SW1151



### FUNAI TEAC MODE SWITCH

8000-22-304, WA-03VO, 6 pin	
Suit	MV300, 400, MV430, 435, MV1400, 1440
Code	SW3105



### FUNAI TEAC MODE SWITCH


62D806513302 Board & connectors.

Suit	MV3010, 3030, MV3050, 4010, MV6010, etc, VCR9688, etc.
Code	SW3302



### FUNAI TEAC MODE SWITCH

Original Part No	SSR0104HD004
Suit	MV3420, MV4820.
Code	SW0004



### FUNAI TEAC MODE SWITCH

Original Part No	5S10104100
Suit	MV3094
Code	SW4100



## FUNAI TEAC MODE SWITCH


Original Part No	5SSF1DKM10, MMSS00320ZMB0
Suit	D284 D884, DVK10 224 424 824, MV3080 3092 4090, MV6080 6090 6092
Code	SW3200



## □ Goldstar


### GOLDSTAR MODE SWITCH

Original Part No	556-115A
Suit	VCP100, 101, VCP110, 115, VCP120, 126, KVP120, etc.
Code	SW6115




### GOLDSTAR MODE SWITCH

Original Part No	556-085A
Suit	GHV1290, 1295, GHV1910, 4300, GHV4310, 4320, AV64, etc.
Code	SW5560




### GOLDSTAR MODE SWITCH

Original Part No	556-055B
Suit	GHV1232, 1240, GHV1241, 1247, KBV9012, AV61/2, VCP4100, R7000, and more...
Code	SW6055



### GOLDSTAR MODE SWITCH

Original Part No	556-133A
Suit	AV66, RG20, and more...
Code	SW6133



### GOLDSTAR / NEC MODE SWITCH


Original Part No	556-252A & B, NEC 79VG1093 VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	SW6252



## □ Hitachi

### HITACHI MODE SWITCH


Original Part No	5625141
Suit	VT100, 110, VT111, 125, VT128, 138, VT150....
Code	SW5141






## HITACHI MODE SWITCH

Original Part No	5625061
Suit	VT11,14, VH600, VT9300,etc.
Code	SW5061



## HITACHI MODE SWITCH

Original Part No	5625091
Suit	VT17,19,33,34,35,38,52 ,63,330,640.
Code	SW5091



## JVC


## JVC SLIDE ENCODER

Suit	HRD170,171,180,210,230, HRD320,470,530.	Code	PU58642
	HRD227,380.		PU59924




## JVC SLIDE ENCODER

Suit	HRD300,337, HRD400,441, HRD700,750, HRS5000,5500, HRS9000,etc.
Code	PU60444



## JVC SLIDE ENCODER

Original Part No	PU60973-1-1
Suit	HRD540,580
Code	PU60973



## JVC SLIDE ENCODER

Suit	HRD520, 521, HRD830, 600, HRDX20, 22, HRJ200, etc.
Code	PU60622



## JVC SLIDE ENCODER

Original Part No	PU61247-1-1
Suit	HRD640, HRD790, HRD910
Code	PU61247




## JVC SLIDE ENCODER

Suit	HRJ600
Code	PU61322-1-2




## JVC ROTARY ENCODER

Suit	HRJ220, 221, HRJ625, etc.
Code	PU61432-1-1




## JVC / PHILIPS ROTARY ENCODER

Original Part No	QSW0554-02, 4822-273-10349
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	SW5402



## JVC RECORD PROTECT

Original Part No	PU60624-1-4, PU60624-1-5
Suit	HRDX20, VR3241/75
Code	PU60624



## LG

## LG MODE SWITCH

### AKAI SANYO GOLDSTAR

Original Part No	6600RPY001B
Suit	LG AC, AF, BC, SANYO VHR, NEC VN, VNG, AKAI VCJ, etc.
Code	SW6600



## Mitsubishi

## MITSUBISHI MODE SELECTOR

### GREY COG

Original Part No	439P011020
Suit	HS337,338, HS347,411, HS421,etc..
Code	SW1102





# Video Repair Parts

## MITSUBISHI MODE SWITCH


### GREEN COG

Original	439P011040
Part No	
Suit	HSE10, 20, 30
Code	SW1040




## NEC MODE SWITCH

Original	5SSFMDKM10, MMA0018OZBO, 79TD3598
Suit	VN23,26,64, AWA 2H20D, AWA 4H40D, etc
Code	SW3598



## MITSUBISHI MODE SWITCH


Original	439P007010
Part No	SWITCH ONLY
Code	SW7010



## MITSUBISHI MODE SWITCH KIT


COMPLETE KIT  
Manufacturer  
recommends:  
Replace one,  
Replace them all!

Original	439P007010
Part No	
Code	KT7010



## MITSUBISHI CASSETTE SWITCH


Original	439P00802
Part No	
Suit	AV12,51, 400, TR102, etc.
Code	SW8020



## MITSUBISHI MODE SWITCH

Original	439D03901, 439D039010, 439P03101/0
Part No	
Suit	HSM50,X3, HSMX5,X7, HSMX10, 20.


Code SW3901



## NEC


### NEC MODE SWITCH

Original	5S10407058
Part No	
Suit	VN20
Code	SW7058




## NEC MODE SWITCH

Original	79TD3895
Part No	
Suit	VN22, 25
Code	SW3895




## NATIONAL MODE SWITCH

Suit	NV300, 340, 600, 777, 788
Code	VSS0060




## NATIONAL MODE SWITCH

Suit	NV370,380,480,630, NV730,770,780,850.
Code	VSS0091




## NATIONAL MODE SWITCH

Suit	NVG7, 9, NVG10, 11, NVG12, 16,
Code	VSS0135



## NATIONAL MODE SWITCH


Suit	NV100
Code	VSS0061





## NATIONAL MODE SWITCH

Suit	NV250, 280, NV450, 470, NV870, etc.
Code	VSS0110



## NATIONAL MODE SWITCH


Suit	NVG20, 22, 25, 33, 40, 45 NVH65, H75, L20, L25, RTV560, 740, etc..
Code	VSS0175A EVQWXD001



### □ Panasonic


## PANASONIC MODE SWITCH

Suit	NVG30
Code	VES0327




## PANASONIC MODE SWITCH

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VSS0365



## PANASONIC MODE SWITCH

Original	VSS0520
Part No	
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VSS0520




## PANASONIC CASSETTE UP/DOWN SWITCH

Suit	NV300, 370, 600, 777, 788 etc.
Equiv.	VSM0046
Code	VSM0048



## PANASONIC SAFETY TAB SWITCH


Suit	NV300, 600, NV777, 788, etc.
Code	VSM0043



### □ Orion


## ORION MODE SWITCH

Original	0520244002
Part No	
Code	SW4002



## ORION MODE SWITCH

Original	0520244003
Part No	
Code	SW4003




### □ Samsung

## SAMSUNG/TEMPEST MODE SWITCH


Original	9000-221-4109
Part No	
Suit	VB627, VB629
Code	SW6900

This switch will substitute for a Samsung/Tempest mode switch used in VB900, VB2215B and TE900. With info.



## SAMSUNG MODE SWITCH

Original	63579-101-026
Part No	
Suit	VB1230
Code	SW1026



## SAMSUNG MODE SWITCH


Original	AC3420100A
Part No	
Suit	SV240B
Code	SW0100



### □ Sanyo


## SANYO/FISHER MODE SWITCH

Original	4-2314-00251, Also 621-006-
Part No	4030
Suit	FVH-P series.
Code	SW4030



## SANYO MODE SWITCH

Original	645-007-1560
Part No	
Suit	VHR510, 530, VHR590, 610, VHR630, 650
Code	SW1560






# Video Repair Parts


## SANYO MODE SWITCH

Original 613-110-0374,  
Part No 613-077-4361  
Suit VHR4100,5700,  
Code SW4361




## SANYO/FISHER MODE SWITCH

Original 610 064 783, Also  
Part No 4 231V 86200  
Suit VHR1100,  
VHR1300,  
VHR1500  
Code SW6200




## SANYO/FISHER MODE SWITCH

Original 4-231V-86500,  
Part No Also 613-006-4820  
Suit VHR2500  
Code SW4820




## SANYO/FISHER MODE SWITCH

Original 4-231V-87400,  
Part No Also 613-006-4936  
Suit VHR3500,  
VHR3700,etc.  
Code SW4936



## SANYO REC SAFETY SWITCH


Original 4-231V-8700  
Part No  
Suit VHR3100 etc.  
Code SW8700



## □ Sharp


## SHARP MODE SWITCH

Original QSW-R0014GEZZ  
Part No  
Suit VC581, VR6441.  
Code QSWR0014




## SHARP MODE SWITCH

Original QSW-R0019GEZZ  
Part No  
Suit VCA502, VCH851,  
etc.  
Code QSWR0019




## SHARP MODE SWITCH

Original QSW-R0026GEZZ  
Part No  
Suit VCA30, 35,  
VCA115, 125.  
Code QSWR0026



## SHARP CASSETTE IN SWITCH


Original QSW-F0004GEZZ  
Part No  
Suit 300/9000 series.  
Code QSWF0004



## SHARP SWITCH


Suit many models.

Original QSWF0011GEZZ  
Part No  
Code QSWF0011




## SHARP CASSETTE IN SWITCH

Original QSW-F0021GEZZ  
Part No  
Suit DAEWOO,  
DEITRON,  
TEMPEST.  
Code QSWF0021




## SHARP LEAF SWITCH

Original QSW-F0023GEZZ  
Part No  
Suit VC51B  
Code QSWF0023




## SHARP REC SAFETY SWITCH

Original QSWF0034GEZZ  
Part No  
Suit VCA10,34,40,49,  
VCA105,125,  
VCB20,60,H91,  
VR3360,6349,  
VT3480,etc.  
Code QSWF0034



## SHARP SWITCH


Original QSWR0034GEZZ  
Part No  
Suit VCH88, 91, 95,  
VT3418, 5118.  
Code QSWR0034






## SHARP MODE SWITCH

Original Part No	QSWR0008GEZZ, QSWR0010GEZZ, 480227617213
Suit	MV640, 740, VC5F3, VC383, 481, 584, 9300, VR401, 6840, VRD012
Code	QSWR0010




## SHARP MODE SWITCH

Suit	VC651, 682, 6V3, 6442, VR6520, 6542.
Code	QSWR0017




## SHARP MODE SWITCH

Original Part No	QSWR0023GEZZ
Suit	VC780, 790, VCA105, A111, VCA505, D805, VCH855, ...
Code	QSWR0023




## SHARP MODE SWITCH

Original Part No	QSW-S0032GEZZ
Suit	VC381, 386, VC388, 390, VC9300, VR501, 601, VRD022, etc...
Code	QSWS0032




## SHARP CASSETTE-IN SWITCH

Original Part No	QSWF0010GEZZ
Suit	MP121, MV740, VC387, 482, 581, ... VC4842, 8482, VR6440, 6641, VR6840, 6937
Code	QSWF0010



## SHARP SWITCH

Original Part No	QSW-F0013GEZZ
Suit	VC381, 383, 390, VR501, 601, 701, and more
Equiv.	QSW-M0014GEZZ, QSW- M0019GEZZ
Code	QSWF0013




## SHARP ROCKER SWITCH

Original Part No	QSW-F0022GEZZ
Suit	VC200, 500, 651, VC682, 6F3, 779, VC785, 787, 793, VCA101, 103, 502, VR6443, 6543, etc.
Code	QSWF0022




## SHARP LEAF SWITCH

Original Part No	QSW-F0024GEZZ
Suit	VC51B, VCA101, VR6443, More.
Code	QSWF0024



## SHARP SWITCH


Suit	14VT10X, VCA10, 30, 40, 60, VCA105, 115, 125, VCB20, 60, D810, VCH80, 855, S1000, VR3360, 6448, etc..
Code	QSWF0040



## SHARP CASSETTE SWITCH AND PCB

Complete PCB, switch  
and components, etc.


Original Part No	Old QSW-F0035GEZZ, New DUNTK3194HE00
Suit	VCA111X and others.
Code	KT3194



## □ Sony

### SONY MODE SWITCH

Original Part No	1-692-062-11
Suit	SLV715, SLV810*, SLV811, SLV815
Code	SW2012




### SONY MODE SWITCH

Original Part No	177115511
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	SW5511




### SONY MODE SWITCH

Original Part No	1-762-490-11, 1-762-076-11
Suit	SLVX812, SLVX822
Code	SW9011



### SONY FACIA ROTARY SWITCH

FF/REW Rotary PLAY/STOP Push	1-572-662-11
Original Part No	SLVF10,
Suit	SLVX810
Code	SW6211





# Video Repair Parts

## Mode Sensors

## Universal Lamps

### VCR SENSING LAMP

Volts	Code
6	SL74-6
12	SL74-12



### VCR SENSING LAMP

Suit older units

Volts	Code
12	SL79-12
6	SL79-6



## JVC

### JVC SENSING LAMP

Suit HR7200 etc.  
30cm lead.6  
volt,70mA. 4mm  
Diam.

Code	SL15
------	------



### JVC SENSING LAMP

As SL15  
Including Plug.  
20cm blue lead.

Code	SL25
------	------



## Akai

### AKAI SENSING LAMP

VS1, 2, 3, 4, 5 etc.  
12V 60mA. 50cm  
lead.


Code	SL40
------	------



### AKAI LAMP & HOLDER

Same as SL40

Code	SL42
------	------



## Sharp

### SHARP SENSING LAMP

300 & 900 series 5V,  
110mA, 18cm lead.


Code	SL50
------	------



### SHARP LAMP & HOLDER

As SL50

Code	SL52
------	------



## LG / Goldstar

### GOLDSTAR SENSOR

Suits many models  
and many brands.

Original	513-194D
Part No	
Code	LN3194




## JVC

### JVC REEL SENSOR



Original	JVC PU61433, Philips Part No 4822 2099 0487
Suit	HRJ220, 425, 635, HRS9400, RV455,
Code	PU61433
	VR155, 255, 257, VR357, 455, 755,

### JVC PHOTO DIODE



Original	HRD540,
Suit	860, X20, etc...
Code	PU60625

### JVC SENSOR



Original	JVC HR-D725,
Part No	NEC N895
Code	PU55827

### JVC SENSOR



Original	PU57650-1-1
Part No	
Suit	HR-D160, 275, 755, etc.
Code	PU57650

### JVC REEL SENSOR



Suit	HRD540, 580, HRDX20, etc.
Code	PS5705

### JVC REEL SENSOR



Suit	HRD170, 180, 530
Code	PU60271
	HRD520, etc.

Suit	HRD520, etc.
Code	PU60271

Suit	HRD520, etc.
Code	PU60271

### JVC SENSOR



Suit	HR-D300, etc.
Code	PU58879

## Sharp

### SHARP PHOTO DIODE

Original	RH-PX0039GEZZ
Part No	
Code	PX0039



### SHARP SENSOR

Original	RH-PX0042GEZZ
Part No	
Code	PX0042



### SHARP CASSETTE SENSOR

Original	RH-PX0169GEZZ, RH-PX0180GEZZ
Part No	
Code	PX0180



### SHARP IR SENSOR

Original	RHPX0176GEZZ, RHPX0053GEZZ
Part No	
Code	PX0176



### SHARP SENSOR

Original	RHPX0238GEZZ
Part No	
Code	PX0238



### Rotational Sensor

### ROTATION SENSOR

Original	RHPX0252GEZZ
Part No	
Suit	VCA200X
Code	PX0252



### Reel Sensor

### REEL SENSOR

IR TX & RX LEDs	
Code	PS6002A



### Infrared Receiver

NATIONAL	PN313B or PH302
Code	PN313



### INFRA-RED RECEIVER

PN323B, PH310, ED360409 and more!	
Equiv.	PH310
Code	PN323



### Components

### SECTION 12

LED Diodes Electronic Components Section 12  
COMPONENTS





## Misc Parts

### Brake Pads

#### AKAI BRAKE PADS

21mm x 5mm  
Supplied in bags of 10 pieces.

Code  
ABP10



#### JVC BRAKE PADS

8mm x 2.5mm  
Supplied 10 pcs/bag.


Original PUM30019-2  
Part No  
Code JBP10



#### SANYO BRAKE PADS

21mm x 3.5mm  
Supplied 10 pcs/bag.


Original 613-055-7117,  
Part No 143-2-712T-05200  
Code SBP10



#### ADHESIVE BRAKE PAD / TENSION BAND FELT


Supplied in a sheet  
100mm x 70mm.  
Just cut to size for application.  
Light grey colour felt.

Code  
TBF170



## Misc Parts


### JVC KNOB SET



Suit HRDX20EA Code PQ21174

#### SHARP CRYSTAL

Original RCRSB0090GEZZ  
Part No  
Code CR0090




MORE X-TALS SEE SECTION 12  
COMPONENTS

## Chroma


### NATIONAL CHROMA PCBs

Code  
VEFC007  
VEFC009  
VEFC013  
VEFC015



### PANASONIC COLOUR MODULES

Suit NVG30 Code VEFH03D  
NVJ1 VEFH04F



### PANASONIC COLOUR MODULES

Suit NVHD100,  
NVSD1, 10  
VEFH29B,  
VEFH29C  
Code VEFH29D



## Switchmode Repair


### PANASONIC SWITCHMODE REPAIR KIT

OEM kit by Panasonic. Includes Resistors, Diodes, Transistors, Required for repair.

Suit NVSD200, 205,  
NVSD207, 250,  
Code VUE4127KIT



### SONY SWITCH MODE



Original	1-413-896-21	1-413-621-11	1-413-897-11
Part No			
Suit	SLVX312PS	SLV777	SLVX835
Type	8 Pin		
Code	PS9621	PSM2111	PSM9711



# Video Repair Parts

## Servicing Tools and Accessories

### UNIVERSAL REMOTES See Section 01

We sell a comprehensive range of pre-programmed and programmable remotes for replacing damaged remotes and/or combining all your remotes into one.

Different styles and features available.

See section 01 AV TV SAT Install  
From ONLY \$15.50 !



### REMOTE CONTROL REPLACEMENT CABLES

6M in length with molded plus & grommets. 3 Types of plugs.

Type 2.5mm plug 3.5mm plug  
Code RCC25 RCC35



### RUBBER KEYPAD REPAIR KIT

#### REMOTE CONTROL REPAIR

Restores conductivity to worn carbon contacts on remote controls & keypads. Repairs are good for at least 500,000 keystrokes. Carbon/silver solution.

#### 50 Applications

Code  
CW2605




### SECURITY TAMPER LABELS

#### "WARNING - WARRANTY VOID IF SEAL BROKEN OR TAMPERED WITH."

Place over screws and seals to prevent tampering. Suit repair shops, etc. Special type sticker that will not peel off in one go. Convenient dispenser box. Roll 500 pieces

Code  
WL500



### UNIVERSAL HEAD EXTRACTOR TOOL

Extract VCR heads without damage to either head or mounting assembly.

Adjustable so as to suit various brand heads.

Code  
HT800



EXTRACT VIDEO HEADS  
SAFELY AND ACCURATELY

### COTTON GLOVES

Eliminate the need to clean heads after fitting by using gloves. Recommended by leading manufacturers. Sold in pairs.

Code  
GLV2



### MECHANICALS GREASE

#### PLASTICS GREASE

Plastic to Plastic or Metal.

Size Code  
35ml SPG35SL



#### MOLYKOTE DX PASTE

White Grease for Surfaces & Bearings.

Size Code  
50g MK6195



#### MOLYKOTE BR 2 PLUS

Metal bearings, etc.

Size Code  
100g LM47




### HAND TOOLS

For our comprehensive servicemans tool range please see section TOOLS & TEST EQUIPMENT

#### PEARL CATCHER

Oops! Retrieve dropped screws.

Code  
PU5



#### DENTIST MIRROR

Look behind things.

Code  
HT922




Please see section 07 TOOLS & TEST EQUIPMENT  
**DOOR CATCH**

#### FRONT FLAP CLOSE

As found on front door flaps on VCRs, DVDs, etc. Push to open Push to close

Code  
DL1902






## GENERAL PURPOSE VHS TEST TAPE

This tape is designed as a preliminary service test tape for standard VCR's. Its cost effectiveness makes it suitable for initial fault finding and mechanical checking. It contains 30 minutes of colour bar signal and 1KHz audio tone.


Code  
VID50



## PRECISION VHS ALIGNMENT TAPE

Highest Quality recording.  
Suit final alignments.  
8 min RF Sweep  
8 min Colour bars 3KHz Tone  
8 min Staircase Monoscope  
333Hz Tone  
6 min Crosshatch, Linearity  
(circle & border)

Code  
VID70



## VHS HIFI ALIGNMENT TAPE

Includes 3KHz & 333Hz tones in linear & HiFi,  
Standard RF Sweep, etc.  
Ideal for final alignment.  
Master Tape.  
8min Colour Bars  
8min Stair Step  
8min Circle & Border  
8min RF Sweep


Code  
VID75



## TRANSPARENT VHS WORKING CASSETTE

VCR servicing is made easier with this tape simulator.  
All functions normally but now you have access to the parts of the mechanism. Saves time and chewed tapes!  
Now with door tab simulator. Clear plastic.

Code  
VID5041



## ELECTRONIC TOOL WALLET

### 25 PIECE REPAIR KIT

An excellent variety of common electronic repair tools for the technician  
Soldering/De-Soldering, Screw drivers, Cutters, all manner of handy items  
Zip-Case 285x195x50mm

Code  
GTK030B

More tools; See Section 07  
TOOLS & TEST EQUIPMENT



## VCR ALIGNMENT TOOLS

Three types are available to adjust AC heads, video heads, tape guide path, transport, etc.



## HAND ASSIST TOOLS

A collection of assorted hand tools scribes, hooks, blades, brushes, etc. designed to assist technicians in repair and servicing. Premium quality. Made in Japan.

Code  
SA10



## TOOLS & TEST EQUIPMENT - SECTION 07

SEE SECTION 07 TOOLS & TEST EQUIPMENT

We also stock a large range of hand tools like screwdrivers needle-noze pliers NEW! Screw head pliers! Cutters, crimpers, seizure clamps, assorted sizes of metal & plastic tweezers plus lots more!





# Video Repair Parts

## CAMCORDER HEADCLEANER

Can be used wet or dry.  
Supplied with cleaning fluid. Non-abrasive

Type	VHS-C	8mm
Code	HL206	HL205



## HEAD CLEANER VHS

Non-Abrasive polyester to clean the entire tape path.  
Includes cleaning solution.  
Note this tape does not have a leader tape and may not function as expected in some machines.



## EXTRA CLEANING SOLUTION

Code	CS500
------	-------

## SUPER QUALITY VIDEO HEAD CLEANERS

Chamois Tip with 45° shaft. Packaged 10 per bag.

Code	VCS10
------	-------



## VIDEO CLEANING SWABS

Lint-less foam swabs with a strong shaft.  
Packaged 20 per bag.

Code	VCS20
------	-------



Full Range In Section 07  
TOOLS & TEST EQUIPMENT

## HEAD CLEANING SPRAY

Our full range is found in the Section  
TOOLS & TEST EQUIPMENT

**ELECTROLUBE 270g**  
Spray can non-residue  
Video Head Cleaner

Code	VID400M
------	---------



## CASSETTE ADAPTOR VHS-C

Adapts the compact camcorder cassette to the normal size. VHS-C Cassettes ONLY! S-VHS Compatible [ NOT 8mm/Hi-8 ] REQUIRES "AA" BATTERY

Code	EL303E
------	--------

NOT FOR 8mm!




## VIDEO SPLICE KIT

Repair or modify VHS or BETA tapes with this splicing jig for precise control of cut & pasting.  
Includes jig, press, blade, adhesive tape and VHS & BETA leader tapes.

### KIT

Code	PC8101
------	--------



## VIDEO SPLICING TABS

Splice tabs for ½" video tape.  
Order one to receive a packet of 90.

Code	MK32
------	------



## VIDEO TAPE SPlicer KIT


Defeats all hassles with repairing and modifying video cassette tapes. This handy unit has clips for holding the door open and releasing the reel ratchet. A grooved plate allows easy alignment of the tape with 'fingers' to hold it in position. Also includes a guillotine blade for accurate & neat splicing of the video tape. Suitable for both VHS & BETA tapes. Comes with instructions and splice tabs. Edit and repair is easy now.

Code	SV620
------	-------

## REPLACEMENT TABS

Splice tabs for ½" video tape. Order one to receive a packet of 90.

Code	MK32
------	------





## VHS VIDEO CASSETTE

Long-Life Anti-Fungus  
Treatment provides high  
reliability for long-term storage.

Brand Maxell\*  
Time 180 min  
Code ME180GX



### TDK

Extra High Grade ideal  
for archiving extra  
special recordings.

Brand TDK  
Time 180 min  
Code EHGE180




\*Brand may change to continue stock.

## S-VHS SUPER VHS CASSETTE

### Super-VHS PRO 240 Min

Absolute premium  
solution High density  
magnetic tape With  
S-VHS identity tag as  
required to work as  
S-VHS TDK or JVC or  
FUJI Brands may be  
supplied. 240 Min.

Code SVHS240



Brand may change  
to continue stock.

## 8mm VIDEO CAMERA CASSETTE

To suit the Video-8 format  
Japan quality & durability\*  
Sony or TDK may be  
supplied Depending on  
availability\*

Time 85min  
Code V8085



## MINI-DV DIGITAL VIDEO CASSETTE

### DVC CAMCORDER CASSETTES

Brand	Type	Time	Code
Panasonic	SD	83minLP 55minSP	DVM83PQ
Panasonic	SD	90minLP 60minSP	DVC090
Sony	HD	94minLP 63minSP	DVM63HD


\*Brands may change to continue stock.



## VIDEO CASSETTE COVERS

Video cassette storage  
cases for VHS and BETA  
Fitted with outer sleeve

Colour Clear Black  
Code VCC2 VCC4





# Video Repair Parts

<b>Cassette Housings</b> .....	80
Akai .....	80
Daewoo / Tempest.....	80
Funai / Teac / Palsonic.....	80
JVC / Philips.....	80
LG / Goldstar.....	80
Mitsubishi .....	81
Panasonic.....	81
Samsung .....	81
Sanyo .....	82
Sharp.....	82
Sony .....	82
<b>Idlers &amp; Gears</b> .....	33
Akai .....	33
Daewoo / NEC / AWA / Tempest .....	36
Funai / Teac / Palsonic .....	38
Hitachi .....	44
JVC.....	45
LG / Goldstar / NEC / Teac.....	40
Mitsubishi / AWA.....	52
NEC.....	54
Orion.....	55
Panasonic.....	55
Samsung .....	63
Sanyo / Fisher / Sony .....	66
Sharp.....	68
Sony .....	75
Teac / Philips .....	79
Toshiba.....	79
<b>Misc Parts</b> .....	95
Brake Pads.....	95
Chroma.....	95
Misc Parts.....	95
Switchmode Repair.....	95
<b>Mode Sensors</b> .....	94
Akai .....	94
Components.....	94
Infrared .....	94
JVC.....	94
JVC.....	94
LG / Goldstar.....	94
National .....	94
NEC .....	94
Reel Sensor.....	94
Rotational Sensor.....	94
Sharp.....	94
Sharp.....	94
Universal Lamps.....	94
<b>Mode Switches</b> .....	87
Akai .....	87
Deitron / Tempest / Tracton .....	88
Funai / Teac .....	88
Goldstar .....	88
Hitachi .....	88
JVC.....	89
LG.....	89
Mitsubishi .....	89
National .....	90
NEC .....	90
Orion.....	91
Panasonic.....	91
Samsung .....	91
Sanyo .....	91
Sharp.....	92
Sony .....	93
<b>Overhaul Kits</b> .....	30
JVC OEM .....	30
JVC Replacement .....	32
National Panasonic OEM .....	31
National Panasonic Replacement .....	32
<b>Pinch Rollers</b> .....	25
Akai .....	25
Daewoo .....	25
Funai / Teac .....	25
Goldstar / LG / NEC .....	25
Hitachi .....	25
JVC / Philips .....	26
Mitsubishi .....	26
National .....	26
NEC .....	26
Panasonic .....	27
Philips / Teac .....	27
Samsung .....	27
Sanyo .....	27
Sharp .....	27
Sony .....	27
Video Pinch Roller Listing .....	28
<b>Motors</b> .....	9
Akai .....	9
Daewoo .....	10
Funai / Teac / Palsonic .....	10
Goldstar / LG .....	10
Hitachi .....	10
JVC .....	11
LG / Goldstar .....	12
Mitsubishi .....	13
National .....	14
NEC .....	14
Panasonic .....	14
Philips .....	15
Samsung .....	15
Sanyo .....	16
Sharp .....	16
Sony .....	19
Teac / Philips .....	19
<b>Servicing Tools and Accessories</b> .....	96
<b>Tension Bands</b> .....	83
Akai .....	83
Funai / Teac / Palsonic .....	83
Hitachi .....	84
JVC .....	84
LG / Goldstar .....	83
Mitsubishi .....	84
NEC .....	85
Panasonic .....	85
Samsung .....	85
Sanyo .....	86
Sharp .....	86
Sony .....	87
<b>Video Belts</b> .....	20
Belt Kits .....	22
Cross Reference .....	20
Idler Tires .....	24
Video Belts & Idler Tyres .....	23
<b>Video Heads</b> .....	2
AC Heads .....	8
Akai / LG .....	5
Funai .....	5
Hitachi .....	5
JVC .....	5
Samsung .....	5
Video Head Cross Reference .....	6